

GDS-Render

v1.1

Generated by Doxygen 1.8.14

Contents

1	Main Page	1
2	Compilation	3
2.1	Preface	3
2.2	Dependencies	3
2.2.1	Program Dependencies	3
2.2.2	Compilation Dependencies	3
2.3	Compilation Instructions	4
2.3.1	General Linux Build Instruction	4
2.3.2	Archlinux Package	4
2.3.3	Warnings	4
3	Layer Mapping File Specification	5
4	Usage	7
4.1	Command Line Interface	7
4.2	Graphical User Interface	7
5	Version Number	9
5.1	Main Versioning Scheme	9
5.1.1	Release Candidates	9
5.1.2	Patch Levels	9
5.2	Git Based Version Number	9
6	GNU GENERAL PUBLIC LICENSE	11

7	GDS-Render Readme	17
8	Module Index	19
8.1	Modules	19
9	Data Structure Index	21
9.1	Data Structures	21
10	File Index	23
10.1	File List	23
11	Module Documentation	25
11.1	Cairo Renderer	25
11.1.1	Detailed Description	26
11.1.2	Macro Definition Documentation	26
11.1.2.1	MAX_LAYERS	26
11.1.3	Function Documentation	26
11.1.3.1	apply_inherited_transform_to_all_layers()	26
11.1.3.2	cairo_render_cell_to_vector_file()	27
11.1.3.3	render_cell()	28
11.1.3.4	revert_inherited_transform()	29
11.2	Command Line Interface	30
11.2.1	Detailed Description	30
11.2.2	Function Documentation	30
11.2.2.1	command_line_convert_gds()	30
11.2.2.2	delete_layer_info_with_name()	32
11.3	External Shared Object Renderer	33
11.3.1	Detailed Description	33
11.3.2	Macro Definition Documentation	33
11.3.2.1	EXTERNAL_LIBRARY_FUNCTION	33
11.3.3	Function Documentation	33
11.3.3.1	external_renderer_render_cell()	33

11.4 Geometric Helper Functions	35
11.4.1 Detailed Description	36
11.4.2 Macro Definition Documentation	36
11.4.2.1 ABS_DBL [1/2]	36
11.4.2.2 ABS_DBL [2/2]	36
11.4.2.3 DEG2RAD	36
11.4.2.4 MAX	36
11.4.2.5 MIN	37
11.4.3 Typedef Documentation	37
11.4.3.1 conv_generic_to_vector_2d_t	37
11.4.4 Function Documentation	37
11.4.4.1 bounding_box_apply_transform()	37
11.4.4.2 bounding_box_calculate_path_box()	38
11.4.4.3 bounding_box_calculate_polygon()	39
11.4.4.4 bounding_box_prepare_empty()	39
11.4.4.5 bounding_box_update_box()	40
11.4.4.6 bounding_box_update_point()	40
11.4.4.7 calculate_cell_bounding_box()	40
11.4.4.8 calculate_path_miter_points()	41
11.4.4.9 convert_gds_point_to_2d_vector()	42
11.4.4.10 update_box_with_gfx()	42
11.4.4.11 vector_2d_abs()	43
11.4.4.12 vector_2d_add()	44
11.4.4.13 vector_2d_alloc()	44
11.4.4.14 vector_2d_calculate_angle_between()	45
11.4.4.15 vector_2d_copy()	45
11.4.4.16 vector_2d_free()	46
11.4.4.17 vector_2d_normalize()	46
11.4.4.18 vector_2d_rotate()	47
11.4.4.19 vector_2d_scalar_multiply()	47

11.4.4.20	<code>vector_2d_scale()</code>	48
11.4.4.21	<code>vector_2d_subtract()</code>	48
11.5	Graphical User Interface	49
11.5.1	Detailed Description	50
11.5.2	Macro Definition Documentation	50
11.5.2.1	<code>RENDERER_TYPE_GUI</code>	50
11.5.3	Enumeration Type Documentation	51
11.5.3.1	<code>cell_store_columns</code>	51
11.5.3.2	<code>gds_render_gui_signal_sig_ids</code>	51
11.5.4	Function Documentation	51
11.5.4.1	<code>cell_selection_changed()</code>	51
11.5.4.2	<code>cell_store_filter_visible_func()</code>	52
11.5.4.3	<code>cell_tree_view_activated()</code>	53
11.5.4.4	<code>change_filter()</code>	54
11.5.4.5	<code>G_DECLARE_FINAL_TYPE()</code>	54
11.5.4.6	<code>gds_render_gui_class_init()</code>	55
11.5.4.7	<code>gds_render_gui_dispose()</code>	55
11.5.4.8	<code>gds_render_gui_get_main_window()</code>	56
11.5.4.9	<code>gds_render_gui_init()</code>	56
11.5.4.10	<code>gds_render_gui_new()</code>	57
11.5.4.11	<code>generate_string_from_date()</code>	58
11.5.4.12	<code>on_convert_clicked()</code>	58
11.5.4.13	<code>on_load_gds()</code>	59
11.5.4.14	<code>on_window_close()</code>	61
11.5.4.15	<code>setup_cell_selector()</code>	61
11.5.4.16	<code>sort_down_callback()</code>	62
11.5.4.17	<code>sort_up_callback()</code>	63
11.5.4.18	<code>tree_sel_func()</code>	64
11.5.5	Variable Documentation	64
11.5.5.1	<code>gds_render_gui_signals</code>	64

11.6 LaTeX/TikZ Renderer	65
11.6.1 Detailed Description	65
11.6.2 Macro Definition Documentation	65
11.6.2.1 LATEX_LINE_BUFFER_KB	65
11.6.2.2 WRITEOUT_BUFFER	66
11.6.3 Function Documentation	66
11.6.3.1 generate_graphics()	66
11.6.3.2 latex_render_cell_to_code()	67
11.6.3.3 render_cell()	68
11.6.3.4 write_layer_definitions()	68
11.6.3.5 write_layer_env()	69
11.7 LayerSelector Object	71
11.7.1 Detailed Description	72
11.7.2 Macro Definition Documentation	72
11.7.2.1 TYPE_LAYER_SELECTOR	73
11.7.3 Enumeration Type Documentation	73
11.7.3.1 layer_selector_sort_algo	73
11.7.4 Function Documentation	73
11.7.4.1 G_DECLARE_FINAL_TYPE()	73
11.7.4.2 layer_selector_analyze_cell_layers()	73
11.7.4.3 layer_selector_check_if_layer_widget_exists()	74
11.7.4.4 layer_selector_class_init()	75
11.7.4.5 layer_selector_clear_widgets()	76
11.7.4.6 layer_selector_dispose()	76
11.7.4.7 layer_selector_drag_data_received()	76
11.7.4.8 layer_selector_drag_leave()	77
11.7.4.9 layer_selector_drag_motion()	77
11.7.4.10 layer_selector_export_rendered_layer_info()	78
11.7.4.11 layer_selector_find_layer_element_in_list()	79
11.7.4.12 layer_selector_force_sort()	80

11.7.4.13	<code>layer_selector_generate_layer_widgets()</code>	81
11.7.4.14	<code>layer_selector_get_last_row()</code>	82
11.7.4.15	<code>layer_selector_get_row_after()</code>	82
11.7.4.16	<code>layer_selector_get_row_before()</code>	83
11.7.4.17	<code>layer_selector_init()</code>	83
11.7.4.18	<code>layer_selector_load_layer_mapping_from_file()</code>	83
11.7.4.19	<code>layer_selector_load_mapping_clicked()</code>	84
11.7.4.20	<code>layer_selector_new()</code>	85
11.7.4.21	<code>layer_selector_save_layer_mapping_data()</code>	86
11.7.4.22	<code>layer_selector_save_mapping_clicked()</code>	87
11.7.4.23	<code>layer_selector_set_load_mapping_button()</code>	88
11.7.4.24	<code>layer_selector_set_save_mapping_button()</code>	89
11.7.4.25	<code>layer_selector_setup_dnd()</code>	90
11.7.4.26	<code>layer_selector_sort_func()</code>	91
11.7.4.27	<code>sel_layer_element_drag_begin()</code>	92
11.7.4.28	<code>sel_layer_element_drag_data_get()</code>	92
11.7.4.29	<code>sel_layer_element_drag_end()</code>	93
11.7.4.30	<code>sel_layer_element_setup_dnd_callbacks()</code>	93
11.7.5	Variable Documentation	94
11.7.5.1	<code>dnd_additional_css</code>	94
11.8	LibCellRenderer GObject	95
11.8.1	Detailed Description	96
11.8.2	Macro Definition Documentation	96
11.8.2.1	<code>LIB_CELL_RENDERER_ERROR_ERR</code>	96
11.8.2.2	<code>LIB_CELL_RENDERER_ERROR_WARN</code>	96
11.8.2.3	<code>TYPE_LIB_CELL_RENDERER</code>	96
11.8.3	Typedef Documentation	97
11.8.3.1	LibCellRenderer	97
11.8.4	Enumeration Type Documentation	97
11.8.4.1	anonymous enum	97

11.8.5	Function Documentation	97
11.8.5.1	convert_error_level_to_color()	97
11.8.5.2	lib_cell_renderer_class_init()	98
11.8.5.3	lib_cell_renderer_constructed()	98
11.8.5.4	lib_cell_renderer_get_property()	99
11.8.5.5	lib_cell_renderer_get_type()	99
11.8.5.6	lib_cell_renderer_init()	99
11.8.5.7	lib_cell_renderer_new()	100
11.8.5.8	lib_cell_renderer_set_property()	100
11.8.6	Variable Documentation	101
11.8.6.1	properties	101
11.9	Output Renderers	102
11.9.1	Detailed Description	102
11.10	Custom GTK Widgets	103
11.10.1	Detailed Description	103
11.11	GDS-Utilities	104
11.11.1	Detailed Description	106
11.11.2	Macro Definition Documentation	106
11.11.2.1	CELL_NAME_MAX	106
11.11.2.2	GDS_DEFAULT_UNITS	106
11.11.2.3	GDS_ERROR	106
11.11.2.4	GDS_INF	107
11.11.2.5	GDS_PRINT_DEBUG_INFOS	107
11.11.2.6	GDS_WARN	107
11.11.2.7	MAX	107
11.11.2.8	MIN	107
11.11.3	Enumeration Type Documentation	107
11.11.3.1	anonymous enum	107
11.11.3.2	gds_record	108
11.11.3.3	graphics_type	108

11.11.3.4 path_type	109
11.11.4 Function Documentation	109
11.11.4.1 append_cell()	109
11.11.4.2 append_cell_ref()	110
11.11.4.3 append_graphics()	111
11.11.4.4 append_library()	111
11.11.4.5 append_vertex()	112
11.11.4.6 clear_lib_list()	112
11.11.4.7 convert_aref_to_sref()	113
11.11.4.8 delete_cell_element()	114
11.11.4.9 delete_cell_inst_element()	115
11.11.4.10 delete_graphics_obj()	116
11.11.4.11 delete_library_element()	116
11.11.4.12 delete_vertex()	117
11.11.4.13 gds_convert_double()	118
11.11.4.14 gds_convert_signed_int()	118
11.11.4.15 gds_convert_signed_int16()	119
11.11.4.16 gds_convert_unsigned_int16()	119
11.11.4.17 gds_parse_date()	120
11.11.4.18 gds_tree_check_cell_references()	121
11.11.4.19 gds_tree_check_iterate_ref_and_check()	122
11.11.4.20 gds_tree_check_list_contains_cell()	123
11.11.4.21 gds_tree_check_reference_loops()	124
11.11.4.22 name_array_cell_ref()	125
11.11.4.23 name_cell()	125
11.11.4.24 name_cell_ref()	126
11.11.4.25 name_library()	127
11.11.4.26 parse_gds_from_file()	127
11.11.4.27 parse_reference_list()	128
11.11.4.28 scan_cell_reference_dependencies()	129

11.11.4.2	scan_library_references()	130
11.12	Mapping-Parser	131
11.12.1	Detailed Description	131
11.12.2	Function Documentation	131
11.12.2.1	mapping_parser_gen_csv_line()	131
11.12.2.2	mapping_parser_load_line()	132
11.13	Version Number	134
11.13.1	Detailed Description	134
11.13.2	Variable Documentation	134
11.13.2.1	_app_version_string [1/2]	134
11.13.2.2	_app_version_string [2/2]	134
11.14	RendererSettingsDialog	135
11.14.1	Detailed Description	136
11.14.2	Macro Definition Documentation	136
11.14.2.1	RENDERER_TYPE_SETTINGS_DIALOG	136
11.14.3	Enumeration Type Documentation	136
11.14.3.1	anonymous enum	136
11.14.3.2	output_renderer	137
11.14.4	Function Documentation	137
11.14.4.1	convert_number_to_engineering()	137
11.14.4.2	hide_tex_options()	137
11.14.4.3	latex_render_callback()	138
11.14.4.4	renderer_settings_dialog_class_init()	138
11.14.4.5	renderer_settings_dialog_get_property()	139
11.14.4.6	renderer_settings_dialog_get_settings()	139
11.14.4.7	renderer_settings_dialog_init()	140
11.14.4.8	renderer_settings_dialog_new()	140
11.14.4.9	renderer_settings_dialog_set_cell_height()	141
11.14.4.10	renderer_settings_dialog_set_cell_width()	141
11.14.4.11	renderer_settings_dialog_set_database_unit_scale()	142

11.14.4.12	renderer_settings_dialog_set_property()	143
11.14.4.13	renderer_settings_dialog_set_settings()	143
11.14.4.14	renderer_settings_dialog_update_labels()	144
11.14.4.15	scale_value_changed()	145
11.14.4.16	shape_drawer_drawing_callback()	146
11.14.4.17	show_tex_options()	146
11.14.5	Variable Documentation	146
11.14.5.1	properties	146
11.15	LayerElement	147
11.15.1	Detailed Description	148
11.15.2	Macro Definition Documentation	148
11.15.2.1	TYPE_LAYER_ELEMENT	148
11.15.3	Typedef Documentation	148
11.15.3.1	LayerElementPriv	148
11.15.4	Function Documentation	148
11.15.4.1	layer_element_class_init()	148
11.15.4.2	layer_element_constructed()	149
11.15.4.3	layer_element_dispose()	149
11.15.4.4	layer_element_get_color()	149
11.15.4.5	layer_element_get_export()	150
11.15.4.6	layer_element_get_layer()	150
11.15.4.7	layer_element_get_name()	151
11.15.4.8	layer_element_init()	152
11.15.4.9	layer_element_new()	152
11.15.4.10	layer_element_set_color()	152
11.15.4.11	layer_element_set_dnd_callbacks()	153
11.15.4.12	layer_element_set_export()	153
11.15.4.13	layer_element_set_layer()	154
11.15.4.14	layer_element_set_name()	154

12 Data Structure Documentation	157
12.1 <code>gds_cell_checks::_check_internals</code> Struct Reference	157
12.1.1 Detailed Description	157
12.1.2 Field Documentation	157
12.1.2.1 <code>marker</code>	157
12.2 <code>_GdsRenderGui</code> Struct Reference	158
12.2.1 Detailed Description	158
12.2.2 Field Documentation	158
12.2.2.1 <code>cell_search_entry</code>	158
12.2.2.2 <code>cell_tree_store</code>	159
12.2.2.3 <code>cell_tree_view</code>	159
12.2.2.4 <code>convert_button</code>	159
12.2.2.5 <code>gds_libraries</code>	159
12.2.2.6 <code>layer_selector</code>	159
12.2.2.7 <code>main_window</code>	159
12.2.2.8 <code>parent</code>	160
12.2.2.9 <code>render_dialog_settings</code>	160
12.3 <code>_LayerElement</code> Struct Reference	160
12.3.1 Detailed Description	160
12.3.2 Field Documentation	161
12.3.2.1 <code>parent</code>	161
12.3.2.2 <code>priv</code>	161
12.4 <code>_LayerElementPriv</code> Struct Reference	161
12.4.1 Detailed Description	161
12.4.2 Field Documentation	161
12.4.2.1 <code>color</code>	162
12.4.2.2 <code>event_handle</code>	162
12.4.2.3 <code>export</code>	162
12.4.2.4 <code>layer</code>	162
12.4.2.5 <code>layer_num</code>	162

12.4.2.6	name	162
12.5	_LayerSelector Struct Reference	163
12.5.1	Detailed Description	163
12.5.2	Field Documentation	163
12.5.2.1	associated_load_button	163
12.5.2.2	associated_save_button	163
12.5.2.3	dnd_target	163
12.5.2.4	dummy	164
12.5.2.5	list_box	164
12.5.2.6	load_parent_window	164
12.5.2.7	parent	164
12.5.2.8	save_parent_window	164
12.6	_LibCellRenderer Struct Reference	164
12.6.1	Detailed Description	165
12.6.2	Field Documentation	165
12.6.2.1	super	165
12.7	_RendererSettingsDialog Struct Reference	165
12.7.1	Detailed Description	165
12.7.2	Field Documentation	166
12.7.2.1	cell_height	166
12.7.2.2	cell_width	166
12.7.2.3	layer_check	166
12.7.2.4	parent	166
12.7.2.5	radio_cairo_pdf	166
12.7.2.6	radio_cairo_svg	167
12.7.2.7	radio_latex	167
12.7.2.8	scale	167
12.7.2.9	shape_drawing	167
12.7.2.10	standalone_check	167
12.7.2.11	unit_in_meters	167

12.7.2.12 x_label	168
12.7.2.13 x_output_label	168
12.7.2.14 y_label	168
12.7.2.15 y_output_label	168
12.8 bounding_box::_vectors Struct Reference	168
12.8.1 Detailed Description	169
12.8.2 Field Documentation	169
12.8.2.1 lower_left	169
12.8.2.2 upper_right	169
12.9 application_data Struct Reference	169
12.9.1 Detailed Description	170
12.9.2 Field Documentation	170
12.9.2.1 app	170
12.9.2.2 gui_list	170
12.10 bounding_box Union Reference	170
12.10.1 Detailed Description	171
12.10.2 Field Documentation	171
12.10.2.1 vector_array	171
12.10.2.2 vectors	171
12.11 cairo_layer Struct Reference	171
12.11.1 Detailed Description	172
12.11.2 Field Documentation	172
12.11.2.1 cr	172
12.11.2.2 linfo	172
12.11.2.3 rec	172
12.12 gds_cell Struct Reference	173
12.12.1 Detailed Description	173
12.12.2 Field Documentation	174
12.12.2.1 access_time	174
12.12.2.2 checks	174

12.12.2.3 child_cells	174
12.12.2.4 graphic_objs	174
12.12.2.5 mod_time	174
12.12.2.6 name	175
12.12.2.7 parent_library	175
12.13gds_cell_array_instance Struct Reference	175
12.13.1 Detailed Description	176
12.13.2 Field Documentation	176
12.13.2.1 angle	176
12.13.2.2 cell_ref	176
12.13.2.3 columns	177
12.13.2.4 control_points	177
12.13.2.5 flipped	177
12.13.2.6 magnification	177
12.13.2.7 ref_name	177
12.13.2.8 rows	178
12.14gds_cell_checks Struct Reference	178
12.14.1 Detailed Description	179
12.14.2 Field Documentation	179
12.14.2.1 _internal	179
12.14.2.2 affected_by_reference_loop	179
12.14.2.3 unresolved_child_count	179
12.15gds_cell_instance Struct Reference	180
12.15.1 Detailed Description	180
12.15.2 Field Documentation	181
12.15.2.1 angle	181
12.15.2.2 cell_ref	181
12.15.2.3 flipped	181
12.15.2.4 magnification	181
12.15.2.5 origin	181

12.15.2.6 ref_name	182
12.16gds_graphics Struct Reference	182
12.16.1 Detailed Description	182
12.16.2 Field Documentation	182
12.16.2.1 datatype	182
12.16.2.2 gfx_type	183
12.16.2.3 layer	183
12.16.2.4 path_render_type	183
12.16.2.5 vertices	183
12.16.2.6 width_absolute	183
12.17gds_library Struct Reference	184
12.17.1 Detailed Description	184
12.17.2 Field Documentation	184
12.17.2.1 access_time	184
12.17.2.2 cell_names	185
12.17.2.3 cells	185
12.17.2.4 mod_time	185
12.17.2.5 name	185
12.17.2.6 unit_in_meters	185
12.18gds_point Struct Reference	186
12.18.1 Detailed Description	186
12.18.2 Field Documentation	186
12.18.2.1 x	186
12.18.2.2 y	186
12.19gds_time_field Struct Reference	186
12.19.1 Detailed Description	187
12.19.2 Field Documentation	187
12.19.2.1 day	187
12.19.2.2 hour	187
12.19.2.3 minute	187

12.19.2.4 month	187
12.19.2.5 second	188
12.19.2.6 year	188
12.20layer_element_dnd_data Struct Reference	188
12.20.1 Detailed Description	188
12.20.2 Field Documentation	188
12.20.2.1 drag_begin	189
12.20.2.2 drag_data_get	189
12.20.2.3 drag_end	189
12.20.2.4 entries	189
12.20.2.5 entry_count	189
12.21layer_info Struct Reference	190
12.21.1 Detailed Description	190
12.21.2 Field Documentation	190
12.21.2.1 color	190
12.21.2.2 layer	190
12.21.2.3 name	191
12.21.2.4 stacked_position	191
12.22render_settings Struct Reference	191
12.22.1 Detailed Description	191
12.22.2 Field Documentation	192
12.22.2.1 renderer	192
12.22.2.2 scale	192
12.22.2.3 tex_pdf_layers	192
12.22.2.4 tex_standalone	192
12.23tree_stores Struct Reference	193
12.23.1 Detailed Description	193
12.23.2 Field Documentation	193
12.23.2.1 base_store	193
12.23.2.2 base_tree_view	193
12.23.2.3 filter	193
12.23.2.4 search_entry	194
12.24vector_2d Struct Reference	194
12.24.1 Detailed Description	194
12.24.2 Field Documentation	194
12.24.2.1 x	194
12.24.2.2 y	194

13 File Documentation	195
13.1 bounding-box.c File Reference	195
13.1.1 Detailed Description	196
13.2 bounding-box.c	196
13.3 bounding-box.h File Reference	199
13.3.1 Detailed Description	200
13.4 bounding-box.h	200
13.5 cairo-output.c File Reference	201
13.5.1 Detailed Description	202
13.6 cairo-output.c	202
13.7 cairo-output.h File Reference	205
13.7.1 Detailed Description	207
13.8 cairo-output.h	207
13.9 cairo-renderer.dox File Reference	207
13.10 cell-geometrics.c File Reference	207
13.10.1 Detailed Description	208
13.11 cell-geometrics.c	209
13.12 cell-geometrics.h File Reference	210
13.12.1 Detailed Description	211
13.13 cell-geometrics.h	211
13.14 command-line.c File Reference	212
13.14.1 Detailed Description	212
13.15 command-line.c	213
13.16 command-line.dox File Reference	215
13.17 command-line.h File Reference	215
13.17.1 Detailed Description	216
13.18 command-line.h	216
13.19 compilation.dox File Reference	217
13.20 conv-settings-dialog.c File Reference	217
13.20.1 Detailed Description	218

13.21conv-settings-dialog.c	218
13.22conv-settings-dialog.h File Reference	223
13.22.1 Detailed Description	225
13.23conv-settings-dialog.h	225
13.24external-renderer.c File Reference	226
13.24.1 Detailed Description	226
13.25external-renderer.c	227
13.26external-renderer.dox File Reference	227
13.27external-renderer.h File Reference	227
13.27.1 Detailed Description	229
13.28external-renderer.h	229
13.29gds-parser.c File Reference	229
13.29.1 Detailed Description	232
13.30gds-parser.c	232
13.31gds-parser.h File Reference	244
13.31.1 Detailed Description	245
13.32gds-parser.h	245
13.33gds-render-gui.c File Reference	245
13.33.1 Detailed Description	247
13.34gds-render-gui.c	247
13.35gds-render-gui.h File Reference	253
13.35.1 Detailed Description	254
13.36gds-render-gui.h	254
13.37gds-tree-checker.c File Reference	255
13.37.1 Detailed Description	256
13.38gds-tree-checker.c	256
13.39gds-tree-checker.h File Reference	258
13.39.1 Detailed Description	259
13.40gds-tree-checker.h	260
13.41gds-types.h File Reference	260

13.41.1 Detailed Description	261
13.42gds-types.h	262
13.43geometric.dox File Reference	263
13.44gpl-2.0.md File Reference	263
13.45gpl-2.0.md	263
13.46gui.dox File Reference	267
13.47latex-output.c File Reference	267
13.47.1 Detailed Description	268
13.48latex-output.c	269
13.49latex-output.h File Reference	271
13.49.1 Detailed Description	273
13.50latex-output.h	273
13.51latex-renderer.dox File Reference	273
13.52layer-element.c File Reference	273
13.52.1 Detailed Description	275
13.53layer-element.c	275
13.54layer-element.h File Reference	276
13.54.1 Detailed Description	278
13.55layer-element.h	278
13.56layer-info.c File Reference	279
13.56.1 Detailed Description	280
13.56.2 Function Documentation	280
13.56.2.1 layer_info_delete_struct()	280
13.57layer-info.c	281
13.58layer-info.h File Reference	281
13.58.1 Detailed Description	282
13.58.2 Function Documentation	283
13.58.2.1 layer_info_delete_struct()	283
13.59layer-info.h	283
13.60layer-selector.c File Reference	284

13.60.1 Detailed Description	285
13.61 layer-selector.c	286
13.62 layer-selector.dox File Reference	294
13.63 layer-selector.h File Reference	294
13.63.1 Detailed Description	296
13.64 layer-selector.h	296
13.65 lib-cell-renderer.c File Reference	297
13.65.1 Detailed Description	298
13.66 lib-cell-renderer.c	298
13.67 lib-cell-renderer.dox File Reference	300
13.68 lib-cell-renderer.h File Reference	300
13.68.1 Detailed Description	301
13.69 lib-cell-renderer.h	301
13.70 lmf-spec.dox File Reference	302
13.71 main-page.dox File Reference	302
13.72 main.c File Reference	302
13.72.1 Detailed Description	303
13.72.2 Function Documentation	303
13.72.2.1 app_about()	303
13.72.2.2 app_quit()	303
13.72.2.3 gapp_activate()	305
13.72.2.4 gui_window_closed_callback()	306
13.72.2.5 main()	306
13.72.2.6 print_version()	307
13.72.2.7 start_gui()	308
13.72.3 Variable Documentation	309
13.72.3.1 app_actions	309
13.73 main.c	309
13.74 mapping-parser.c File Reference	312
13.74.1 Detailed Description	313

13.75mapping-parser.c	314
13.76mapping-parser.h File Reference	315
13.76.1 Detailed Description	316
13.77mapping-parser.h	317
13.78README.MD File Reference	317
13.79README.MD	317
13.80renderers.dox File Reference	317
13.81tree-store.c File Reference	317
13.82tree-store.c	318
13.83tree-store.h File Reference	320
13.83.1 Detailed Description	321
13.84tree-store.h	322
13.85usage.dox File Reference	322
13.86vector-operations.c File Reference	322
13.86.1 Detailed Description	323
13.87vector-operations.c	324
13.88vector-operations.h File Reference	325
13.88.1 Detailed Description	327
13.89vector-operations.h	327
13.90version.c File Reference	328
13.91version.c	328
13.92version.h File Reference	328
13.93version.h	329
13.94versioning.dox File Reference	329
13.95widgets.dox File Reference	329

Chapter 1

Main Page

This program converts GDS layout files to

- PDF Files using the [Cairo Renderer](#)
- Latex code (TikZ) using the [LaTeX/TikZ Renderer](#)

See the [Usage](#) page for details and [Compilation](#) for building instructions and [Version Number](#) for the versioning scheme of this program.

Chapter 2

Compilation

2.1 Preface

GDS-Render is designed for UNIX-like, especially GNU/Linux based systems. It was developed under a Linux system. Therefore, best performance is expected using a Linux operating system.

2.2 Dependencies

The dependencies of GDS-Render are:

2.2.1 Program Dependencies

- GLib2
- GTK3
- Cairographics

2.2.2 Compilation Dependencies

These dependencies are not needed for running the program; just for compilation.

- Build System (GCC + binutils, make, etc...). Most distributions supply a "development" meta-package containing this stuff.
- cmake \geq 2.8
- More or less optional: git. Used for extraction of the precise version number. It is strongly recommended to provide git!
- Optional: doxygen for this nice documentation.

The dependency list of GTK3 already includes Cairographics and GLib2. You should be on the safe side with a recent GTK3 version.

Development is done with the following library versions:

Cairographics	GLib2	GTK3
1.16.0-2	2.60.0-1	3.↔ 24.7

2.3 Compilation Instructions

2.3.1 General Linux Build Instruction

Go to the build directory you want to compile in. This may be the gds-render project root. Execute

```
cmake <Path to gds-render root>
```

Cmake will check the dependencies. Once cmake has finished. Type

```
make
```

in order to build the program and

```
make documentation
```

to build the doxygen documentation.

2.3.2 Archlinux Package

The subfolder 'AUR' contains a PKGBUILD file to build an Archlinux/Pacman package.

2.3.3 Warnings

The compiler will throw the following warnings. Compiled with GCC 8.2.1.

Warning	Assessment
warning: 'calculate_path_miter_points' defined but not used [-Wunused-function]	Ignore. Function will be used in later versions.

Chapter 3

Layer Mapping File Specification

File Format

The layer mapping file contains information on how to render the layers. The information is stored in CSV format – *True CSV*; not that rubbish with semicolons that Excel calls CSV.

Each line representing a layer consists of following fields:

layer,r,g,b,a,export,name

- **layer**: Layer number identifying this layer.
- **r,b,g,a**: RGBA color value using double precision float values in the range from 0 to 1.
- **export**: Either '1' or '0'. Defining whether to render this layer into the output file.
- **name**: The name of the layer.

the order of the layers inside the layer mapping file defines the layer stack in the rendered output. The first layer is at the bottom, the last at the top.

Handling Inside the GUI

The layer mapping file can be imported and exported inside the GUI.

Export

During export, all layer configurations are written to the mapping file

Import

During import, all layer configurations are loaded from the mapping file. This overwrites any configuration done to that layer. Layers that are not present in the layer mapping file are appended at the end of the list. This means, they are rendered on top of the other layers. Because the layer mapping file does not contain any information on these layers, their configuration is not reset during import.

Chapter 4

Usage

4.1 Command Line Interface

To use the application on the command line check 'gds-render --help'.


Application Options:

- -t, --tikz Output TikZ code
- -p, --pdf Output PDF document
- -s, --scale=SCALE Divide output coordinates by SCALE
- -o, --tex-output=PATH Optional path for TeX file
- -O, --pdf-output=PATH Optional path for PDF file
- -m, --mapping=PATH Path for Layer Mapping File
- -c, --cell=NAME Cell to render
- -a, --tex-standalone Create standalone PDF
- -l, --tex-layers Create PDF Layers (OCG)
- -P, --custom-render-lib=PATH Path to a custom shared object, that implements the `render_cell_to_file` function
- -e, --external-lib-output=PATH Output path for external render library
- --display=DISPLAY X display to use

4.2 Graphical User Interface

The graphical user interface (GUI) can be used to open GDS Files, configure the layer rendering (colors, order, transparency etc.), and convert cells.

It is possible to export the layer configurations so they can be used later on. Even in the [Command Line Interface](#)



The cell selector on the left shows the GDS Libraries and Cells. The cells are marked green if all references inside the cell could be found. If not all references could be found, the cell is marked orange. This doesn't show if child cells have missing childs. Only one level of the hierarchy is checked in order to make it easier to spot an erroneous cell. Cells with missing child cells are still renderable but – obviously – faulty. If a cell or any sub-cell contains a reference loop, the cell is marked red. In this case it can't be selected for rendering.

In the above image the cell is green; so everything is okay.

Chapter 5

Version Number

5.1 Main Versioning Scheme

The version number of this application consists of a given version in the format of 'v1.0'. Where the first number indicates a major release and the second number indicates minor changes.

Versions, including release candidates and path-levels, are tagged in git.

5.1.1 Release Candidates

Release candidates are software versions that seem stable and functional to become a new version but testing is not fully finished. These versions are marked with an '-rcX', where X is the number of the release candidate. The 3rd release candidate of version 4.2 would be 'v4.2-rc3'. Release candidates are in a frozen state. Only bugfixes that are necessary for functionality are applied to these versions before releasing the final version.

5.1.2 Patch Levels

If an already released version contains bugs that need to be fixed, the version number is not incremented. Instead a new version number with a patch-level is created. The patch-level is appended with a dash directly after the version number. The first patch-level of version 3.5 would be: 'v3.5-1'.

5.2 Git Based Version Number

The application and this documentation contain a git-based version number. With this version number not only released versions but all development points of the software can be uniquely identified.

An example for such a version number is: *v1.0-rc4-41-gaa41373-dirty*

It consists of the last [Main Versioning Scheme](#) (in this case version 1.0 – Release candidate 4) and some other information from the source code management system. The number after the version tag is the commit count after the given version. In this case the specified version is 41 commits after the last tagged version 'v1.0-rc4'. The next section always starts with a 'g' (for git) and after that contains the first letters of the commit ID. In this case an additional '-dirty' is appended, showing that the software version contains unstaged changes.

In tabular form: *v1.0-rc4-41-gaa41373-dirty*

Last tagged version	Commits since that version	Start of commit ID	Unstaged changes?
1.0-rc4	41	aa41373	yes

This git-based version number is automatically put into the application and this documentation during the application's compilation / the documentation's generation. For this *git* is needed. Therefore, it is highly recommended to have 'git' installed for compilation although it is no build dependency. In case of a missing git installation, the string "! version not set !" is compiled into the application.

Chapter 6

GNU GENERAL PUBLIC LICENSE

Version 2, June 1991

Copyright (C) 1989, 1991 Free Software Foundation, Inc.
51 Franklin Street, Fifth Floor, Boston, MA 02110-1301, USA

Everyone is permitted to copy and distribute verbatim copies
of this license document, but changing it is not allowed.

Preamble

The licenses for most software are designed to take away your freedom to share and change it. By contrast, the GNU General Public License is intended to guarantee your freedom to share and change free software—to make sure the software is free for all its users. This General Public License applies to most of the Free Software Foundation's software and to any other program whose authors commit to using it. (Some other Free Software Foundation software is covered by the GNU Lesser General Public License instead.) You can apply it to your programs, too.

When we speak of free software, we are referring to freedom, not price. Our General Public Licenses are designed to make sure that you have the freedom to distribute copies of free software (and charge for this service if you wish), that you receive source code or can get it if you want it, that you can change the software or use pieces of it in new free programs; and that you know you can do these things.

To protect your rights, we need to make restrictions that forbid anyone to deny you these rights or to ask you to surrender the rights. These restrictions translate to certain responsibilities for you if you distribute copies of the software, or if you modify it.

For example, if you distribute copies of such a program, whether gratis or for a fee, you must give the recipients all the rights that you have. You must make sure that they, too, receive or can get the source code. And you must show them these terms so they know their rights.

We protect your rights with two steps: (1) copyright the software, and (2) offer you this license which gives you legal permission to copy, distribute and/or modify the software.

Also, for each author's protection and ours, we want to make certain that everyone understands that there is no warranty for this free software. If the software is modified by someone else and passed on, we want its recipients to know that what they have is not the original, so that any problems introduced by others will not reflect on the original authors' reputations.

Finally, any free program is threatened constantly by software patents. We wish to avoid the danger that redistributors of a free program will individually obtain patent licenses, in effect making the program proprietary. To prevent this, we have made it clear that any patent must be licensed for everyone's free use or not licensed at all.

The precise terms and conditions for copying, distribution and modification follow.

TERMS AND CONDITIONS FOR COPYING, DISTRIBUTION AND MODIFICATION

0. This License applies to any program or other work which contains a notice placed by the copyright holder saying it may be distributed under the terms of this General Public License. The "Program", below, refers to any such program or work, and a "work based on the Program" means either the Program or any derivative work under copyright law: that is to say, a work containing the Program or a portion of it, either verbatim or with modifications and/or translated into another language. (Hereinafter, translation is included without limitation in the term "modification".) Each licensee is addressed as "you".

Activities other than copying, distribution and modification are not covered by this License; they are outside its scope. The act of running the Program is not restricted, and the output from the Program is covered only if its contents constitute a work based on the Program (independent of having been made by running the Program). Whether that is true depends on what the Program does.

1. You may copy and distribute verbatim copies of the Program's source code as you receive it, in any medium, provided that you conspicuously and appropriately publish on each copy an appropriate copyright notice and disclaimer of warranty; keep intact all the notices that refer to this License and to the absence of any warranty; and give any other recipients of the Program a copy of this License along with the Program.

You may charge a fee for the physical act of transferring a copy, and you may at your option offer warranty protection in exchange for a fee.

2. You may modify your copy or copies of the Program or any portion of it, thus forming a work based on the Program, and copy and distribute such modifications or work under the terms of Section 1 above, provided that you also meet all of these conditions:

a) You must cause the modified files to carry prominent notices stating that you changed the files and the date of any change.

b) You must cause any work that you distribute or publish, that in whole or in part contains or is derived from the Program or any part thereof, to be licensed as a whole at no charge to all third parties under the terms of this License.

c) If the modified program normally reads commands interactively when run, you must cause it, when started running for such interactive use in the most ordinary way, to print or display an announcement including an appropriate copyright notice and a notice that there is no warranty (or else, saying that you provide a warranty) and that users may redistribute the program under these conditions, and telling the user how to view a copy of this License. (Exception: if the Program itself is interactive but does not normally print such an announcement, your work based on the Program is not required to print an announcement.)

These requirements apply to the modified work as a whole. If identifiable sections of that work are not derived from the Program, and can be reasonably considered independent and separate works in themselves, then this License, and its terms, do not apply to those sections when you distribute them as separate works. But when you distribute the same sections as part of a whole which is a work based on the Program, the distribution of the whole must be on the terms of this License, whose permissions for other licensees extend to the entire whole, and thus to each and every part regardless of who wrote it.

Thus, it is not the intent of this section to claim rights or contest your rights to work written entirely by you; rather, the intent is to exercise the right to control the distribution of derivative or collective works based on the Program.

In addition, mere aggregation of another work not based on the Program with the Program (or with a work based on the Program) on a volume of a storage or distribution medium does not bring the other work under the scope of this License.

3. You may copy and distribute the Program (or a work based on it, under Section 2) in object code or executable form under the terms of Sections 1 and 2 above provided that you also do one of the following:

- a)** Accompany it with the complete corresponding machine-readable source code, which must be distributed under the terms of Sections 1 and 2 above on a medium customarily used for software interchange; or,
- b)** Accompany it with a written offer, valid for at least three years, to give any third party, for a charge no more than your cost of physically performing source distribution, a complete machine-readable copy of the corresponding source code, to be distributed under the terms of Sections 1 and 2 above on a medium customarily used for software interchange; or,
- c)** Accompany it with the information you received as to the offer to distribute corresponding source code. (This alternative is allowed only for noncommercial distribution and only if you received the program in object code or executable form with such an offer, in accord with Subsection b above.)

The source code for a work means the preferred form of the work for making modifications to it. For an executable work, complete source code means all the source code for all modules it contains, plus any associated interface definition files, plus the scripts used to control compilation and installation of the executable. However, as a special exception, the source code distributed need not include anything that is normally distributed (in either source or binary form) with the major components (compiler, kernel, and so on) of the operating system on which the executable runs, unless that component itself accompanies the executable.

If distribution of executable or object code is made by offering access to copy from a designated place, then offering equivalent access to copy the source code from the same place counts as distribution of the source code, even though third parties are not compelled to copy the source along with the object code.

4. You may not copy, modify, sublicense, or distribute the Program except as expressly provided under this License. Any attempt otherwise to copy, modify, sublicense or distribute the Program is void, and will automatically terminate your rights under this License. However, parties who have received copies, or rights, from you under this License will not have their licenses terminated so long as such parties remain in full compliance.

5. You are not required to accept this License, since you have not signed it. However, nothing else grants you permission to modify or distribute the Program or its derivative works. These actions are prohibited by law if you do not accept this License. Therefore, by modifying or distributing the Program (or any work based on the Program), you indicate your acceptance of this License to do so, and all its terms and conditions for copying, distributing or modifying the Program or works based on it.

6. Each time you redistribute the Program (or any work based on the Program), the recipient automatically receives a license from the original licensor to copy, distribute or modify the Program subject to these terms and conditions. You may not impose any further restrictions on the recipients' exercise of the rights granted herein. You are not responsible for enforcing compliance by third parties to this License.

7. If, as a consequence of a court judgment or allegation of patent infringement or for any other reason (not limited to patent issues), conditions are imposed on you (whether by court order, agreement or otherwise) that contradict the conditions of this License, they do not excuse you from the conditions of this License. If you cannot distribute so as to satisfy simultaneously your obligations under this License and any other pertinent obligations, then as a consequence you may not distribute the Program at all. For example, if a patent license would not permit royalty-free redistribution of the Program by all those who receive copies directly or indirectly through you, then the only way you could satisfy both it and this License would be to refrain entirely from distribution of the Program.

If any portion of this section is held invalid or unenforceable under any particular circumstance, the balance of the section is intended to apply and the section as a whole is intended to apply in other circumstances.

It is not the purpose of this section to induce you to infringe any patents or other property right claims or to contest validity of any such claims; this section has the sole purpose of protecting the integrity of the free software distribution system, which is implemented by public license practices. Many people have made generous contributions to the wide range of software distributed through that system in reliance on consistent application of that system; it is up to the author/donor to decide if he or she is willing to distribute software through any other system and a licensee cannot impose that choice.

This section is intended to make thoroughly clear what is believed to be a consequence of the rest of this License.

8. If the distribution and/or use of the Program is restricted in certain countries either by patents or by copyrighted interfaces, the original copyright holder who places the Program under this License may add an explicit geographical distribution limitation excluding those countries, so that distribution is permitted only in or among countries not thus excluded. In such case, this License incorporates the limitation as if written in the body of this License.

9. The Free Software Foundation may publish revised and/or new versions of the General Public License from time to time. Such new versions will be similar in spirit to the present version, but may differ in detail to address new problems or concerns.

Each version is given a distinguishing version number. If the Program specifies a version number of this License which applies to it and "any later version", you have the option of following the terms and conditions either of that version or of any later version published by the Free Software Foundation. If the Program does not specify a version number of this License, you may choose any version ever published by the Free Software Foundation.

10. If you wish to incorporate parts of the Program into other free programs whose distribution conditions are different, write to the author to ask for permission. For software which is copyrighted by the Free Software Foundation, write to the Free Software Foundation; we sometimes make exceptions for this. Our decision will be guided by the two goals of preserving the free status of all derivatives of our free software and of promoting the sharing and reuse of software generally.

NO WARRANTY

11. BECAUSE THE PROGRAM IS LICENSED FREE OF CHARGE, THERE IS NO WARRANTY FOR THE PROGRAM, TO THE EXTENT PERMITTED BY APPLICABLE LAW. EXCEPT WHEN OTHERWISE STATED IN WRITING THE COPYRIGHT HOLDERS AND/OR OTHER PARTIES PROVIDE THE PROGRAM "AS IS" WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESSED OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. THE ENTIRE RISK AS TO THE QUALITY AND PERFORMANCE OF THE PROGRAM IS WITH YOU. SHOULD THE PROGRAM PROVE DEFECTIVE, YOU ASSUME THE COST OF ALL NECESSARY SERVICING, REPAIR OR CORRECTION.

12. IN NO EVENT UNLESS REQUIRED BY APPLICABLE LAW OR AGREED TO IN WRITING WILL ANY COPYRIGHT HOLDER, OR ANY OTHER PARTY WHO MAY MODIFY AND/OR REDISTRIBUTE THE PROGRAM AS PERMITTED ABOVE, BE LIABLE TO YOU FOR DAMAGES, INCLUDING ANY GENERAL, SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES ARISING OUT OF THE USE OR INABILITY TO USE THE PROGRAM (INCLUDING BUT NOT LIMITED TO LOSS OF DATA OR DATA BEING RENDERED INACCURATE OR LOSSES SUSTAINED BY YOU OR THIRD PARTIES OR A FAILURE OF THE PROGRAM TO OPERATE WITH ANY OTHER PROGRAMS), EVEN IF SUCH HOLDER OR OTHER PARTY HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

END OF TERMS AND CONDITIONS

How to Apply These Terms to Your New Programs

If you develop a new program, and you want it to be of the greatest possible use to the public, the best way to achieve this is to make it free software which everyone can redistribute and change under these terms.

To do so, attach the following notices to the program. It is safest to attach them to the start of each source file to most effectively convey the exclusion of warranty; and each file should have at least the "copyright" line and a pointer to where the full notice is found.

```
one line to give the program's name and an idea of what it does.
Copyright (C) yyyy name of author
```

```
This program is free software; you can redistribute it and/or
modify it under the terms of the GNU General Public License
as published by the Free Software Foundation; either version 2
of the License, or (at your option) any later version.
```

This program is distributed in the hope that it will be useful, but WITHOUT ANY WARRANTY; without even the implied warranty of MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE. See the GNU General Public License for more details.

You should have received a copy of the GNU General Public License along with this program; if not, write to the Free Software Foundation, Inc., 51 Franklin Street, Fifth Floor, Boston, MA 02110-1301, USA.

Also add information on how to contact you by electronic and paper mail.

If the program is interactive, make it output a short notice like this when it starts in an interactive mode:

```
Gnomovision version 69, Copyright (C) year name of author
Gnomovision comes with ABSOLUTELY NO WARRANTY; for details
type `show w'. This is free software, and you are welcome
to redistribute it under certain conditions; type `show c'
for details.
```

The hypothetical commands `show w' and `show c' should show the appropriate parts of the General Public License. Of course, the commands you use may be called something other than `show w' and `show c'; they could even be mouse-clicks or menu items—whatever suits your program.

You should also get your employer (if you work as a programmer) or your school, if any, to sign a "copyright disclaimer" for the program, if necessary. Here is a sample; alter the names:

```
Yoyodyne, Inc., hereby disclaims all copyright
interest in the program `Gnomovision'
(which makes passes at compilers) written
by James Hacker.
```

```
signature of Ty Coon, 1 April 1989
Ty Coon, President of Vice
```

This General Public License does not permit incorporating your program into proprietary programs. If your program is a subroutine library, you may consider it more useful to permit linking proprietary applications with the library. If this is what you want to do, use the [GNU Lesser General Public License](#) instead of this License.

Chapter 7

GDS-Render Readme

This software is a rendering program for GDS2 layout files. The GDS2 format is mainly used in integrated circuit development. This program allows the conversion of a GDS file to a vector graphics file.

Output Formats

- Export GDS Layout to LaTeX (using TikZ).
- Export to PDF (Cairographics).

Features

Note: Due to various size limitations of both TikZ and the PDF export, the layout might not render correctly. In this case adjust the scale value. A higher scale value scales down your design.

- Configurable layer stack-up.
- Layer colors configurable as ARGB color values.
- Command line interface.
- *~~Awesome~~* Somehow usable GUI.

License and Other Stuff

- Free software (GPLv2 *only*)
- Coded in plain C using GTK+3.0, Glib2, and Cairographics

Chapter 8

Module Index

8.1 Modules

Here is a list of all modules:

Command Line Interface	30
Geometric Helper Functions	35
Graphical User Interface	49
LayerSelector Object	71
LibCellRenderer GObject	95
Custom GTK Widgets	103
RendererSettingsDialog	135
LayerElement	147
Output Renderers	102
Cairo Renderer	25
External Shared Object Renderer	33
LaTeX/TikZ Renderer	65
GDS-Utilities	104
Mapping-Parser	131
Version Number	134

Chapter 9

Data Structure Index

9.1 Data Structures

Here are the data structures with brief descriptions:

gds_cell_checks::_check_internals	
For the internal use of the checker	157
_GdsRenderGui	158
_LayerElement	160
_LayerElementPriv	161
_LayerSelector	163
_LibCellRenderer	164
_RendererSettingsDialog	165
bounding_box::_vectors	168
application_data	
Structure containing The GtkApplication and a list containing the GdsRenderGui objects	169
bounding_box	170
cairo_layer	
The cairo_layer struct Each rendered layer is represented by this struct	171
gds_cell	
A Cell inside a gds_library	173
gds_cell_array_instance	
Struct representing an array instantiation	175
gds_cell_checks	
Stores the result of the cell checks	178
gds_cell_instance	
This represents an instanc of a cell inside another cell	180
gds_graphics	
A GDS graphics object	182
gds_library	
GDS Toplevel library	184
gds_point	
A point in the 2D plane. Sometimes references as vertex	186
gds_time_field	
Date information for cells and libraries	186
layer_element_dnd_data	
This structure holds the necessary data to set up a LayerElement for Drag'n'Drop	188
layer_info	
Layer information	190
render_settings	
This struct holds the renderer configuration	191
tree_stores	193
vector_2d	194

Chapter 10

File Index

10.1 File List

Here is a list of all files with brief descriptions:

bounding-box.c	Calculation of bounding boxes	195
bounding-box.h	Header for calculation of bounding boxes	199
cairo-output.c	Output renderer for Cairo PDF export	201
cairo-output.h	Header File for Cairo output renderer	205
cell-geometrics.c	Calculation of gds_cell trigonometrics	207
cell-geometrics.h	Calculation of gds_cell geometrics	210
command-line.c	Function to render according to command line parameters	212
command-line.h	Render according to command line parameters	215
conv-settings-dialog.c	Implementation of the setting dialog	217
conv-settings-dialog.h	Header file for the Conversion Settings Dialog	223
external-renderer.c	This file implements the dynamic library loading for the external rendering feature	226
external-renderer.h	Render according to command line parameters	227
gds-parser.c	Implementation of the GDS-Parser	229
gds-parser.h	Header file for the GDS-Parser	244
gds-render-gui.c	Handling of GUI	245
gds-render-gui.h	Header for GdsRenderGui Object	253
gds-tree-checker.c	Checking functions of a cell tree	255
gds-tree-checker.h	Checking functions of a cell tree (Header)	258


gds-types.h	Defines types and macros used by the GDS-Parser	260
latex-output.c	LaTeX output renderer	267
latex-output.h	LaTeX output renderer	271
layer-element.c	Implementation of the layer element used for configuring layer colors etc	273
layer-element.h	Implementation of the layer element used for configuring layer colors etc	276
layer-info.c	Helper functions for layer info struct	279
layer-info.h	Helper functions and definition of layer info struct	281
layer-selector.c	Implementation of the layer selector	284
layer-selector.h	Implementation of the Layer selection list	294
lib-cell-renderer.c	LibCellRenderer GObject Class	297
lib-cell-renderer.h	Header file for the LibCellRenderer GObject Class	300
main.c	Main.c	302
mapping-parser.c	Function to read a mapping file line and parse it	312
mapping-parser.h	Function to read a mapping file line and parse it	315
README.MD	317
tree-store.c	317
tree-store.h	Header file for Tree store implementation	320
vector-operations.c	2D Vector operations	322
vector-operations.h	Header for 2D Vector operations	325
version.c	328
version.h	328

Chapter 11

Module Documentation

11.1 Cairo Renderer

Collaboration diagram for Cairo Renderer:



Data Structures

- struct [cairo_layer](#)
The [cairo_layer](#) struct Each rendered layer is represented by this struct.

Macros

- #define [MAX_LAYERS](#) (300)
Maximum layer count the output renderer can process. Typically GDS only specifies up to 255 layers.

Functions

- static void [revert_inherited_transform](#) (struct [cairo_layer](#) *layers)
Revert the last transformation on all layers.
- static void [apply_inherited_transform_to_all_layers](#) (struct [cairo_layer](#) *layers, const struct [gds_point](#) *origin, double magnification, gboolean flipping, double rotation, double scale)
Applies transformation to all layers.
- static void [render_cell](#) (struct [gds_cell](#) *cell, struct [cairo_layer](#) *layers, double scale)
render_cell Render a cell with its sub-cells
- void [cairo_render_cell_to_vector_file](#) (struct [gds_cell](#) *cell, GList *layer_infos, char *pdf_file, char *svg_file, double scale)
Render cell to a PDF file specified by pdf_file.

11.1.1 Detailed Description

11.1.2 Macro Definition Documentation

11.1.2.1 MAX_LAYERS

```
#define MAX_LAYERS (300)
```

Maximum layer count the output renderer can process. Typically GDS only specifies up to 255 layers.

Definition at line [34](#) of file [cairo-output.h](#).

11.1.3 Function Documentation

11.1.3.1 apply_inherited_transform_to_all_layers()

```
static void apply_inherited_transform_to_all_layers (
    struct cairo\_layer * layers,
    const struct gds\_point * origin,
    double magnification,
    gboolean flipping,
    double rotation,
    double scale ) [static]
```


Applies transformation to all layers.

Parameters

<i>layers</i>	Array of layers
<i>origin</i>	Origin translation
<i>magnification</i>	Scaling
<i>flipping</i>	Mirror image on x-axis before rotating
<i>rotation</i>	Rotation in degrees
<i>scale</i>	Scale the image down by. Only used for scaling origin coordinates. Not applied to layer.

Definition at line [71](#) of file [cairo-output.c](#).

Here is the caller graph for this function:



11.1.3.2 cairo_render_cell_to_vector_file()

```

void cairo_render_cell_to_vector_file (
    struct gds_cell * cell,
    GList * layer_infos,
    char * pdf_file,
    char * svg_file,
    double scale )
  
```


Render `cell` to a PDF file specified by `pdf_file`.

Parameters


<i>cell</i>	Toplevel cell to Cairo Renderer
<i>layer_infos</i>	List of layer information. Specifies color and layer stacking
<i>pdf_file</i>	PDF output file. Set to NULL if no PDF file has to be generated
<i>svg_file</i>	SVG output file. Set to NULL if no SVG file has to be generated
<i>scale</i>	Scale the output image down by <i>scale</i>

Definition at line [182](#) of file [cairo-output.c](#).

Here is the call graph for this function:



Here is the caller graph for this function:



11.1.3.3 render_cell()

```

static void render_cell (
    struct gds_cell * cell,
    struct cairo_layer * layers,
    double scale ) [static]
  
```


`render_cell` Render a cell with its sub-cells

Parameters


<i>cell</i>	Cell to render
<i>layers</i>	Cell will be rendered into these layers
<i>scale</i>	scale image down by this factor

Definition at line 101 of file [cairo-output.c](#).

Here is the call graph for this function:



Here is the caller graph for this function:



11.1.3.4 revert_inherited_transform()

```
static void revert_inherited_transform (
    struct cairo\_layer * layers ) [static]
```


Revert the last transformation on all layers.

Parameters

<code>layers</code>	Pointer to cairo_layer structures
---------------------	---------------------------------------------------

Definition at line 51 of file [cairo-output.c](#).

Here is the caller graph for this function:



11.2 Command Line Interface

Functions

- static void `delete_layer_info_with_name` (struct `layer_info` *info)
Delete `layer_info` and free nem element.
- void `command_line_convert_gds` (char *gds_name, char *pdf_name, char *tex_name, gboolean pdf, gboolean tex, char *layer_file, char *cell_name, double scale, gboolean pdf_layers, gboolean pdf_↔standalone, gboolean svg, char *svg_name, char *so_name, char *so_out_file)
Convert GDS according to supplied parameters.

11.2.1 Detailed Description

11.2.2 Function Documentation

11.2.2.1 `command_line_convert_gds()`

```
void command_line_convert_gds (
    char * gds_name,
    char * pdf_name,
    char * tex_name,
    gboolean pdf,
    gboolean tex,
    char * layer_file,
    char * cell_name,
    double scale,
    gboolean pdf_layers,
    gboolean pdf_standalone,
    gboolean svg,
    char * svg_name,
    char * so_name,
    char * so_out_file )
```

Convert GDS according to supplied parameters.

Parameters


<code>gds_name</code>	GDS File path
<code>pdf_name</code>	Cairo-PDF path
<code>tex_name</code>	TeX/TikZ path
<code>pdf</code>	Render Cairo
<code>tex</code>	Render LaTeX
<code>layer_file</code>	Layer mapping file
<code>cell_name</code>	Cell name to render
<code>scale</code>	Scale image down by this value
<code>pdf_layers</code>	TikZ creates OCG layers
<code>pdf_standalone</code>	LaTeX document is standalone?
<code>svg</code>	Render to SVG file
<code>so_name</code>	Path to shared object of custom renderrer
<code>so_out_file</code>	Output file path for custom renderrer
<code>svg_name</code>	SVG file name

Note


This function is pretty damn retarded (Lots of parameters). Will be reworked when generating GObjects for renderers.

Definition at line 58 of file [command-line.c](#).

Here is the call graph for this function:



Here is the caller graph for this function:



11.2.2.2 delete_layer_info_with_name()

```
static void delete_layer_info_with_name (  
    struct layer_info * info ) [static]
```

Delete [layer_info](#) and free nem element.

Like [delete_layer_info_struct\(\)](#) but also frees [layer_info::name](#)

Parameters


<i>info</i>	
-------------	--

Warning

This function must not be used if the [layer_info::name](#) field references the internal storage strings if e.g. an entry field


Definition at line [49](#) of file [command-line.c](#).

Here is the caller graph for this function:



11.3 External Shared Object Renderer

Collaboration diagram for External Shared Object Renderer:



Macros

- `#define EXTERNAL_LIBRARY_FUNCTION "render_cell_to_file"`
function name expected to be found in external library.

Functions

- `int external_renderer_render_cell (struct gds_cell *toplevel_cell, GList *layer_info_list, char *output_file, char *so_path)`
external_renderer_render_cell

11.3.1 Detailed Description

11.3.2 Macro Definition Documentation

11.3.2.1 EXTERNAL_LIBRARY_FUNCTION

```
#define EXTERNAL_LIBRARY_FUNCTION "render_cell_to_file"
```

function name expected to be found in external library.

The function has to be defined as follows:

```
int function_name(gds_cell *toplevel, GList *layer_info_list, char *output_file_name)
```

Definition at line 45 of file [external-renderer.h](#).

11.3.3 Function Documentation

11.3.3.1 external_renderer_render_cell()

```
int external_renderer_render_cell (
    struct gds_cell * toplevel_cell,
    GList * layer_info_list,
    char * output_file,
    char * so_path )
```

`external_renderer_render_cell`

Parameters


<i>toplevel_cell</i>	The toplevel cell to render
<i>layer_info_list</i>	The layer information. Contains layer_info elements
<i>output_file</i>	Output file
<i>so_path</i>	Path to the shared object file containing EXTERNAL_LIBRARY_FUNCTION

Returns

0 on success

Definition at line 36 of file [external-renderer.c](#).

Here is the caller graph for this function:



11.4 Geometric Helper Functions

Data Structures

- union [bounding_box](#)
- struct [vector_2d](#)

Macros

- #define [MIN](#)(a, b) (((a) < (b)) ? (a) : (b))
Return smaller number.
- #define [MAX](#)(a, b) (((a) > (b)) ? (a) : (b))
Return bigger number.
- #define [ABS_DBL](#)(a) ((a) < 0 ? -(a) : (a))
- #define [ABS_DBL](#)(a) ((a) < 0 ? -(a) : (a))
- #define [DEG2RAD](#)(a) ((a)*M_PI/180.0)

Typedefs

- typedef void(* [conv_generic_to_vector_2d_t](#)) (void *, struct [vector_2d](#) *)

Functions

- void [bounding_box_calculate_polygon](#) (GList *vertices, [conv_generic_to_vector_2d_t](#) conv_func, union [bounding_box](#) *box)
- void [bounding_box_update_box](#) (union [bounding_box](#) *destination, union [bounding_box](#) *update)
- void [bounding_box_prepare_empty](#) (union [bounding_box](#) *box)
- static void [calculate_path_miter_points](#) (struct [vector_2d](#) *a, struct [vector_2d](#) *b, struct [vector_2d](#) *c, struct [vector_2d](#) *m1, struct [vector_2d](#) *m2, double width)
- void [bounding_box_calculate_path_box](#) (GList *vertices, double thickness, [conv_generic_to_vector_2d_t](#) conv_func, union [bounding_box](#) *box)
- void [bounding_box_update_point](#) (union [bounding_box](#) *destination, [conv_generic_to_vector_2d_t](#) conv_↔ func, void *pt)
- void [bounding_box_apply_transform](#) (double scale, double rotation_deg, bool flip_at_x, union [bounding_box](#) *box)
Apply transformations onto bounding box.
- static void [convert_gds_point_to_2d_vector](#) (struct [gds_point](#) *pt, struct [vector_2d](#) *vector)
- static void [update_box_with_gfx](#) (union [bounding_box](#) *box, struct [gds_graphics](#) *gfx)
Update the given bounding box with the bounding box of a graphics element.
- void [calculate_cell_bounding_box](#) (union [bounding_box](#) *box, struct [gds_cell](#) *cell)
calculate_cell_bounding_box Calculate bounding box of gds cell
- double [vector_2d_scalar_multiply](#) (struct [vector_2d](#) *a, struct [vector_2d](#) *b)
- void [vector_2d_normalize](#) (struct [vector_2d](#) *vec)
- void [vector_2d_rotate](#) (struct [vector_2d](#) *vec, double angle)
- struct [vector_2d](#) * [vector_2d_copy](#) (struct [vector_2d](#) *opt_res, struct [vector_2d](#) *vec)
- struct [vector_2d](#) * [vector_2d_alloc](#) (void)
- void [vector_2d_free](#) (struct [vector_2d](#) *vec)
- void [vector_2d_scale](#) (struct [vector_2d](#) *vec, double scale)
- double [vector_2d_abs](#) (struct [vector_2d](#) *vec)
- double [vector_2d_calculate_angle_between](#) (struct [vector_2d](#) *a, struct [vector_2d](#) *b)
- void [vector_2d_subtract](#) (struct [vector_2d](#) *res, struct [vector_2d](#) *a, struct [vector_2d](#) *b)
- void [vector_2d_add](#) (struct [vector_2d](#) *res, struct [vector_2d](#) *a, struct [vector_2d](#) *b)

11.4.1 Detailed Description

The geometric helper function are used to calculate bounding boxes

Warning

Code is incomplete. Please double check for functionality!

11.4.2 Macro Definition Documentation

11.4.2.1 ABS_DBL [1/2]

```
#define ABS_DBL(  
    a ) ((a) < 0 ? -(a) : (a))
```

Definition at line 36 of file [vector-operations.c](#).

11.4.2.2 ABS_DBL [2/2]

```
#define ABS_DBL(  
    a ) ((a) < 0 ? -(a) : (a))
```

Definition at line 38 of file [bounding-box.c](#).

11.4.2.3 DEG2RAD

```
#define DEG2RAD(  
    a ) ((a)*M_PI/180.0)
```

Definition at line 42 of file [vector-operations.h](#).

11.4.2.4 MAX

```
#define MAX(  
    a,  
    b ) (((a) > (b)) ? (a) : (b))
```

Return bigger number.

Definition at line 37 of file [bounding-box.c](#).

11.4.2.5 MIN

```
#define MIN(  
    a,  
    b ) ((a) < (b)) ? (a) : (b))
```

Return smaller number.

Definition at line 36 of file [bounding-box.c](#).

11.4.3 Typedef Documentation

11.4.3.1 conv_generic_to_vector_2d_t

```
typedef void(* conv_generic_to_vector_2d_t) (void *, struct vector\_2d *)
```

Definition at line 47 of file [bounding-box.h](#).

11.4.4 Function Documentation

11.4.4.1 bounding_box_apply_transform()

```
void bounding_box_apply_transform (  
    double scale,  
    double rotation_deg,  
    bool flip_at_x,  
    union bounding\_box * box )
```


Apply transformations onto bounding box.

Parameters


<i>scale</i>	Scaling factor
<i>rotation_deg</i>	Roation of bounding box around the origin in degrees (counterclockwise)
<i>flip_at_x</i>	Flip the boundig box on the x axis before rotating.
<i>box</i>	Bounding box the operations should be applied to.

Definition at line 190 of file [bounding-box.c](#).

Here is the call graph for this function:



Here is the caller graph for this function:




11.4.4.2 bounding_box_calculate_path_box()

```

void bounding_box_calculate_path_box (
    GList * vertices,
    double thickness,
    conv_generic_to_vector_2d_t conv_func,
    union bounding_box * box )
  
```

Definition at line 137 of file [bounding-box.c](#).

Here is the call graph for this function:



Here is the caller graph for this function:




11.4.4.3 `bounding_box_calculate_polygon()`

```
void bounding_box_calculate_polygon (
    GList * vertices,
    conv_generic_to_vector_2d_t conv_func,
    union bounding_box * box )
```

Definition at line 40 of file [bounding-box.c](#).

Here is the call graph for this function:



Here is the caller graph for this function:

11.4.4.4 `bounding_box_prepare_empty()`

```
void bounding_box_prepare_empty (
    union bounding_box * box )
```

Definition at line 86 of file [bounding-box.c](#).

Here is the caller graph for this function:



11.4.4.5 bounding_box_update_box()

```
void bounding_box_update_box (
    union bounding_box * destination,
    union bounding_box * update )
```

Definition at line 71 of file [bounding-box.c](#).

Here is the caller graph for this function:




11.4.4.6 bounding_box_update_point()

```
void bounding_box_update_point (
    union bounding_box * destination,
    conv_generic_to_vector_2d_t conv_func,
    void * pt )
```

Definition at line 165 of file [bounding-box.c](#).

Here is the call graph for this function:



11.4.4.7 calculate_cell_bounding_box()

```
void calculate_cell_bounding_box (
    union bounding_box * box,
    struct gds_cell * cell )
```

`calculate_cell_bounding_box` Calculate bounding box of gds cell

Parameters


<i>box</i>	Resulting bounding box. Will be updated and not overwritten
<i>cell</i>	Toplevel cell

Warning

Path handling not yet implemented correctly.

Definition at line 80 of file [cell-geometrics.c](#).

Here is the call graph for this function:



Here is the caller graph for this function:


**11.4.4.8 calculate_path_miter_points()**

```

static void calculate_path_miter_points (
    struct vector_2d * a,
    struct vector_2d * b,
    struct vector_2d * c,
    struct vector_2d * m1,
    struct vector_2d * m2,
    double width ) [static]
  
```

Definition at line 94 of file [bounding-box.c](#).

Here is the call graph for this function:



11.4.4.9 convert_gds_point_to_2d_vector()

```

static void convert_gds_point_to_2d_vector (
    struct gds_point * pt,
    struct vector_2d * vector ) [static]
  
```

Definition at line 35 of file [cell-geometrics.c](#).

Here is the caller graph for this function:



11.4.4.10 update_box_with_gfx()

```

static void update_box_with_gfx (
    union bounding_box * box,
    struct gds_graphics * gfx ) [static]
  
```


Update the given bounding box with the bounding box of a graphics element.

Parameters

<i>box</i>	box to update
<i>gfx</i>	Graphics element

Definition at line 46 of file [cell-geometrics.c](#).

Here is the call graph for this function:



Here is the caller graph for this function:




11.4.4.11 vector_2d_abs()

```
double vector_2d_abs (
    struct vector_2d * vec )
```

Definition at line 114 of file [vector-operations.c](#).

Here is the caller graph for this function:




11.4.4.12 `vector_2d_add()`

```
void vector_2d_add (
    struct vector_2d * res,
    struct vector_2d * a,
    struct vector_2d * b )
```

Definition at line 142 of file [vector-operations.c](#).


Here is the caller graph for this function:

11.4.4.13 `vector_2d_alloc()`

```
struct vector_2d * vector_2d_alloc (
    void )
```

Definition at line 93 of file [vector-operations.c](#).

Here is the caller graph for this function:




11.4.4.14 `vector_2d_calculate_angle_between()`

```
double vector_2d_calculate_angle_between (
    struct vector_2d * a,
    struct vector_2d * b )
```

Definition at line 123 of file [vector-operations.c](#).

Here is the call graph for this function:



Here is the caller graph for this function:

11.4.4.15 `vector_2d_copy()`


```
struct vector_2d * vector_2d_copy (
    struct vector_2d * opt_res,
    struct vector_2d * vec )
```

Definition at line 74 of file [vector-operations.c](#).

Here is the call graph for this function:



Here is the caller graph for this function:



11.4.4.16 vector_2d_free()

```
void vector_2d_free (
    struct vector_2d * vec )
```


Definition at line 98 of file [vector-operations.c](#).

11.4.4.17 vector_2d_normalize()

```
void vector_2d_normalize (
    struct vector_2d * vec )
```

Definition at line 46 of file [vector-operations.c](#).

Here is the caller graph for this function:




11.4.4.18 `vector_2d_rotate()`


```
void vector_2d_rotate (
    struct vector_2d * vec,
    double angle )
```

Definition at line 56 of file [vector-operations.c](#).

Here is the call graph for this function:




Here is the caller graph for this function:

11.4.4.19 `vector_2d_scalar_multiply()`

```
double vector_2d_scalar_multiply (
    struct vector_2d * a,
    struct vector_2d * b )
```

Definition at line 38 of file [vector-operations.c](#).

Here is the caller graph for this function:




11.4.4.20 `vector_2d_scale()`

```
void vector_2d_scale (
    struct vector_2d * vec,
    double scale )
```

Definition at line 105 of file `vector-operations.c`.

Here is the caller graph for this function:

11.4.4.21 `vector_2d_subtract()`

```
void vector_2d_subtract (
    struct vector_2d * res,
    struct vector_2d * a,
    struct vector_2d * b )
```


Definition at line 134 of file `vector-operations.c`.

Here is the caller graph for this function:



11.5 Graphical User Interface

Collaboration diagram for Graphical User Interface:



Modules

- [LayerSelector Object](#)
- [LibCellRenderer GObject](#)
- [Custom GTK Widgets](#)

Data Structures

- [struct _GdsRenderGui](#)
- [struct tree_stores](#)

Macros

- `#define RENDERER_TYPE_GUI (gds_render_gui_get_type())`

Enumerations

- `enum gds_render_gui_signal_sig_ids { SIGNAL_WINDOW_CLOSED = 0, SIGNAL_COUNT }`
- `enum cell_store_columns { CELL_SEL_LIBRARY = 0, CELL_SEL_CELL, CELL_SEL_CELL_ERROR_STATE, CELL_SEL_MODDATE, CELL_SEL_ACCESSDATE, CELL_SEL_COLUMN_COUNT }`

Columns of selection tree view.

Functions

- static gboolean [on_window_close](#) (gpointer window, GdkEvent *event, gpointer user)
Main window close event.
- static GString * [generate_string_from_date](#) (struct [gds_time_field](#) *date)
generate string from [gds_time_field](#)
- static void [on_load_gds](#) (gpointer button, gpointer user)
Callback function of Load GDS button.
- static void [on_convert_clicked](#) (gpointer button, gpointer user)
Convert button callback.
- static void [cell_tree_view_activated](#) (gpointer tree_view, GtkTreePath *path, GtkTreeViewColumn *column, gpointer user)
cell_tree_view_activated Callback for 'double click' on cell selector element
- static void [cell_selection_changed](#) (GtkTreeSelection *sel, GdsRenderGui *self)
Callback for cell-selection change event.
- static void [sort_up_callback](#) (GtkWidget *widget, gpointer user)
- static void [sort_down_callback](#) (GtkWidget *widget, gpointer user)
- static void [gds_render_gui_dispose](#) (GObject *gobject)
- static void [gds_render_gui_class_init](#) (GdsRenderGuiClass *klass)
- GtkWidget * [gds_render_gui_get_main_window](#) (GdsRenderGui *gui)
Get main window.
- static void [gds_render_gui_init](#) (GdsRenderGui *self)
- GdsRenderGui * [gds_render_gui_new](#) ()
Create new GdsRenderGui Object.
- G_BEGIN_DECLS [G_DECLARE_FINAL_TYPE](#) (GdsRenderGui, gds_render_gui, RENDERER, GUI, GObject)
- struct [tree_stores](#) * [setup_cell_selector](#) (GtkTreeView *view, GtkEntry *search_entry)
Setup a GtkTreeView with the necessary columns.
- static gboolean [tree_sel_func](#) (GtkTreeSelection *selection, GtkTreeModel *model, GtkTreePath *path, gboolean path_currently_selected, gpointer data)
this function only allows cells to be selected
- static gboolean [cell_store_filter_visible_func](#) (GtkTreeModel *model, GtkTreeIter *iter, gpointer data)
cell_store_filter_visible_func Decides whether an element of the tree model `model` is visible.
- static void [change_filter](#) (GtkWidget *entry, gpointer data)

Variables

- static guint [gds_render_gui_signals](#) [SIGNAL_COUNT]

11.5.1 Detailed Description

11.5.2 Macro Definition Documentation

11.5.2.1 RENDERER_TYPE_GUI

```
#define RENDERER_TYPE_GUI (gds_render_gui_get_type())
```

Definition at line 40 of file [gds-render-gui.h](#).

11.5.3 Enumeration Type Documentation

11.5.3.1 `cell_store_columns`

enum `cell_store_columns`

Columns of selection tree view.

Enumerator

CELL_SEL_LIBRARY	
CELL_SEL_CELL	
CELL_SEL_CELL_ERROR_STATE	Used for cell color and selectability
CELL_SEL_MODDATE	
CELL_SEL_ACCESSDATE	
CELL_SEL_COLUMN_COUNT	Not a column. Used to determine count of columns.

Definition at line 37 of file `tree-store.h`.

11.5.3.2 `gds_render_gui_signal_sig_ids`

enum `gds_render_gui_signal_sig_ids`

Enumerator

SIGNAL_WINDOW_CLOSED	
SIGNAL_COUNT	

Definition at line 45 of file `gds-render-gui.c`.

11.5.4 Function Documentation

11.5.4.1 `cell_selection_changed()`

```
static void cell_selection_changed (
    GtkTreeSelection * sel,
    GdsRenderGui * self ) [static]
```

Callback for cell-selection change event.

This function activates/deactivates the convert button depending on whether a cell is selected for conversion or not

Parameters

<i>sel</i>	
<i>self</i>	

Definition at line 397 of file [gds-render-gui.c](#).

Here is the caller graph for this function:

11.5.4.2 `cell_store_filter_visible_func()`

```

static gboolean cell_store_filter_visible_func (
    GtkTreeModel * model,
    GtkTreeIter * iter,
    gpointer data ) [static]
  
```

`cell_store_filter_visible_func` Decides whether an element of the tree model `model` is visible.

Parameters

<i>model</i>	Tree model
<i>iter</i>	Current element / iter in Model to check
<i>data</i>	Data. Set to static stores variable

Returns


TRUE if visible, else FALSE

Note

TODO: Maybe implement Damerau-Levenshtein distance matching

Definition at line 79 of file [tree-store.c](#).

Here is the caller graph for this function:



11.5.4.3 cell_tree_view_activated()

```
static void cell_tree_view_activated (
    gpointer tree_view,
    GtkTreePath * path,
    GtkTreeViewColumn * column,
    gpointer user ) [static]
```


cell_tree_view_activated Callback for 'double click' on cell selector element

Parameters

<i>tree_view</i>	The tree view the event occurred in
<i>path</i>	path to the selected row
<i>column</i>	The clicked column
<i>user</i>	pointer to GdsRenderGui object

Definition at line 378 of file [gds-render-gui.c](#).

Here is the call graph for this function:



Here is the caller graph for this function:




11.5.4.4 `change_filter()`

```
static void change_filter (  
    GtkWidget * entry,  
    gpointer data ) [static]
```

Definition at line 115 of file [tree-store.c](#).

Here is the caller graph for this function:



11.5.4.5 `G_DECLARE_FINAL_TYPE()`

```
G_BEGIN_DECLS G_DECLARE_FINAL_TYPE (  
    GdsRenderGui ,  
    gds_render_gui ,  
    RENDERER ,  
    GUI ,  
    GObject )
```

11.5.4.6 `gds_render_gui_class_init()`

```
static void gds_render_gui_class_init (
    GdsRenderGuiClass * klass ) [static]
```

Definition at line 456 of file [gds-render-gui.c](#).


Here is the call graph for this function:

11.5.4.7 `gds_render_gui_dispose()`

```
static void gds_render_gui_dispose (
    GObject * gobject ) [static]
```

Definition at line 432 of file [gds-render-gui.c](#).

Here is the call graph for this function:



Here is the caller graph for this function:



11.5.4.8 gds_render_gui_get_main_window()

```
GtkWindow * gds_render_gui_get_main_window (
    GdsRenderGui * gui )
```

Get main window.


This function returns the main window of the GUI, which can later be displayed. All handling of the GUI is taken care of inside the GdsRenderGui Object

Returns

The generated main window

Definition at line [474](#) of file [gds-render-gui.c](#).

Here is the caller graph for this function:




11.5.4.9 gds_render_gui_init()

```
static void gds_render_gui_init (
    GdsRenderGui * self ) [static]
```

Definition at line [479](#) of file [gds-render-gui.c](#).

Here is the call graph for this function:



11.5.4.10 gds_render_gui_new()

```
GdsRenderGui * gds_render_gui_new ( )
```


Create new GdsRenderGui Object.

Returns

New object

Definition at line 554 of file [gds-render-gui.c](#).

Here is the caller graph for this function:



11.5.4.11 generate_string_from_date()

```

static GString* generate_string_from_date (
    struct gds\_time\_field * date ) [static]
  
```

generate string from [gds_time_field](#)

Parameters


<i>date</i>	Date to convert
-------------	-----------------

Returns

String with date

Definition at line 99 of file [gds-render-gui.c](#).

Here is the caller graph for this function:



11.5.4.12 on_convert_clicked()

```

static void on_convert_clicked (
    gpointer button,
    gpointer user ) [static]
  
```


Convert button callback.

Parameters


<i>button</i>	
<i>user</i>	

Definition at line 245 of file `gds-render-gui.c`.

Here is the call graph for this function:



Here is the caller graph for this function:



11.5.4.13 on_load_gds()

```

static void on_load_gds (
    gpointer button,
    gpointer user ) [static]
    
```


Callback function of Load GDS button.

Parameters

<i>button</i>	
<i>user</i>	GdsRenderGui instance

Definition at line 118 of file `gds-render-gui.c`.

Here is the call graph for this function:



Here is the caller graph for this function:



11.5.4.14 `on_window_close()`

```
static gboolean on_window_close (
    gpointer window,
    GdkEvent * event,
    gpointer user ) [static]
```

Main window close event.

Parameters


<i>window</i>	GtkWindow which is closed
<i>event</i>	unused event
<i>user</i>	GdsRenderGui instance

Returns

Status of the event handling. Always true.

Definition at line 73 of file [gds-render-gui.c](#).

Here is the call graph for this function:



Here is the caller graph for this function:

11.5.4.15 `setup_cell_selector()`

```
struct tree_stores * setup_cell_selector (
    GtkTreeView * view,
    GtkEntry * search_entry )
```

Setup a GtkTreeView with the necessary columns.

Parameters


<i>view</i>	Tree view to set up
<i>search_entry</i>	Entry field for search

Returns

Tree stores for storing data inside the GtkTreeView

Definition at line 129 of file [tree-store.c](#).

Here is the call graph for this function:



Here is the caller graph for this function:

11.5.4.16 `sort_down_callback()`

```

static void sort_down_callback (
    GtkWidget * widget,
    gpointer user ) [static]
  
```

Definition at line 421 of file [gds-render-gui.c](#).

Here is the call graph for this function:



Here is the caller graph for this function:



11.5.4.17 `sort_up_callback()`

```
static void sort_up_callback (
    GtkWidget * widget,
    gpointer user ) [static]
```

Definition at line 410 of file [gds-render-gui.c](#).

Here is the call graph for this function:



Here is the caller graph for this function:



11.5.4.18 tree_sel_func()

```
static gboolean tree_sel_func (
    GtkTreeSelection * selection,
    GtkTreeModel * model,
    GtkTreePath * path,
    gboolean path_currently_selected,
    gpointer data ) [static]
```

this function only allows cells to be selected

Parameters


<i>selection</i>	
<i>model</i>	
<i>path</i>	
<i>path_currently_selected</i>	
<i>data</i>	

Returns

TRUE if element is selectable, FALSE if not

Definition at line 44 of file [tree-store.c](#).

Here is the caller graph for this function:



11.5.5 Variable Documentation


11.5.5.1 gds_render_gui_signals

```
guint gds_render_gui_signals[SIGNAL_COUNT] [static]
```

Definition at line 47 of file [gds-render-gui.c](#).

11.6 LaTeX/TikZ Renderer

Collaboration diagram for LaTeX/TikZ Renderer:



Macros

- `#define LATEX_LINE_BUFFER_KB (10)`
Buffer for LaTeX Code line in KiB.
- `#define WRITEOUT_BUFFER(buff) fwrite((buff)->str, sizeof(char), (buff)->len, tex_file)`
*Writes a GString *buffer* to the fixed file *tex_file*.*

Functions

- void `latex_render_cell_to_code` (struct `gds_cell` *cell, GList *layer_infos, FILE *tex_file, double scale, gboolean create_pdf_layers, gboolean standalone_document)
*Render *cell* to LaTeX/TikZ code.*
- static void `write_layer_definitions` (FILE *tex_file, GList *layer_infos, GString *buffer)
Write the layer declarration to TeX file.
- static gboolean `write_layer_env` (FILE *tex_file, GdkRGBA *color, int layer, GList *linfo, GString *buffer)
Write layer Environment.
- static void `generate_graphics` (FILE *tex_file, GList *graphics, GList *linfo, GString *buffer, double scale)
Writes a graphics object to the specified tex_file.
- static void `render_cell` (struct `gds_cell` *cell, GList *layer_infos, FILE *tex_file, GString *buffer, double scale)
Render cell to file.

11.6.1 Detailed Description

11.6.2 Macro Definition Documentation

11.6.2.1 LATEX_LINE_BUFFER_KB

```
#define LATEX_LINE_BUFFER_KB (10)
```

Buffer for LaTeX Code line in KiB.

Definition at line 40 of file [latex-output.h](#).

11.6.2.2 WRITEOUT_BUFFER

```
#define WRITEOUT_BUFFER(  
    buff ) fwrite((buff)->str, sizeof(char), (buff)->len, tex_file)
```

Writes a GString `buffer` to the fixed file `tex_file`.

Definition at line [36](#) of file [latex-output.c](#).

11.6.3 Function Documentation

11.6.3.1 generate_graphics()

```
static void generate_graphics (  
    FILE * tex_file,  
    GList * graphics,  
    GList * linfo,  
    GString * buffer,  
    double scale ) [static]
```

Writes a graphics object to the specified `tex_file`.

This function opens the layer, writes a graphics object and closes the layer

Parameters


<i>tex_file</i>	File to write to
<i>graphics</i>	Object to render
<i>linfo</i>	Layer information
<i>buffer</i>	Working buffer
<i>scale</i>	Scale abject down by this value

Definition at line [138](#) of file [latex-output.c](#).

Here is the call graph for this function:



Here is the caller graph for this function:



11.6.3.2 latex_render_cell_to_code()

```

void latex_render_cell_to_code (
    struct gds_cell * cell,
    GList * layer_infos,
    FILE * tex_file,
    double scale,
    gboolean create_pdf_layers,
    gboolean standalone_document )
    
```


Render `cell` to LateX/TikZ code.

Parameters


<i>cell</i>	Cell to render
<i>layer_infos</i>	Layer information
<i>tex_file</i>	Already opened file to write data in
<i>scale</i>	Scale image down by this value
<i>create_pdf_layers</i>	Optional content groups used
<i>standalone_document</i>	document can be compiled standalone

Definition at line 252 of file [latex-output.c](#).

Here is the call graph for this function:



Here is the caller graph for this function:



11.6.3.3 render_cell()

```
static void render_cell (
    struct gds_cell * cell,
    GList * layer_infos,
    FILE * tex_file,
    GString * buffer,
    double scale ) [static]
```


Render cell to file.

Parameters


<i>cell</i>	Cell to render
<i>layer_infos</i>	Layer information
<i>tex_file</i>	File to write to
<i>buffer</i>	Working buffer
<i>scale</i>	Scale output down by this value

Definition at line 209 of file [latex-output.c](#).

Here is the call graph for this function:



Here is the caller graph for this function:



11.6.3.4 write_layer_definitions()

```
static void write_layer_definitions (
    FILE * tex_file,
```

```
GList * layer_infos,
GString * buffer ) [static]
```

Write the layer declaration to TeX file.

This writes the declaration of the layers and the mapping in which order the layers shall be rendered by TikZ. Layers are written in the order they are positioned inside the `layer_infos` list.

Parameters


<code>tex_file</code>	TeX-File to write to
<code>layer_infos</code>	List containing <code>layer_info</code> structs.
<code>buffer</code>	

Note

The field `layer_info::stacked_position` is ignored. Stack depends on list order.

Definition at line 50 of file `latex-output.c`.

Here is the caller graph for this function:



11.6.3.5 write_layer_env()

```
static gboolean write_layer_env (
    FILE * tex_file,
    GdkRGBA * color,
    int layer,
    GList * linfo,
    GString * buffer ) [static]
```

Write layer Environment.

If the requested layer shall be rendered, this code writes the necessary code to open the layer. It also returns the color the layer shall be rendered in.

The following environments are generated:

```
\begin{pgfonlayer}{<layer>}
% If pdf layers shall be used also this is enabled:
\begin{scope}[ocg={ref=<layer>, status=visible,name={<Layer Name>}}]
```

If the layer shall not be rendered, `FALSE` is returned and the color is not filled in and the code is not written to the file.

Parameters

<i>tex_file</i>	TeX file to write to
<i>color</i>	Return of the layer's color
<i>layer</i>	Requested layer number
<i>linfo</i>	Layer information list containing layer_info structs
<i>buffer</i>	Some working buffer

Returns


TRUE, if the layer shall be rendered.

Note

The opened environments have to be closed afterwards


Definition at line 106 of file [latex-output.c](#).

Here is the caller graph for this function:



11.7 LayerSelector Object

Collaboration diagram for LayerSelector Object:



Data Structures

- struct [_LayerSelector](#)

Macros

- #define [TYPE_LAYER_SELECTOR](#) ([layer_selector_get_type\(\)](#))

Enumerations

- enum [layer_selector_sort_algo](#) { [LAYER_SELECTOR_SORT_DOWN](#) = 0, [LAYER_SELECTOR_SORT_UP](#) }

Defines how to sort the layer selector list box.

Functions

- G_BEGIN_DECLS [G_DECLARE_FINAL_TYPE](#) (LayerSelector, layer_selector, [LAYER_SELECTOR](#), G↳ Object)
- LayerSelector * [layer_selector_new](#) (GtkListBox *list_box)
layer_selector_new
- void [layer_selector_generate_layer_widgets](#) (LayerSelector *selector, GList *libs)
Generate layer widgets in in the LayerSelector instance.
- void [layer_selector_set_load_mapping_button](#) (LayerSelector *selector, GtkWidget *button, GtkWidget *main_window)
Supply button for loading the layer mapping.
- void [layer_selector_set_save_mapping_button](#) (LayerSelector *selector, GtkWidget *button, GtkWidget *main_window)
Supply button for saving the layer mapping.
- GList * [layer_selector_export_rendered_layer_info](#) (LayerSelector *selector)
Get a list of all layers that shall be exported when rendering the cells.
- void [layer_selector_force_sort](#) (LayerSelector *selector, enum [layer_selector_sort_algo](#) sort_function)
*Force the layer selector list to be sorted according to *sort_function*.*
- static void [sel_layer_element_drag_begin](#) (GtkWidget *widget, GdkDragContext *context, gpointer data)
- static void [sel_layer_element_drag_end](#) (GtkWidget *widget, GdkDragContext *context, gpointer data)

- static void [sel_layer_element_drag_data_get](#) (GtkWidget *widget, GdkDragContext *context, GtkSelectionData *selection_data, guint info, guint time, gpointer data)
- static GtkWidget * [layer_selector_get_last_row](#) (GtkListBox *list)
- static GtkWidget * [layer_selector_get_row_before](#) (GtkListBox *list, GtkWidget *row)
- static GtkWidget * [layer_selector_get_row_after](#) (GtkListBox *list, GtkWidget *row)
- static void [layer_selector_drag_data_received](#) (GtkWidget *widget, GdkDragContext *context, gint x, gint y, GtkSelectionData *selection_data, guint info, guint32 time, gpointer data)
- static gboolean [layer_selector_drag_motion](#) (GtkWidget *widget, GdkDragContext *context, int x, int y, guint time)
- static void [layer_selector_drag_leave](#) (GtkWidget *widget, GdkDragContext *context, guint time)
- static void [layer_selector_dispose](#) (GObject *self)
- static void [layer_selector_class_init](#) (LayerSelectorClass *klass)
- static void [layer_selector_setup_dnd](#) (LayerSelector *self)
- static void [layer_selector_init](#) (LayerSelector *self)
- static void [layer_selector_clear_widgets](#) (LayerSelector *self)
- static gboolean [layer_selector_check_if_layer_widget_exists](#) (LayerSelector *self, int layer)
 - Check if a specific layer element with the given layer number is present in the layer selector.*
- static void [sel_layer_element_setup_dnd_callbacks](#) (LayerSelector *self, LayerElement *element)
 - Setup the necessary drag and drop callbacks of layer elements.*
- static void [layer_selector_analyze_cell_layers](#) (LayerSelector *self, struct [gds_cell](#) *cell)
 - Analyze cell layers and append detected layers to layer selector self.*
- static gint [layer_selector_sort_func](#) (GtkWidget *row1, GtkWidget *row2, gpointer unused)
 - sort_func Sort callback for list box*
- static LayerElement * [layer_selector_find_layer_element_in_list](#) (GList *el_list, int layer)
 - Find LayerElement in list with specified layer number.*
- static void [layer_selector_load_layer_mapping_from_file](#) (LayerSelector *self, gchar *file_name)
 - Load the layer mapping from a CSV formatted file.*
- static void [layer_selector_load_mapping_clicked](#) (GtkWidget *button, gpointer user_data)
 - Callback for Load Mapping Button.*
- static void [layer_selector_save_layer_mapping_data](#) (LayerSelector *self, const gchar *file_name)
 - Save layer mapping of selector self to a file.*
- static void [layer_selector_save_mapping_clicked](#) (GtkWidget *button, gpointer user_data)
 - Callback for Save Layer Mapping Button.*

Variables

- static const char * [dnd_additional_css](#)

11.7.1 Detailed Description

This objects implements the layer selector and displays the layers in a list box. It uses [LayerElement](#) objects to display the individual layers inside the list box.

11.7.2 Macro Definition Documentation

11.7.2.1 TYPE_LAYER_SELECTOR

```
#define TYPE_LAYER_SELECTOR (layer_selector_get_type())
```

Definition at line 41 of file [layer-selector.h](#).

11.7.3 Enumeration Type Documentation

11.7.3.1 layer_selector_sort_algo

```
enum layer_selector_sort_algo
```

Defines how to sort the layer selector list box.

Enumerator

LAYER_SELECTOR_SORT_DOWN	
LAYER_SELECTOR_SORT_UP	

Definition at line 46 of file [layer-selector.h](#).

11.7.4 Function Documentation

11.7.4.1 G_DECLARE_FINAL_TYPE()

```
G_BEGIN_DECLS G_DECLARE_FINAL_TYPE (  
    LayerSelector ,  
    layer_selector ,  
    LAYER ,  
    SELECTOR ,  
    GObject )
```

11.7.4.2 layer_selector_analyze_cell_layers()

```
static void layer_selector_analyze_cell_layers (  
    LayerSelector * self,  
    struct gds_cell * cell ) [static]
```


Analyze `cell` layers and append detected layers to layer selector `self`.

Parameters


<i>self</i>	LayerSelector instance
<i>cell</i>	Cell to analyze

Definition at line 482 of file [layer-selector.c](#).

Here is the call graph for this function:



Here is the caller graph for this function:



11.7.4.3 layer_selector_check_if_layer_widget_exists()

```

static gboolean layer_selector_check_if_layer_widget_exists (
    LayerSelector * self,
    int layer ) [static]
  
```

Check if a specific layer element with the given layer number is present in the layer selector.

Parameters

<i>self</i>	LayerSelector instance
<i>layer</i>	Layer number to check for

Returns


TRUE if layer is present, else FALSE

Definition at line [435](#) of file [layer-selector.c](#).

Here is the call graph for this function:



Here is the caller graph for this function:

**11.7.4.4 layer_selector_class_init()**

```
static void layer_selector_class_init (  
    LayerSelectorClass * klass ) [static]
```

Definition at line [321](#) of file [layer-selector.c](#).

Here is the call graph for this function:




11.7.4.5 `layer_selector_clear_widgets()`

```
static void layer_selector_clear_widgets (
    LayerSelector * self ) [static]
```

Definition at line [409](#) of file [layer-selector.c](#).

Here is the caller graph for this function:



11.7.4.6 `layer_selector_dispose()`

```
static void layer_selector_dispose (
    GObject * self ) [static]
```

Definition at line [302](#) of file [layer-selector.c](#).

Here is the caller graph for this function:




11.7.4.7 `layer_selector_drag_data_received()`

```
static void layer_selector_drag_data_received (
    GtkWidget * widget,
    GdkDragContext * context,
    gint x,
    gint y,
    GtkSelectionData * selection_data,
    guint info,
    guint32 time,
    gpointer data ) [static]
```

Definition at line [153](#) of file [layer-selector.c](#).

Here is the caller graph for this function:




11.7.4.8 layer_selector_drag_leave()

```
static void layer_selector_drag_leave (
    GtkWidget * widget,
    GdkDragContext * context,
    guint time ) [static]
```

Definition at line 248 of file [layer-selector.c](#).

Here is the caller graph for this function:




11.7.4.9 layer_selector_drag_motion()

```
static gboolean layer_selector_drag_motion (
    GtkWidget * widget,
    GdkDragContext * context,
    int x,
    int y,
    guint time ) [static]
```

Definition at line 191 of file [layer-selector.c](#).

Here is the call graph for this function:



Here is the caller graph for this function:



11.7.4.10 layer_selector_export_rendered_layer_info()

```
GList * layer_selector_export_rendered_layer_info (
    LayerSelector * selector )
```

Get a list of all layers that shall be exported when rendering the cells.

Parameters


<i>selector</i>	Layer selector instance
-----------------	-------------------------

Returns


List of [layer_info](#) structures containing the layer information

Definition at line 374 of file [layer-selector.c](#).

Here is the call graph for this function:



Here is the caller graph for this function:



11.7.4.11 layer_selector_find_layer_element_in_list()

```

static LayerElement* layer_selector_find_layer_element_in_list (
    GList * el_list,
    int layer ) [static]
  
```

Find LayerElement in list with specified layer number.

Parameters

<i>el_list</i>	List with elements of type LayerElement
<i>layer</i>	Layer number

Returns


Found LayerElement. If nothing is found, NULL.

Definition at line 564 of file [layer-selector.c](#).

Here is the call graph for this function:



Here is the caller graph for this function:



11.7.4.12 layer_selector_force_sort()

```

void layer_selector_force_sort (
    LayerSelector * selector,
    enum layer_selector_sort_algo sort_function )
  
```


Force the layer selector list to be sorted according to `sort_function`.

Parameters


<i>selector</i>	LayerSelector instance
<i>sort_function</i>	The sorting method (up or down sorting)

Definition at line [767](#) of file [layer-selector.c](#).

Here is the call graph for this function:



Here is the caller graph for this function:



11.7.4.13 layer_selector_generate_layer_widgets()

```

void layer_selector_generate_layer_widgets (
    LayerSelector * selector,
    GList * libs )
    
```

Generate layer widgets in the LayerSelector instance.

Note


This clears all previously inserted elements

Parameters


<i>selector</i>	LayerSelector instance
<i>libs</i>	The libraries to add

Definition at line 534 of file [layer-selector.c](#).

Here is the call graph for this function:



Here is the caller graph for this function:




11.7.4.14 layer_selector_get_last_row()

```
static GtkWidget* layer_selector_get_last_row (
    GtkWidget * list ) [static]
```

Definition at line 120 of file [layer-selector.c](#).

Here is the caller graph for this function:




11.7.4.15 layer_selector_get_row_after()

```
static GtkWidget* layer_selector_get_row_after (
    GtkWidget * list,
    GtkWidget* row ) [static]
```

Definition at line 145 of file [layer-selector.c](#).

Here is the caller graph for this function:




11.7.4.16 `layer_selector_get_row_before()`

```
static GtkWidgetRow* layer_selector_get_row_before (
    GtkWidget * list,
    GtkWidgetRow * row ) [static]
```

Definition at line 137 of file [layer-selector.c](#).

Here is the caller graph for this function:

11.7.4.17 `layer_selector_init()`

```
static void layer_selector_init (
    LayerSelector * self ) [static]
```

Definition at line 347 of file [layer-selector.c](#).

11.7.4.18 `layer_selector_load_layer_mapping_from_file()`

```
static void layer_selector_load_layer_mapping_from_file (
    LayerSelector * self,
    gchar * file_name ) [static]
```

Load the layer mapping from a CSV formatted file.


This function imports the layer specification from a file (see [Layer Mapping File Specification](#)). The layer ordering defined in the file is kept. All layers present in the current loaded library, which are not present in the layer mapping file are appended at the end of the layer selector list.

Parameters

<i>self</i>	LayerSelector instance
<i>file_name</i>	File name to load from

Definition at line 587 of file [layer-selector.c](#).

Here is the call graph for this function:



Here is the caller graph for this function:



11.7.4.19 layer_selector_load_mapping_clicked()

```

static void layer_selector_load_mapping_clicked (
    GtkWidget * button,
    gpointer user_data ) [static]
  
```


Callback for Load Mapping Button.

Parameters


<i>button</i>	
<i>user_data</i>	

Definition at line 662 of file [layer-selector.c](#).

Here is the call graph for this function:



Here is the caller graph for this function:



11.7.4.20 layer_selector_new()

```

LayerSelector * layer_selector_new (
    GtkWidget * list_box )
  
```

`layer_selector_new`

Parameters


<code>list_box</code>	The associated list box, the content is displayed in
-----------------------	------------------------------------------------------

Returns

Newly created layer selector

Definition at line 359 of file [layer-selector.c](#).

Here is the call graph for this function:



Here is the caller graph for this function:

**11.7.4.21 layer_selector_save_layer_mapping_data()**

```

static void layer_selector_save_layer_mapping_data (
    LayerSelector * self,
    const gchar * file_name ) [static]
  
```


Save layer mapping of selector *self* to a file.

Parameters

<i>self</i>	LayerSelector instance
<i>file_name</i>	File name to save to

Definition at line 689 of file [layer-selector.c](#).

Here is the call graph for this function:



Here is the caller graph for this function:



11.7.4.22 layer_selector_save_mapping_clicked()

```

static void layer_selector_save_mapping_clicked (
    GtkWidget * button,
    gpointer user_data ) [static]
  
```


Callback for Save Layer Mapping Button.

Parameters


<i>button</i>	
<i>user_data</i>	

Definition at line 721 of file [layer-selector.c](#).

Here is the call graph for this function:



Here is the caller graph for this function:



11.7.4.23 layer_selector_set_load_mapping_button()

```

void layer_selector_set_load_mapping_button (
    LayerSelector * selector,
    GtkWidget * button,
    GtkWindow * main_window )
  
```


Supply button for loading the layer mapping.

Parameters


<i>selector</i>	LayerSelector instance
<i>button</i>	Load button. Will be referenced
<i>main_window</i>	Parent window for dialogs. Will be referenced

Definition at line 743 of file `layer-selector.c`.

Here is the call graph for this function:



Here is the caller graph for this function:



11.7.4.24 layer_selector_set_save_mapping_button()

```

void layer_selector_set_save_mapping_button (
    LayerSelector * selector,
    GtkWidget * button,
    GtkWindow * main_window )
  
```

Supply button for saving the layer mapping.

Parameters


<i>selector</i>	LayerSelector instance
<i>button</i>	Save button. Will be referenced
<i>main_window</i>	Parent window for dialogs. Will be referenced

Definition at line 755 of file [layer-selector.c](#).

Here is the call graph for this function:



Here is the caller graph for this function:




11.7.4.25 layer_selector_setup_dnd()


```
static void layer_selector_setup_dnd (
    LayerSelector * self ) [static]
```

Definition at line 337 of file [layer-selector.c](#).

Here is the call graph for this function:



Here is the caller graph for this function:



11.7.4.26 layer_selector_sort_func()

```

static gint layer_selector_sort_func (
    GtkWidgetRow * row1,
    GtkWidgetRow * row2,
    gpointer unused ) [static]
  
```

sort_func Sort callback for list box

Parameters

<i>row1</i>	
<i>row2</i>	
<i>unused</i>	

Note

Do not use this function. This is an internal callback

Returns


See sort function documentation of GTK+

Definition at line [510](#) of file [layer-selector.c](#).

Here is the call graph for this function:



Here is the caller graph for this function:




11.7.4.27 sel_layer_element_drag_begin()

```

static void sel_layer_element_drag_begin (
    GtkWidget * widget,
    GdkDragContext * context,
    gpointer data ) [static]
  
```

Definition at line 63 of file [layer-selector.c](#).

Here is the caller graph for this function:



11.7.4.28 sel_layer_element_drag_data_get()

```

static void sel_layer_element_drag_data_get (
    GtkWidget * widget,
    GdkDragContext * context,
    GtkSelectionData * selection_data,
    guint info,
    guint time,
    gpointer data ) [static]
  
```

Definition at line 104 of file [layer-selector.c](#).

Here is the caller graph for this function:




11.7.4.29 sel_layer_element_drag_end()

```
static void sel_layer_element_drag_end (
    GtkWidget * widget,
    GdkDragContext * context,
    gpointer data ) [static]
```

Definition at line 92 of file [layer-selector.c](#).

Here is the caller graph for this function:



11.7.4.30 sel_layer_element_setup_dnd_callbacks()

```
static void sel_layer_element_setup_dnd_callbacks (
    LayerSelector * self,
    LayerElement * element ) [static]
```


Setup the necessary drag and drop callbacks of layer elements.

Parameters


<i>self</i>	LayerSelector instance. Used to get the DnD target entry.
<i>element</i>	LayerElement instance to set the callbacks

Definition at line 461 of file [layer-selector.c](#).

Here is the call graph for this function:



Here is the caller graph for this function:



11.7.5 Variable Documentation


11.7.5.1 dnd_additional_css

```
const char* dnd_additional_css [static]
```

Definition at line 266 of file [layer-selector.c](#).

11.8 LibCellRenderer GObject

Collaboration diagram for LibCellRenderer GObject:



Data Structures

- struct [_LibCellRenderer](#)

Macros

- #define [TYPE_LIB_CELL_RENDERER](#) ([lib_cell_renderer_get_type\(\)](#))
- #define [LIB_CELL_RENDERER_ERROR_WARN](#) (1U<<0)
- #define [LIB_CELL_RENDERER_ERROR_ERR](#) (1U<<1)

Typedefs

- typedef struct [_LibCellRenderer](#) [LibCellRenderer](#)

Enumerations

- enum { [PROP_LIB](#) = 1, [PROP_CELL](#), [PROP_ERROR_LEVEL](#), [PROP_COUNT](#) }

Functions

- GType [lib_cell_renderer_get_type](#) (void)
lib_cell_renderer_get_type
- GtkCellRenderer * [lib_cell_renderer_new](#) (void)
Create a new renderer for rendering [gds_cell](#) and [gds_library](#) elements.
- void [lib_cell_renderer_init](#) ([LibCellRenderer](#) *self)
- static void [lib_cell_renderer_constructed](#) (GObject *obj)
- static void [convert_error_level_to_color](#) (GdkRGBA *color, unsigned int error_level)
- static void [lib_cell_renderer_set_property](#) (GObject *object, guint param_id, const GValue *value, GParamSpec *pspec)
- static void [lib_cell_renderer_get_property](#) (GObject *object, guint param_id, GValue *value, GParamSpec *pspec)
- void [lib_cell_renderer_class_init](#) ([LibCellRendererClass](#) *klass)

Variables

- static GParamSpec * [properties](#) [[PROP_COUNT](#)]

11.8.1 Detailed Description

The LibCellRenderer Object is used to render [gds_cell](#) and [gds_library](#) elements to a GtkTreeView.

The LibCellRenderer class is derived from a GtkCellRendererText and works the same way. The additional features are three new properties:

- *gds-lib*: This property can be used to set a [gds_library](#) structure. The renderer will render the name of the library.
- *gds-cell*: This property can be used to set a [gds_cell](#) structure. The renderer will render the name of the cell.
- *error-level*: Set the error level of the cell/library. This affects the foreground color of the rendered output.

Internally the class operates by setting the 'text' property, which is inherited from the base class to the library/cell name ([gds_library::name](#) and [gds_cell::name](#) fields). The error level ([LIB_CELL_RENDERER_ERROR_WARN](#) and [LIB_CELL_RENDERER_ERROR_ERR](#)) is translated to the inherited 'foreground-rgba' property.

11.8.2 Macro Definition Documentation

11.8.2.1 LIB_CELL_RENDERER_ERROR_ERR

```
#define LIB_CELL_RENDERER_ERROR_ERR (1U<<1)
```

Definition at line 45 of file [lib-cell-renderer.h](#).

11.8.2.2 LIB_CELL_RENDERER_ERROR_WARN

```
#define LIB_CELL_RENDERER_ERROR_WARN (1U<<0)
```

Error levels

Definition at line 44 of file [lib-cell-renderer.h](#).

11.8.2.3 TYPE_LIB_CELL_RENDERER

```
#define TYPE_LIB_CELL_RENDERER (lib_cell_renderer_get_type())
```

Definition at line 39 of file [lib-cell-renderer.h](#).

11.8.3 Typedef Documentation

11.8.3.1 LibCellRenderer

```
typedef struct _LibCellRenderer LibCellRenderer
```

11.8.4 Enumeration Type Documentation

11.8.4.1 anonymous enum

anonymous enum

Enumerator

PROP_LIB	
PROP_CELL	
PROP_ERROR_LEVEL	
PROP_COUNT	

Definition at line 36 of file [lib-cell-renderer.c](#).


11.8.5 Function Documentation

11.8.5.1 convert_error_level_to_color()

```
static void convert_error_level_to_color (
    GdkRGBA * color,
    unsigned int error_level ) [static]
```

Definition at line 53 of file [lib-cell-renderer.c](#).

Here is the caller graph for this function:




11.8.5.2 lib_cell_renderer_class_init()

```
void lib_cell_renderer_class_init (  
    LibCellRendererClass * klass )
```

Definition at line 123 of file [lib-cell-renderer.c](#).

Here is the call graph for this function:



11.8.5.3 lib_cell_renderer_constructed()

```
static void lib_cell_renderer_constructed (  
    GObject * obj ) [static]
```

Definition at line 48 of file [lib-cell-renderer.c](#).

Here is the caller graph for this function:




11.8.5.4 lib_cell_renderer_get_property()

```
static void lib_cell_renderer_get_property (
    GObject * object,
    guint param_id,
    GValue * value,
    GParamSpec * pspec ) [static]
```

Definition at line 109 of file [lib-cell-renderer.c](#).

Here is the caller graph for this function:



11.8.5.5 lib_cell_renderer_get_type()

```
GType lib_cell_renderer_get_type (
    void )
```

`lib_cell_renderer_get_type`

Returns

GObject Type

11.8.5.6 lib_cell_renderer_init()

```
void lib_cell_renderer_init (
    LibCellRenderer * self )
```

Definition at line 43 of file [lib-cell-renderer.c](#).

11.8.5.7 lib_cell_renderer_new()

```
GtkCellRenderer * lib_cell_renderer_new (
    void )
```


Create a new renderer for rendering [gds_cell](#) and [gds_library](#) elements.

Returns

New renderer object

Definition at line [143](#) of file [lib-cell-renderer.c](#).

Here is the caller graph for this function:




11.8.5.8 lib_cell_renderer_set_property()


```
static void lib_cell_renderer_set_property (
    GObject * object,
    guint param_id,
    const GValue * value,
    GParamSpec * pspec ) [static]
```

Definition at line [77](#) of file [lib-cell-renderer.c](#).

Here is the call graph for this function:



Here is the caller graph for this function:



11.8.6 Variable Documentation


11.8.6.1 properties

GParamSpec* `properties`[[PROP_COUNT](#)] [static]

Definition at line [121](#) of file [lib-cell-renderer.c](#).

11.9 Output Renderers

Collaboration diagram for Output Renderers:



Modules

- [Cairo Renderer](#)
- [External Shared Object Renderer](#)
- [LaTeX/TikZ Renderer](#)


11.9.1 Detailed Description

The renderers are used to convert the cell structures read from the GDS layout file into different output formats.

Currently the renderers are statically implemented without the use of GObject. This will probably change in future releases in order to make it easier to integrate new rendering methods.

11.10 Custom GTK Widgets

Collaboration diagram for Custom GTK Widgets:



Modules

- [RendererSettingsDialog](#)
- [LayerElement](#)

11.10.1 Detailed Description

11.11 GDS-Utilities

Data Structures

- struct `gds_cell_array_instance`
Struct representing an array instantiation.
- struct `gds_point`
A point in the 2D plane. Sometimes references as vertex.
- struct `gds_cell_checks`
Stores the result of the cell checks.
- struct `gds_time_field`
Date information for cells and libraries.
- struct `gds_graphics`
A GDS graphics object.
- struct `gds_cell_instance`
This represents an instanc of a cell inside another cell.
- struct `gds_cell`
A Cell inside a `gds_library`.
- struct `gds_library`
GDS Toplevel library.

Macros

- `#define GDS_DEFAULT_UNITS (10E-9)`
Default units assumed for library.
- `#define GDS_ERROR(fmt, ...) printf("[PARSE_ERROR] " fmt "\n", ##__VA_ARGS__)`
Print GDS error.
- `#define GDS_WARN(fmt, ...) printf("[PARSE_WARNING] " fmt "\n", ##__VA_ARGS__)`
Print GDS warning.
- `#define GDS_INF(fmt, ...)`
- `#define GDS_PRINT_DEBUG_INFOS (0)`
1: Print infos, 0: Don't print
- `#define CELL_NAME_MAX (100)`
Maximum length of a `gds_cell::name` or a `gds_library::name`.
- `#define MIN(a, b) (((a) < (b)) ? (a) : (b))`
Return smaller number.
- `#define MAX(a, b) (((a) > (b)) ? (a) : (b))`
Return bigger number.

Enumerations

- enum `gds_record` {
`INVALID = 0x0000, HEADER = 0x0002, BGNLIB = 0x0102, LIBNAME = 0x0206,`
`UNITS = 0x0305, ENDLIB = 0x0400, BGNSTR = 0x0502, STRNAME = 0x0606,`
`ENDSTR = 0x0700, BOUNDARY = 0x0800, PATH = 0x0900, SREF = 0x0A00,`
`ENDEL = 0x1100, XY = 0x1003, MAG = 0x1B05, ANGLE = 0x1C05,`
`SNAME = 0x1206, STRANS = 0x1A01, BOX = 0x2D00, LAYER = 0x0D02,`
`WIDTH = 0x0F03, PATHTYPE = 0x2102, COLROW = 0x1302, AREF = 0x0B00 }`
- enum { `GDS_CELL_CHECK_NOT_RUN = -1` }
Defintion of check counter default value that indicates that the corresponding check has not yet been executed.
- enum `graphics_type` { `GRAPHIC_PATH = 0, GRAPHIC_POLYGON = 1, GRAPHIC_BOX = 2` }
Types of graphic objects.
- enum `path_type` { `PATH_FLUSH = 0, PATH_ROUNDED = 1, PATH_SQUARED = 2` }
Defines the line caps of a path.

Functions

- static int `name_cell_ref` (struct `gds_cell_instance` *cell_inst, unsigned int bytes, char *data)
Name cell reference.
- static int `name_array_cell_ref` (struct `gds_cell_array_instance` *cell_inst, unsigned int bytes, char *data)
Name cell reference.
- static double `gds_convert_double` (const char *data)
Convert GDS 8-byte real to double.
- static signed int `gds_convert_signed_int` (const char *data)
Convert GDS INT32 to int.
- static int16_t `gds_convert_signed_int16` (const char *data)
Convert GDS INT16 to int16.
- static uint16_t `gds_convert_unsigned_int16` (const char *data)
Convert GDS UINT16 String to uint16.
- static GList * `append_library` (GList *curr_list, struct `gds_library` **library_ptr)
Append library to list.
- static GList * `append_graphics` (GList *curr_list, enum `graphics_type` type, struct `gds_graphics` **graphics_ptr)
Append graphics to list.
- static GList * `append_vertex` (GList *curr_list, int x, int y)
Appends vertex List.
- static GList * `append_cell` (GList *curr_list, struct `gds_cell` **cell_ptr)
append_cell Append a gds_cell to a list
- static GList * `append_cell_ref` (GList *curr_list, struct `gds_cell_instance` **instance_ptr)
Append a cell reference to the reference GList.
- static int `name_library` (struct `gds_library` *current_library, unsigned int bytes, char *data)
Name a gds_library.
- static int `name_cell` (struct `gds_cell` *cell, unsigned int bytes, char *data, struct `gds_library` *lib)
Names a gds_cell.
- static void `parse_reference_list` (gpointer gcell_ref, gpointer glibrary)
Search for cell reference gcell_ref in glibrary.
- static void `scan_cell_reference_dependencies` (gpointer gcell, gpointer library)
Scans cell references inside cell This function searches all the references in gcell and updates the gds_cell_instance::cell_ref field in each instance.
- static void `scan_library_references` (gpointer library_list_item, gpointer user)
Scans library's cell references.
- static void `gds_parse_date` (const char *buffer, int length, struct `gds_time_field` *mod_date, struct `gds_time_field` *access_date)
gds_parse_date
- static void `convert_aref_to_sref` (struct `gds_cell_array_instance` *aref, struct `gds_cell` *container_cell)
Convert AREF to a bunch of SREFs and append them to container_cell.
- int `parse_gds_from_file` (const char *filename, GList **library_list)
- static void `delete_cell_inst_element` (struct `gds_cell_instance` *cell_inst)
delete_cell_inst_element
- static void `delete_vertex` (struct `gds_point` *vertex)
delete_vertex
- static void `delete_graphics_obj` (struct `gds_graphics` *gfx)
delete_graphics_obj
- static void `delete_cell_element` (struct `gds_cell` *cell)
delete_cell_element
- static void `delete_library_element` (struct `gds_library` *lib)

- delete_library_element*

 - int [clear_lib_list](#) (GList **library_list)
 - Deletes all libraries including cells, references etc.*
 - int [gds_tree_check_cell_references](#) (struct [gds_library](#) *lib)
 - gds_tree_check_cell_references checks if all child cell references can be resolved in the given library*
 - static int [gds_tree_check_list_contains_cell](#) (GList *list, struct [gds_cell](#) *cell)
 - Check if list contains a cell.*
 - static int [gds_tree_check_iterate_ref_and_check](#) (struct [gds_cell](#) *cell_to_check, GList **visited_cells)
 - This function follows down the reference list of a cell and marks each visited subcell and detects loops.*
 - int [gds_tree_check_reference_loops](#) (struct [gds_library](#) *lib)
 - gds_tree_check_reference_loops checks if the given library contains reference loops*

11.11.1 Detailed Description

11.11.2 Macro Definition Documentation

11.11.2.1 CELL_NAME_MAX

```
#define CELL_NAME_MAX (100)
```

Maximum length of a [gds_cell::name](#) or a [gds_library::name](#).

Definition at line 37 of file [gds-types.h](#).

11.11.2.2 GDS_DEFAULT_UNITS

```
#define GDS_DEFAULT_UNITS (10E-9)
```

Default units assumed for library.

Note

This value is usually overwritten with the value defined in the library.

Definition at line 50 of file [gds-parser.c](#).

11.11.2.3 GDS_ERROR

```
#define GDS_ERROR(
    fmt,
    ... ) printf("[PARSE_ERROR] " fmt "\n", ##__VA_ARGS__)
```

Print GDS error.

Definition at line 52 of file [gds-parser.c](#).

11.11.2.4 GDS_INF

```
#define GDS_INF(  
    fmt,  
    ... )
```

Definition at line 58 of file [gds-parser.c](#).

11.11.2.5 GDS_PRINT_DEBUG_INFOS

```
#define GDS_PRINT_DEBUG_INFOS (0)
```

1: Print infos, 0: Don't print

Definition at line 38 of file [gds-parser.h](#).

11.11.2.6 GDS_WARN

```
#define GDS_WARN(  
    fmt,  
    ... ) printf("[PARSE_WARNING] " fmt "\n", ##__VA_ARGS__)
```

Print GDS warning.

Definition at line 53 of file [gds-parser.c](#).

11.11.2.7 MAX

```
#define MAX(  
    a,  
    b ) ((a) > (b)) ? (a) : (b)
```

Return bigger number.

Definition at line 41 of file [gds-types.h](#).

11.11.2.8 MIN

```
#define MIN(  
    a,  
    b ) ((a) < (b)) ? (a) : (b)
```

Return smaller number.

Definition at line 40 of file [gds-types.h](#).

11.11.3 Enumeration Type Documentation

11.11.3.1 anonymous enum

anonymous enum

Definition of check counter default value that indicates that the corresponding check has not yet been executed.

Enumerator

GDS_CELL_CHECK_NOT_RUN	
------------------------	--

Definition at line 45 of file [gds-types.h](#).

11.11.3.2 gds_record

enum [gds_record](#)

Enumerator

INVALID	
HEADER	
BGNLIB	
LIBNAME	
UNITS	
ENDLIB	
BGNSTR	
STRNAME	
ENDSTR	
BOUNDARY	
PATH	
SREF	
ENDEL	
XY	
MAG	
ANGLE	
SNAME	
STRANS	
BOX	
LAYER	
WIDTH	
PATHTYPE	
COLROW	
AREF	

Definition at line 60 of file [gds-parser.c](#).

11.11.3.3 graphics_type

enum [graphics_type](#)

Types of graphic objects.

Enumerator

GRAPHIC_PATH	Path. Essentially a line.
GRAPHIC_POLYGON	An arbitrary polygon.
GRAPHIC_BOX	A rectangle. Warning Implementation in renderers might be buggy!

Definition at line 48 of file [gds-types.h](#).

11.11.3.4 path_type

enum [path_type](#)

Defines the line caps of a path.

Enumerator

PATH_FLUSH	
PATH_ROUNDED	
PATH_SQUARED	

Definition at line 58 of file [gds-types.h](#).

11.11.4 Function Documentation

11.11.4.1 append_cell()

```
static GList* append_cell (
    GList * curr_list,
    struct gds_cell ** cell_ptr ) [static]
```

`append_cell` Append a [gds_cell](#) to a list

Usage similar to [append_cell_ref\(\)](#).

Parameters


<i>curr_list</i>	List containing gds_cell elements. May be NULL
<i>cell_ptr</i>	newly created cell

Returns

new pointer to list

Definition at line 341 of file [gds-parser.c](#).

Here is the caller graph for this function:

**11.11.4.2 append_cell_ref()**

```

static GList* append_cell_ref (
    GList * curr_list,
    struct gds\_cell\_instance ** instance_ptr ) [static]
  
```

Append a cell reference to the reference GList.

Appends a new [gds_cell_instance](#) to `curr_list` and returns the new element via `instance_ptr`

Parameters


<i>curr_list</i>	List of gds_cell_instance elements. May be NULL
<i>instance_ptr</i>	newly created element

Returns

new GList pointer

Definition at line 370 of file [gds-parser.c](#).

Here is the caller graph for this function:



11.11.4.3 `append_graphics()`

```
static GList* append_graphics (
    GList * curr_list,
    enum graphics_type type,
    struct gds_graphics ** graphics_ptr ) [static]
```

Append graphics to list.

Parameters


<i>curr_list</i>	List containing <code>gds_graphics</code> elements. May be NULL
<i>type</i>	Type of graphics
<i>graphics_ptr</i>	newly created graphic is written here

Returns

new list pointer

Definition at line 291 of file `gds-parser.c`.

Here is the caller graph for this function:

11.11.4.4 `append_library()`

```
static GList* append_library (
    GList * curr_list,
    struct gds_library ** library_ptr ) [static]
```

Append library to list.

Parameters


<i>curr_list</i>	List containing <code>gds_library</code> elements. May be NULL.
<i>library_ptr</i>	Return of newly created library.

Returns

Newly created list pointer

Definition at line 266 of file [gds-parser.c](#).

Here is the caller graph for this function:



11.11.4.5 `append_vertex()`

```
static GList* append_vertex (
    GList * curr_list,
    int x,
    int y ) [static]
```

Appends vertex List.

Parameters


<i>curr_list</i>	List containing gds_point elements. May be NULL.
<i>x</i>	x-coordinate of new point
<i>y</i>	y-coordinate of new point

Returns

new Pointer to List.

Definition at line 320 of file [gds-parser.c](#).

Here is the caller graph for this function:



11.11.4.6 `clear_lib_list()`

```
int clear_lib_list (
    GList ** library_list )
```

Deletes all libraries including cells, references etc.

Parameters


<code>library_list</code>	Pointer to a list of gds_library . Is set to NULL after completion.
---------------------------	-------------------------------------------------------------------------------------

Returns


0

Definition at line 1130 of file [gds-parser.c](#).

Here is the call graph for this function:



Here is the caller graph for this function:

11.11.4.7 `convert_aref_to_sref()`

```

static void convert_aref_to_sref (
    struct gds_cell_array_instance * aref,
    struct gds_cell * container_cell ) [static]
  
```

Convert AREF to a bunch of SREFs and append them to `container_cell`.

This function converts a single array reference (`aref`) to `gds_cell_array_instance::rows * gds_cell_array_instance::columns` single references (SREFs). See [gds_cell_instance](#).

Both `gds_cell_array_instance::rows` and `gds_cell_array_instance::columns` must be larger than zero.

Parameters


in	<i>aref</i>	Array reference to parse
in	<i>container_cell</i>	cell to add the converted single references to.

Definition at line 572 of file [gds-parser.c](#).

Here is the call graph for this function:



Here is the caller graph for this function:



11.11.4.8 delete_cell_element()

```
static void delete_cell_element (
    struct gds\_cell * cell ) [static]
```


`delete_cell_element`

Parameters


<i>cell</i>	
-------------	--

Definition at line 1106 of file [gds-parser.c](#).

Here is the call graph for this function:



Here is the caller graph for this function:




11.11.4.9 delete_cell_inst_element()

```

static void delete_cell_inst_element (
    struct gds_cell_instance * cell_inst ) [static]
  
```


delete_cell_inst_element

Parameters



Definition at line 1073 of file gds-parser.c.

Here is the caller graph for this function:



11.11.4.10 delete_graphics_obj()

```
static void delete_graphics_obj (
    struct gds_graphics * gfx ) [static]
```

delete_graphics_obj

Parameters


<i>gfx</i>	
------------	--

Definition at line 1093 of file [gds-parser.c](#).

Here is the call graph for this function:



Here is the caller graph for this function:



11.11.4.11 delete_library_element()

```
static void delete_library_element (
    struct gds_library * lib ) [static]
```


delete_library_element

Parameters


<i>lib</i>	
------------	--

Definition at line 1120 of file [gds-parser.c](#).

Here is the call graph for this function:



Here is the caller graph for this function:



11.11.4.12 delete_vertex()

```
static void delete_vertex (
    struct gds_point * vertex ) [static]
```


delete_vertex

Parameters

<i>vertex</i>

Definition at line 1083 of file [gds-parser.c](#).

Here is the caller graph for this function:



11.11.4.13 gds_convert_double()

```
static double gds_convert_double (
    const char * data ) [static]
```

Convert GDS 8-byte real to double.

Parameters


<i>data</i>	8 Byte GDS real
-------------	-----------------

Returns

result

Definition at line 169 of file [gds-parser.c](#).

Here is the caller graph for this function:



11.11.4.14 gds_convert_signed_int()

```
static signed int gds_convert_signed_int (
    const char * data ) [static]
```

Convert GDS INT32 to int.

Parameters


<i>data</i>	Buffer containing the int
-------------	---------------------------

Returns

result

Definition at line 214 of file [gds-parser.c](#).

Here is the caller graph for this function:



11.11.4.15 `gds_convert_signed_int16()`

```
static int16_t gds_convert_signed_int16 (
    const char * data ) [static]
```

Convert GDS INT16 to int16.

Parameters


<i>data</i>	Buffer containing the INT16
-------------	-----------------------------

Returns

result

Definition at line [235](#) of file [gds-parser.c](#).

Here is the caller graph for this function:



11.11.4.16 `gds_convert_unsigned_int16()`

```
static uint16_t gds_convert_unsigned_int16 (
    const char * data ) [static]
```

Convert GDS UINT16 String to uint16.

Parameters


<i>data</i>	Buffer containing the uint16
-------------	------------------------------

Returns

result

Definition at line 250 of file [gds-parser.c](#).

Here is the caller graph for this function:

11.11.4.17 `gds_parse_date()`

```

static void gds_parse_date (
    const char * buffer,
    int length,
    struct gds\_time\_field * mod_date,
    struct gds\_time\_field * access_date ) [static]
  
```


`gds_parse_date`

Parameters


<i>buffer</i>	Buffer that contains the GDS Date field
<i>length</i>	Length of <i>buffer</i>
<i>mod_date</i>	Modification Date
<i>access_date</i>	Last Access Date

Definition at line 527 of file [gds-parser.c](#).

Here is the call graph for this function:



Here is the caller graph for this function:



11.11.4.18 `gds_tree_check_cell_references()`

```
int gds_tree_check_cell_references (
    struct gds_library * lib )
```

`gds_tree_check_cell_references` checks if all child cell references can be resolved in the given library

This function will only mark cells that directly contain unresolved references.

If a cell contains a reference to a cell with unresolved references, it is not flagged.

Parameters


<i>lib</i>	The GDS library to check
------------	--------------------------

Returns

less than 0 if an error occurred during processing; 0 if all child cells could be resolved; greater than zero if the processing was successful but not all cell references could be resolved. In this case the number of unresolved references is returned

Definition at line 40 of file [gds-tree-checker.c](#).

Here is the caller graph for this function:



11.11.4.19 gds_tree_check_iterate_ref_and_check()

```
static int gds_tree_check_iterate_ref_and_check (  
    struct gds_cell * cell_to_check,  
    GList ** visited_cells ) [static]
```

This function follows down the reference list of a cell and marks each visited subcell and detects loops.

Parameters


<i>cell_to_check</i>	The cell to check for reference loops
<i>visited_cells</i>	Pointer to list head. May be zero.

Returns


0 if no loops exist; error in processing: <0; loop found: >0

Definition at line 110 of file [gds-tree-checker.c](#).

Here is the call graph for this function:



Here is the caller graph for this function:

11.11.4.20 `gds_tree_check_list_contains_cell()`

```

static int gds_tree_check_list_contains_cell (
    GList * list,
    struct gds_cell * cell ) [static]
  
```

Check if list contains a cell.

Parameters


<i>list</i>	GList to check. May be a null pointer
<i>cell</i>	Cell to check for

Returns

0 if cell is not in list. 1 if cell is in list

Definition at line 93 of file [gds-tree-checker.c](#).

Here is the caller graph for this function:

**11.11.4.21 gds_tree_check_reference_loops()**

```
int gds_tree_check_reference_loops (
    struct gds_library * lib )
```

`gds_tree_check_reference_loops` checks if the given library contains reference loops

Parameters


<i>lib</i>	GDS library
------------	-------------

Returns


negative if an error occurred, zero if there are no reference loops, else a positive number representing the number of affected cells

Definition at line 157 of file [gds-tree-checker.c](#).

Here is the call graph for this function:



Here is the caller graph for this function:



11.11.4.22 `name_array_cell_ref()`

```
static int name_array_cell_ref (
    struct gds_cell_array_instance * cell_inst,
    unsigned int bytes,
    char * data ) [static]
```

Name cell reference.

Parameters


<i>cell_inst</i>	Cell reference
<i>bytes</i>	Length of name
<i>data</i>	Name

Returns

0 if successful

Definition at line 141 of file [gds-parser.c](#).

Here is the caller graph for this function:

11.11.4.23 `name_cell()`

```
static int name_cell (
    struct gds_cell * cell,
    unsigned int bytes,
    char * data,
    struct gds_library * lib ) [static]
```

Names a [gds_cell](#).

Parameters


<i>cell</i>	Cell to name
<i>bytes</i>	Length of name
<i>data</i>	Name
<i>lib</i>	Library in which <code>cell</code> is located

Returns

0 id successful

Definition at line 429 of file [gds-parser.c](#).

Here is the caller graph for this function:

**11.11.4.24 name_cell_ref()**

```

static int name_cell_ref (
    struct gds\_cell\_instance * cell_inst,
    unsigned int bytes,
    char * data ) [static]
  
```

Name cell reference.

Parameters


<i>cell_inst</i>	Cell reference
<i>bytes</i>	Length of name
<i>data</i>	Name

Returns

0 if successful

Definition at line 111 of file [gds-parser.c](#).

Here is the caller graph for this function:



11.11.4.25 name_library()

```
static int name_library (
    struct gds_library * current_library,
    unsigned int bytes,
    char * data ) [static]
```

Name a [gds_library](#).

Parameters


<i>current_library</i>	Library to name
<i>bytes</i>	Length of name
<i>data</i>	Name

Returns

0 if successful

Definition at line [398](#) of file [gds-parser.c](#).

Here is the caller graph for this function:




11.11.4.26 parse_gds_from_file()


```
int parse_gds_from_file (
    const char * filename,
    GList ** library_list )
```

Definition at line [617](#) of file [gds-parser.c](#).

Here is the call graph for this function:



Here is the caller graph for this function:



11.11.4.27 parse_reference_list()

```

static void parse_reference_list (
    gpointer gcell_ref,
    gpointer glibrary ) [static]
  
```


Search for cell reference `gcell_ref` in `glibrary`.


Search cell referenced by `gcell_ref` inside `glibrary` and update `gds_cell_instance::cell_ref` with found `gds_cell`

Parameters

<code>gcell_ref</code>	gpointer cast of struct <code>gds_cell_instance *</code>
<code>glibrary</code>	gpointer cast of struct <code>gds_library *</code>

Definition at line 461 of file `gds-parser.c`.

Here is the caller graph for this function:



11.11.4.28 scan_cell_reference_dependencies()

```

static void scan_cell_reference_dependencies (
    gpointer gcell,
    gpointer library ) [static]
  
```


Scans cell references inside cell This function searches all the references in `gcell` and updates the `gds_cell_instance::cell_ref` field in each instance.

Parameters


<code>gcell</code>	pointer cast of <code>gds_cell *</code>
<code>library</code>	Library where the cell references are searched in

Definition at line 493 of file `gds-parser.c`.

Here is the call graph for this function:



Here is the caller graph for this function:



11.11.4.29 scan_library_references()

```

static void scan_library_references (
    gpointer library_list_item,
    gpointer user ) [static]
  
```

Scans library's cell references.


This function searches all the references between cells and updates the `gds_cell_instance::cell_ref` field in each instance

Parameters


<i>library_list_item</i>	List containing gds_library elements
<i>user</i>	not used

Definition at line 511 of file [gds-parser.c](#).

Here is the call graph for this function:



Here is the caller graph for this function:



11.12 Mapping-Parser

Functions

- int [mapping_parser_load_line](#) (GDataInputStream *stream, gboolean *export, char **name, int *layer, GdkRGBA *color)
Load a line from `stream` and parse try to parse it as layer information.
- void [mapping_parser_gen_csv_line](#) (LayerElement *layer_element, char *line_buffer, size_t max_len)
Create Line for LayerMapping file with supplied information.

11.12.1 Detailed Description

11.12.2 Function Documentation

11.12.2.1 [mapping_parser_gen_csv_line\(\)](#)

```
void mapping_parser_gen_csv_line (  
    LayerElement * layer_element,  
    char * line_buffer,  
    size_t max_len )
```


Create Line for LayerMapping file with supplied information.

Parameters


<i>layer_element</i>	information
<i>line_buffer</i>	buffer to write to
<i>max_len</i>	Maximum length that can be used in <code>line_buffer</code>

Definition at line 97 of file [mapping-parser.c](#).

Here is the call graph for this function:



Here is the caller graph for this function:



11.12.2.2 mapping_parser_load_line()

```

int mapping_parser_load_line (
    GDataInputStream * stream,
    gboolean * export,
    char ** name,
    int * layer,
    GdkRGBA * color )
  
```

Load a line from `stream` and parse try to parse it as layer information.

Parameters


<i>stream</i>	Input data stream
<i>export</i>	Layer shall be exported
<i>name</i>	Layer name. Free returned pointer after using.
<i>layer</i>	Layer number
<i>color</i>	RGBA color.

Returns

1 if malformed line, 0 if parsing was successful and parameters are valid, -1 if file end

Definition at line 34 of file [mapping-parser.c](#).

Here is the caller graph for this function:



11.13 Version Number

Variables

- `const char * _app_version_string`
This string holds the [Git Based Version Number](#) of the app.
- `const char * _app_version_string = "! version not set !"`
This string holds the [Git Based Version Number](#) of the app.

11.13.1 Detailed Description

See [Git Based Version Number](#)

11.13.2 Variable Documentation

11.13.2.1 `_app_version_string` [1/2]

```
const char* _app_version_string
```

This string holds the [Git Based Version Number](#) of the app.

Definition at line 33 of file [version.c](#).

11.13.2.2 `_app_version_string` [2/2]


```
const char* _app_version_string = "! version not set !"
```

This string holds the [Git Based Version Number](#) of the app.

Definition at line 33 of file [version.c](#).

11.14 RendererSettingsDialog

Collaboration diagram for RendererSettingsDialog:



Data Structures

- struct [render_settings](#)
This struct holds the renderer configuration.
- struct [_RendererSettingsDialog](#)

Macros

- #define [RENDERER_TYPE_SETTINGS_DIALOG](#) ([renderer_settings_dialog_get_type\(\)](#))

Enumerations

- enum [output_renderer](#) { [RENDERER_LATEX_TIKZ](#), [RENDERER_CAIROGRAPHICS_PDF](#), [RENDERER_CAIROGRAPHICS_PNG](#) }
- *return type of the [RendererSettingsDialog](#)*
- enum { [PROP_CELL_NAME](#) = 1, [PROP_COUNT](#) }

Functions

- [RendererSettingsDialog](#) * [renderer_settings_dialog_new](#) ([GtkWindow](#) *parent)
Create a new [RendererSettingsDialog](#) GObject.
- G_END_DECLS void [renderer_settings_dialog_set_settings](#) ([RendererSettingsDialog](#) *dialog, struct [render_settings](#) *settings)
Apply settings to dialog.
- void [renderer_settings_dialog_get_settings](#) ([RendererSettingsDialog](#) *dialog, struct [render_settings](#) *settings)
Get the settings configured in the dialog.
- void [renderer_settings_dialog_set_cell_width](#) ([RendererSettingsDialog](#) *dialog, unsigned int width)
[renderer_settings_dialog_set_cell_width](#) Set width for rendered cell
- void [renderer_settings_dialog_set_cell_height](#) ([RendererSettingsDialog](#) *dialog, unsigned int height)
[renderer_settings_dialog_set_cell_height](#) Set height for rendered cell
- void [renderer_settings_dialog_set_database_unit_scale](#) ([RendererSettingsDialog](#) *dialog, double unit_in_meters)
[renderer_settings_dialog_set_database_unit_scale](#) Set database scale

- static void [renderer_settings_dialog_set_property](#) (GObject *object, guint property_id, const GValue *value, GParamSpec *pspec)
- static void [renderer_settings_dialog_get_property](#) (GObject *object, guint property_id, GValue *value, GParamSpec *pspec)
- static void [renderer_settings_dialog_class_init](#) (RendererSettingsDialogClass *klass)
- static void [show_tex_options](#) (RendererSettingsDialog *self)
- static void [hide_tex_options](#) (RendererSettingsDialog *self)
- static void [latex_render_callback](#) (GtkToggleButton *radio, RendererSettingsDialog *dialog)
- static gboolean [shape_drawer_drawing_callback](#) (GtkWidget *widget, cairo_t *cr, gpointer data)
- static double [convert_number_to_engineering](#) (double input, const char **out_prefix)
- static void [renderer_settings_dialog_update_labels](#) (RendererSettingsDialog *self)
- static void [scale_value_changed](#) (GtkRange *range, gpointer user_data)
- static void [renderer_settings_dialog_init](#) (RendererSettingsDialog *self)

Variables

- static GParamSpec * [properties](#) [PROP_COUNT]

11.14.1 Detailed Description

11.14.2 Macro Definition Documentation

11.14.2.1 RENDERER_TYPE_SETTINGS_DIALOG

```
#define RENDERER_TYPE_SETTINGS_DIALOG (renderer_settings_dialog_get_type())
```

Definition at line 51 of file [conv-settings-dialog.h](#).

11.14.3 Enumeration Type Documentation

11.14.3.1 anonymous enum

anonymous enum

Enumerator

PROP_CELL_NAME	
PROP_COUNT	

Definition at line 57 of file [conv-settings-dialog.c](#).

11.14.3.2 output_renderer

enum `output_renderer`

return type of the RedererSettingsDialog

Enumerator

RENDERER_LATEX_TIKZ	
RENDERER_CAIROGRAPHICS_PDF	
RENDERER_CAIROGRAPHICS_SVG	

Definition at line 40 of file [conv-settings-dialog.h](#).


11.14.4 Function Documentation

11.14.4.1 convert_number_to_engineering()

```
static double convert_number_to_engineering (
    double input,
    const char ** out_prefix ) [static]
```

Definition at line 181 of file [conv-settings-dialog.c](#).

Here is the caller graph for this function:




11.14.4.2 hide_tex_options()

```
static void hide_tex_options (
    RendererSettingsDialog * self ) [static]
```

Definition at line 120 of file [conv-settings-dialog.c](#).

Here is the caller graph for this function:




11.14.4.3 latex_render_callback()

```
static void latex_render_callback (
    GtkToggleButton * radio,
    RendererSettingsDialog * dialog ) [static]
```

Definition at line 126 of file [conv-settings-dialog.c](#).

Here is the call graph for this function:



Here is the caller graph for this function:




11.14.4.4 renderer_settings_dialog_class_init()

```
static void renderer_settings_dialog_class_init (
    RendererSettingsDialogClass * klass ) [static]
```

Definition at line 97 of file [conv-settings-dialog.c](#).

Here is the call graph for this function:




11.14.4.5 `renderer_settings_dialog_get_property()`

```
static void renderer_settings_dialog_get_property (
    GObject * object,
    guint property_id,
    GValue * value,
    GParamSpec * pspec ) [static]
```

Definition at line 81 of file [conv-settings-dialog.c](#).

Here is the caller graph for this function:

11.14.4.6 `renderer_settings_dialog_get_settings()`

```
void renderer_settings_dialog_get_settings (
    RendererSettingsDialog * dialog,
    struct render_settings * settings )
```


Get the settings configured in the dialog.

Parameters

<i>dialog</i>	
<i>settings</i>	

Definition at line 317 of file [conv-settings-dialog.c](#).

Here is the caller graph for this function:




11.14.4.7 `renderer_settings_dialog_init()`

```
static void renderer_settings_dialog_init (
    RendererSettingsDialog * self ) [static]
```

Definition at line 265 of file [conv-settings-dialog.c](#).

Here is the call graph for this function:

11.14.4.8 `renderer_settings_dialog_new()`

```
RendererSettingsDialog * renderer_settings_dialog_new (
    GtkWidget * parent )
```

Create a new `RendererSettingsDialog` GObject.

Parameters


<i>parent</i>	Parent window
---------------	---------------

Returns

Created dialog object

Definition at line 306 of file [conv-settings-dialog.c](#).

Here is the caller graph for this function:



11.14.4.9 `renderer_settings_dialog_set_cell_height()`

```
void renderer_settings_dialog_set_cell_height (
    RendererSettingsDialog * dialog,
    unsigned int height )
```


`renderer_settings_dialog_set_cell_height` Set height for rendered cell

Parameters


<i>dialog</i>	
<i>height</i>	Height in database units

Definition at line 374 of file [conv-settings-dialog.c](#).

Here is the call graph for this function:



Here is the caller graph for this function:

11.14.4.10 `renderer_settings_dialog_set_cell_width()`

```
void renderer_settings_dialog_set_cell_width (
    RendererSettingsDialog * dialog,
    unsigned int width )
```


`renderer_settings_dialog_set_cell_width` Set width for rendered cell

Parameters


<i>dialog</i>	
<i>width</i>	Width in database units

Definition at line 362 of file [conv-settings-dialog.c](#).

Here is the call graph for this function:



Here is the caller graph for this function:



11.14.4.11 render_settings_dialog_set_database_unit_scale()

```

void render_settings_dialog_set_database_unit_scale (
    RendererSettingsDialog * dialog,
    double unit_in_meters )
  
```


render_settings_dialog_set_database_unit_scale Set database scale

Parameters


<i>dialog</i>	dialog element
<i>unit_in_meters</i>	Database unit in meters

Definition at line 386 of file [conv-settings-dialog.c](#).

Here is the call graph for this function:



Here is the caller graph for this function:




11.14.4.12 `renderer_settings_dialog_set_property()`

```

static void renderer_settings_dialog_set_property (
    GObject * object,
    guint property_id,
    const GValue * value,
    GParamSpec * pspec ) [static]
  
```

Definition at line 64 of file [conv-settings-dialog.c](#).

Here is the caller graph for this function:



11.14.4.13 `renderer_settings_dialog_set_settings()`

```

void renderer_settings_dialog_set_settings (
    RendererSettingsDialog * dialog,
    struct render\_settings * settings )
  
```


Apply settings to dialog.

Parameters


<i>dialog</i>	
<i>settings</i>	

Definition at line 337 of file [conv-settings-dialog.c](#).

Here is the call graph for this function:



Here is the caller graph for this function:




11.14.4.14 `render_settings_dialog_update_labels()`

```


static void render_settings_dialog_update_labels (
    RendererSettingsDialog * self ) [static]
  
```

Definition at line 220 of file [conv-settings-dialog.c](#).

Here is the call graph for this function:



Here is the caller graph for this function:




11.14.4.15 scale_value_changed()

```

static void scale_value_changed (
    GtkRange * range,
    gpointer user_data ) [static]
  
```

Definition at line 256 of file [conv-settings-dialog.c](#).

Here is the call graph for this function:



Here is the caller graph for this function:




11.14.4.16 shape_drawer_drawing_callback()

```
static gboolean shape_drawer_drawing_callback (
    GtkWidget * widget,
    cairo_t * cr,
    gpointer data ) [static]
```

Definition at line 134 of file [conv-settings-dialog.c](#).

Here is the caller graph for this function:




11.14.4.17 show_tex_options()

```
static void show_tex_options (
    RendererSettingsDialog * self ) [static]
```

Definition at line 113 of file [conv-settings-dialog.c](#).

Here is the caller graph for this function:



11.14.5 Variable Documentation

11.14.5.1 properties

```
GParamSpec* properties[PROP_COUNT] [static]
```

Definition at line 62 of file [conv-settings-dialog.c](#).

11.15 LayerElement

Collaboration diagram for LayerElement:



Data Structures

- struct [_LayerElementPriv](#)
- struct [_LayerElement](#)
- struct [layer_element_dnd_data](#)

This structure holds the necessary data to set up a LayerElement for Drag'n'Drop.

Macros

- `#define` [TYPE_LAYER_ELEMENT](#) ([layer_element_get_type\(\)](#))

Typedefs

- typedef struct [_LayerElementPriv](#) [LayerElementPriv](#)

Functions

- GtkWidget * [layer_element_new](#) (void)
Create new layer element object.
- const char * [layer_element_get_name](#) (LayerElement *elem)
get name of the layer
- void [layer_element_set_name](#) (LayerElement *elem, const char *name)
layer_element_set_name
- void [layer_element_set_layer](#) (LayerElement *elem, int layer)
Set layer number for this layer.
- int [layer_element_get_layer](#) (LayerElement *elem)
Get layer number.
- void [layer_element_set_export](#) (LayerElement *elem, gboolean export)
Set export flag for this layer.
- gboolean [layer_element_get_export](#) (LayerElement *elem)
Get export flag of layer.
- void [layer_element_get_color](#) (LayerElement *elem, GdkRGBA *rgba)
Get color of layer.
- void [layer_element_set_color](#) (LayerElement *elem, GdkRGBA *rgba)
Set color of layer.
- void [layer_element_set_dnd_callbacks](#) (LayerElement *elem, struct [layer_element_dnd_data](#) *data)
Setup drag and drop of elem for use in the LayerSelector.
- static void [layer_element_dispose](#) (GObject *obj)
- static void [layer_element_constructed](#) (GObject *obj)
- static void [layer_element_class_init](#) (LayerElementClass *klass)
- static void [layer_element_init](#) (LayerElement *self)

11.15.1 Detailed Description

11.15.2 Macro Definition Documentation

11.15.2.1 TYPE_LAYER_ELEMENT

```
#define TYPE_LAYER_ELEMENT (layer_element_get_type())
```

Definition at line 42 of file [layer-element.h](#).

11.15.3 Typedef Documentation

11.15.3.1 LayerElementPriv

```
typedef struct _LayerElementPriv LayerElementPriv
```


11.15.4 Function Documentation

11.15.4.1 layer_element_class_init()

```
static void layer_element_class_init (  
    LayerElementClass * klass ) [static]
```

Definition at line 54 of file [layer-element.c](#).

Here is the call graph for this function:



11.15.4.2 `layer_element_constructed()`

```
static void layer_element_constructed (  
    GObject * obj ) [static]
```

Definition at line 49 of file [layer-element.c](#).

Here is the caller graph for this function:

11.15.4.3 `layer_element_dispose()`

```
static void layer_element_dispose (  
    GObject * obj ) [static]
```

Definition at line 43 of file [layer-element.c](#).

Here is the caller graph for this function:

11.15.4.4 `layer_element_get_color()`

```
void layer_element_get_color (  
    LayerElement * elem,  
    GdkRGBA * rgba )
```

Get color of layer.

Parameters

<i>elem</i>	Layer Element
<i>rgba</i>	RGBA color

Definition at line 120 of file [layer-element.c](#).

Here is the caller graph for this function:

11.15.4.5 `layer_element_get_export()`

```
gboolean layer_element_get_export (
    LayerElement * elem )
```

Get export flag of layer.


Parameters

<i>elem</i>	Layer Element
-------------	---------------

Returns

Definition at line 115 of file [layer-element.c](#).

Here is the caller graph for this function:

11.15.4.6 `layer_element_get_layer()`

```
int layer_element_get_layer (
    LayerElement * elem )
```

Get layer number.

Parameters


<i>elem</i>	Layer Element
-------------	---------------

Returns

Number of this layer

Definition at line 105 of file [layer-element.c](#).

Here is the caller graph for this function:



11.15.4.7 layer_element_get_name()

```
const char * layer_element_get_name (
    LayerElement * elem )
```

get name of the layer

Parameters


<i>elem</i>	Layer element
-------------	---------------

Returns

Name. Must not be changed, freed or anything else.

Definition at line 84 of file [layer-element.c](#).

Here is the caller graph for this function:



11.15.4.8 layer_element_init()

```
static void layer_element_init (
    LayerElement * self ) [static]
```

Definition at line 61 of file [layer-element.c](#).

11.15.4.9 layer_element_new()

```
GtkWidget * layer_element_new (
    void )
```


Create new layer element object.

Returns

new object

Definition at line 79 of file [layer-element.c](#).

Here is the caller graph for this function:



11.15.4.10 layer_element_set_color()

```
void layer_element_set_color (
    LayerElement * elem,
    GdkRGBA * rgba )
```


Set color of layer.

Parameters

<i>elem</i>	Layer Element
<i>rgba</i>	RGBA color

Definition at line 128 of file [layer-element.c](#).

Here is the caller graph for this function:



11.15.4.11 layer_element_set_dnd_callbacks()

```
void layer_element_set_dnd_callbacks (
    LayerElement * elem,
    struct layer_element_dnd_data * data )
```


Setup drag and drop of `elem` for use in the LayerSelector.

Parameters

<i>elem</i>	Layer element to set up
<i>data</i>	Data array containing the necessary callbacks etc. for drag and drop.

Definition at line 136 of file [layer-element.c](#).

Here is the caller graph for this function:



11.15.4.12 layer_element_set_export()

```
void layer_element_set_export (
    LayerElement * elem,
    gboolean export )
```


Set export flag for this layer.

Parameters

<i>elem</i>	Layer Element
<i>export</i>	flag

Definition at line 110 of file [layer-element.c](#).

Here is the caller graph for this function:



11.15.4.13 layer_element_set_layer()

```
void layer_element_set_layer (
    LayerElement * elem,
    int layer )
```


Set layer number for this layer.

Parameters

<i>elem</i>	Layer element
<i>layer</i>	Layer number

Definition at line 94 of file [layer-element.c](#).

Here is the caller graph for this function:



11.15.4.14 layer_element_set_name()

```
void layer_element_set_name (
    LayerElement * elem,
    const char * name )
```


`layer_element_set_name`

Parameters

<i>elem</i>	set the name of the layer
<i>name</i>	Name. Can be freed after call to this function

Definition at line 89 of file [layer-element.c](#).

Here is the caller graph for this function:



Chapter 12

Data Structure Documentation

12.1 `gds_cell_checks::_check_internals` Struct Reference

For the internal use of the checker.

```
#include <gds-types.h>
```

Data Fields

- int [marker](#)

12.1.1 Detailed Description

For the internal use of the checker.

Warning

Do not use this structure and its contents!

Definition at line [78](#) of file [gds-types.h](#).

12.1.2 Field Documentation

12.1.2.1 `marker`

```
int marker
```


Definition at line [79](#) of file [gds-types.h](#).

The documentation for this struct was generated from the following file:

- [gds-types.h](#)

12.2 `_GdsRenderGui` Struct Reference

Collaboration diagram for `_GdsRenderGui`:



Data Fields

- GObject [parent](#)
- GtkWidget * [main_window](#)
- GtkWidget * [convert_button](#)
- GtkTreeStore * [cell_tree_store](#)
- GtkWidget * [cell_search_entry](#)
- LayerSelector * [layer_selector](#)
- GtkTreeView * [cell_tree_view](#)
- GList * [gds_libraries](#)
- struct [render_settings](#) [render_dialog_settings](#)

12.2.1 Detailed Description

Definition at line 49 of file [gds-render-gui.c](#).

12.2.2 Field Documentation

12.2.2.1 `cell_search_entry`

GtkWidget* `cell_search_entry`

Definition at line 57 of file [gds-render-gui.c](#).

12.2.2.2 cell_tree_store

GtkTreeStore* cell_tree_store

Definition at line 56 of file [gds-render-gui.c](#).

12.2.2.3 cell_tree_view

GtkTreeView* cell_tree_view

Definition at line 59 of file [gds-render-gui.c](#).

12.2.2.4 convert_button

GtkWidget* convert_button

Definition at line 55 of file [gds-render-gui.c](#).

12.2.2.5 gds_libraries

GList* gds_libraries

Definition at line 60 of file [gds-render-gui.c](#).

12.2.2.6 layer_selector

LayerSelector* layer_selector

Definition at line 58 of file [gds-render-gui.c](#).

12.2.2.7 main_window

GtkWindow* main_window

Definition at line 54 of file [gds-render-gui.c](#).

12.2.2.8 parent

GObject parent

Definition at line 51 of file [gds-render-gui.c](#).

12.2.2.9 render_dialog_settings

```
struct render\_settings render_dialog_settings
```

Definition at line 61 of file [gds-render-gui.c](#).


The documentation for this struct was generated from the following file:

- [gds-render-gui.c](#)

12.3 [_LayerElement](#) Struct Reference

```
#include <layer-element.h>
```

Collaboration diagram for [_LayerElement](#):



Data Fields

- [GtkListBoxRow](#) parent
- [LayerElementPriv](#) priv

12.3.1 Detailed Description

Definition at line 53 of file [layer-element.h](#).

12.3.2 Field Documentation

12.3.2.1 `parent`

`GtkListBoxRow` `parent`

Definition at line 55 of file [layer-element.h](#).

12.3.2.2 `priv`

`LayerElementPriv` `priv`

Definition at line 57 of file [layer-element.h](#).

The documentation for this struct was generated from the following file:

- [layer-element.h](#)

12.4 `_LayerElementPriv` Struct Reference

```
#include <layer-element.h>
```

Data Fields

- `GtkEntry` * [name](#)
- `GtkLabel` * [layer](#)
- `int` [layer_num](#)
- `GtkEventBox` * [event_handle](#)
- `GtkColorButton` * [color](#)
- `GtkCheckButton` * [export](#)

12.4.1 Detailed Description

Definition at line 44 of file [layer-element.h](#).

12.4.2 Field Documentation

12.4.2.1 color

```
GtkColorButton* color
```

Definition at line 49 of file [layer-element.h](#).

12.4.2.2 event_handle

```
GtkEventBox* event_handle
```

Definition at line 48 of file [layer-element.h](#).

12.4.2.3 export

```
GtkCheckButton* export
```

Definition at line 50 of file [layer-element.h](#).

12.4.2.4 layer

```
GtkLabel* layer
```

Definition at line 46 of file [layer-element.h](#).

12.4.2.5 layer_num

```
int layer_num
```

Definition at line 47 of file [layer-element.h](#).

12.4.2.6 name

```
GtkEntry* name
```

Definition at line 45 of file [layer-element.h](#).

The documentation for this struct was generated from the following file:

- [layer-element.h](#)

12.5 `_LayerSelector` Struct Reference

Data Fields

- GObject [parent](#)
- GtkWidget * [associated_load_button](#)
- GtkWidget * [associated_save_button](#)
- GtkWindow * [load_parent_window](#)
- GtkWindow * [save_parent_window](#)
- GtkListBox * [list_box](#)
- GtkTargetEntry [dnd_target](#)
- gpointer [dummy](#) [4]

12.5.1 Detailed Description

Definition at line 42 of file [layer-selector.c](#).

12.5.2 Field Documentation

12.5.2.1 `associated_load_button`

```
GtkWidget* associated_load_button
```

Definition at line 46 of file [layer-selector.c](#).

12.5.2.2 `associated_save_button`

```
GtkWidget* associated_save_button
```

Definition at line 47 of file [layer-selector.c](#).

12.5.2.3 `dnd_target`

```
GtkTargetEntry dnd_target
```

Definition at line 52 of file [layer-selector.c](#).

12.5.2.4 dummy

```
gpointer dummy[4]
```

Definition at line 54 of file [layer-selector.c](#).

12.5.2.5 list_box

```
GtkListBox* list_box
```

Definition at line 50 of file [layer-selector.c](#).

12.5.2.6 load_parent_window

```
GtkWindow* load_parent_window
```

Definition at line 48 of file [layer-selector.c](#).

12.5.2.7 parent

```
GObject parent
```

Definition at line 44 of file [layer-selector.c](#).

12.5.2.8 save_parent_window

```
GtkWindow* save_parent_window
```

Definition at line 49 of file [layer-selector.c](#).

The documentation for this struct was generated from the following file:

- [layer-selector.c](#)

12.6 `_LibCellRenderer` Struct Reference

```
#include <lib-cell-renderer.h>
```

Data Fields

- `GtkCellRendererText` [super](#)

12.6.1 Detailed Description

Definition at line 48 of file `lib-cell-renderer.h`.

12.6.2 Field Documentation

12.6.2.1 `super`

`GtkCellRendererText` [super](#)

Definition at line 50 of file `lib-cell-renderer.h`.

The documentation for this struct was generated from the following file:

- `lib-cell-renderer.h`

12.7 `_RendererSettingsDialog` Struct Reference

Data Fields

- `GtkDialog` [parent](#)
- `GtkWidget` * [radio_latex](#)
- `GtkWidget` * [radio_cairo_pdf](#)
- `GtkWidget` * [radio_cairo_svg](#)
- `GtkWidget` * [scale](#)
- `GtkWidget` * [layer_check](#)
- `GtkWidget` * [standalone_check](#)
- `GtkDrawingArea` * [shape_drawing](#)
- `GtkLabel` * [x_label](#)
- `GtkLabel` * [y_label](#)
- `GtkLabel` * [x_output_label](#)
- `GtkLabel` * [y_output_label](#)
- unsigned int [cell_height](#)
- unsigned int [cell_width](#)
- double [unit_in_meters](#)

12.7.1 Detailed Description

Definition at line 34 of file `conv-settings-dialog.c`.

12.7.2 Field Documentation

12.7.2.1 cell_height

unsigned int cell_height

Definition at line 50 of file [conv-settings-dialog.c](#).

12.7.2.2 cell_width

unsigned int cell_width

Definition at line 51 of file [conv-settings-dialog.c](#).

12.7.2.3 layer_check

GtkWidget* layer_check

Definition at line 41 of file [conv-settings-dialog.c](#).

12.7.2.4 parent

GtkDialog parent

Definition at line 35 of file [conv-settings-dialog.c](#).

12.7.2.5 radio_cairo_pdf

GtkWidget* radio_cairo_pdf

Definition at line 38 of file [conv-settings-dialog.c](#).

12.7.2.6 radio_cairo_svg

GtkWidget* radio_cairo_svg

Definition at line 39 of file [conv-settings-dialog.c](#).

12.7.2.7 radio_latex

GtkWidget* radio_latex

Definition at line 37 of file [conv-settings-dialog.c](#).

12.7.2.8 scale

GtkWidget* scale

Definition at line 40 of file [conv-settings-dialog.c](#).

12.7.2.9 shape_drawing

GtkDrawingArea* shape_drawing

Definition at line 43 of file [conv-settings-dialog.c](#).

12.7.2.10 standalone_check

GtkWidget* standalone_check

Definition at line 42 of file [conv-settings-dialog.c](#).

12.7.2.11 unit_in_meters

double unit_in_meters

Definition at line 52 of file [conv-settings-dialog.c](#).

12.7.2.12 x_label

GtkLabel* x_label

Definition at line 44 of file [conv-settings-dialog.c](#).

12.7.2.13 x_output_label

GtkLabel* x_output_label

Definition at line 47 of file [conv-settings-dialog.c](#).

12.7.2.14 y_label

GtkLabel* y_label

Definition at line 45 of file [conv-settings-dialog.c](#).

12.7.2.15 y_output_label

GtkLabel* y_output_label

Definition at line 48 of file [conv-settings-dialog.c](#).


The documentation for this struct was generated from the following file:

- [conv-settings-dialog.c](#)

12.8 bounding_box::_vectors Struct Reference

```
#include <bounding-box.h>
```

Collaboration diagram for bounding_box::_vectors:



Data Fields

- struct [vector_2d](#) [lower_left](#)
- struct [vector_2d](#) [upper_right](#)

12.8.1 Detailed Description

Coordinate System is (y up | x right)

Definition at line 40 of file [bounding-box.h](#).

12.8.2 Field Documentation

12.8.2.1 lower_left

```
struct vector\_2d lower_left
```

Definition at line 41 of file [bounding-box.h](#).

12.8.2.2 upper_right

```
struct vector\_2d upper_right
```

Definition at line 42 of file [bounding-box.h](#).

The documentation for this struct was generated from the following file:

- [bounding-box.h](#)

12.9 application_data Struct Reference

Structure containing The GtkApplication and a list containing the GdsRenderGui objects.

Data Fields

- GtkApplication * [app](#)
- GList * [gui_list](#)

12.9.1 Detailed Description

Structure containing The GtkApplication and a list containing the GdsRenderGui objects.

Definition at line 38 of file [main.c](#).

12.9.2 Field Documentation

12.9.2.1 app

GtkApplication* app

Definition at line 39 of file [main.c](#).

12.9.2.2 gui_list

GList* gui_list

Definition at line 40 of file [main.c](#).


The documentation for this struct was generated from the following file:

- [main.c](#)

12.10 bounding_box Union Reference

```
#include <bounding-box.h>
```

Collaboration diagram for bounding_box:



Data Structures

- [struct _vectors](#)

Data Fields

- struct [bounding_box::_vectors](#) [vectors](#)
- struct [vector_2d](#) [vector_array](#) [2]

12.10.1 Detailed Description

Definition at line 38 of file [bounding-box.h](#).

12.10.2 Field Documentation

12.10.2.1 vector_array

```
struct vector\_2d vector_array[2]
```

Definition at line 44 of file [bounding-box.h](#).

12.10.2.2 vectors

```
struct bounding\_box::\_vectors vectors
```


The documentation for this union was generated from the following file:

- [bounding-box.h](#)

12.11 cairo_layer Struct Reference

The [cairo_layer](#) struct Each rendered layer is represented by this struct.

Collaboration diagram for [cairo_layer](#):



Data Fields

- `cairo_t * cr`
cairo context for layer
- `cairo_surface_t * rec`
Recording surface to hold the layer.
- struct `layer_info * linfo`
Reference to layer information.

12.11.1 Detailed Description

The `cairo_layer` struct Each rendered layer is represented by this struct.

Definition at line 41 of file `cairo-output.c`.

12.11.2 Field Documentation

12.11.2.1 `cr`

```
cairo_t* cr
```

cairo context for layer

Definition at line 42 of file `cairo-output.c`.

12.11.2.2 `linfo`

```
struct layer_info* linfo
```

Reference to layer information.

Definition at line 44 of file `cairo-output.c`.

12.11.2.3 `rec`

```
cairo_surface_t* rec
```

Recording surface to hold the layer.

Definition at line 43 of file `cairo-output.c`.

The documentation for this struct was generated from the following file:


- `cairo-output.c`

12.12 gds_cell Struct Reference

A Cell inside a [gds_library](#).

```
#include <gds-types.h>
```

Collaboration diagram for gds_cell:



Data Fields

- char `name` [CELL_NAME_MAX]
- struct `gds_time_field` `mod_time`
- struct `gds_time_field` `access_time`
- GList * `child_cells`
List of `gds_cell_instance` elements.
- GList * `graphic_objs`
List of `gds_graphics`.
- struct `gds_library` * `parent_library`
Pointer to parent library.
- struct `gds_cell_checks` `checks`
Checking results.

12.12.1 Detailed Description

A Cell inside a [gds_library](#).

Definition at line 122 of file [gds-types.h](#).

12.12.2 Field Documentation

12.12.2.1 access_time

```
struct gds_time_field access_time
```

Definition at line 125 of file [gds-types.h](#).

12.12.2.2 checks

```
struct gds_cell_checks checks
```

Checking results.

Definition at line 129 of file [gds-types.h](#).

12.12.2.3 child_cells

```
GList* child_cells
```

List of [gds_cell_instance](#) elements.

Definition at line 126 of file [gds-types.h](#).

12.12.2.4 graphic_objs

```
GList* graphic_objs
```

List of [gds_graphics](#).

Definition at line 127 of file [gds-types.h](#).

12.12.2.5 mod_time

```
struct gds_time_field mod_time
```

Definition at line 124 of file [gds-types.h](#).

12.12.2.6 name

```
char name[CELL_NAME_MAX]
```

Definition at line 123 of file [gds-types.h](#).

12.12.2.7 parent_library

```
struct gds_library* parent_library
```

Pointer to parent library.

Definition at line 128 of file [gds-types.h](#).


The documentation for this struct was generated from the following file:

- [gds-types.h](#)

12.13 gds_cell_array_instance Struct Reference

Struct representing an array instantiation.

Collaboration diagram for `gds_cell_array_instance`:



Data Fields

- char `ref_name` [`CELL_NAME_MAX`]
Name of referenced cell.
- struct `gds_cell` * `cell_ref`
Referenced `gds_cell` structure.
- struct `gds_point control_points` [3]
The three control points.
- int `flipped`
Mirror each instance on x-axis before rotation.
- double `angle`
Angle of rotation for each instance (counter clockwise) in degrees.
- double `magnification`
Magnification of each instance.
- int `columns`
Column count.
- int `rows`
Row count.

12.13.1 Detailed Description

Struct representing an array instantiation.

This struct is defined locally because it is not exposed to the outside of the parser. Array references are internally converted to a bunch of standard `gds_cell_instance` elements.

Definition at line 93 of file `gds-parser.c`.

12.13.2 Field Documentation

12.13.2.1 angle

```
double angle
```

Angle of rotation for each instance (counter clockwise) in degrees.

Definition at line 98 of file `gds-parser.c`.

12.13.2.2 cell_ref

```
struct gds_cell* cell_ref
```

Referenced `gds_cell` structure.

Definition at line 95 of file `gds-parser.c`.

12.13.2.3 columns

```
int columns
```

Column count.

Definition at line 100 of file [gds-parser.c](#).

12.13.2.4 control_points

```
struct gds_point control_points[3]
```

The three control points.

Definition at line 96 of file [gds-parser.c](#).

12.13.2.5 flipped

```
int flipped
```

Mirror each instance on x-axis before rotation.

Definition at line 97 of file [gds-parser.c](#).

12.13.2.6 magnification

```
double magnification
```

Magnification of each instance.

Definition at line 99 of file [gds-parser.c](#).

12.13.2.7 ref_name

```
char ref_name[CELL_NAME_MAX]
```

Name of referenced cell.

Definition at line 94 of file [gds-parser.c](#).

12.13.2.8 rows

```
int rows
```

Row count.

Definition at line 101 of file [gds-parser.c](#).

The documentation for this struct was generated from the following file:


- [gds-parser.c](#)

12.14 gds_cell_checks Struct Reference

Stores the result of the cell checks.

```
#include <gds-types.h>
```

Collaboration diagram for gds_cell_checks:



Data Structures

- struct [_check_internals](#)

For the internal use of the checker.

Data Fields

- int [unresolved_child_count](#)
Number of unresolved cell instances inside this cell. Default: [GDS_CELL_CHECK_NOT_RUN](#).
- int [affected_by_reference_loop](#)
1 if the cell is affected by a reference loop and therefore not renderable. Default: [GDS_CELL_CHECK_NOT_RUN](#)
- struct [gds_cell_checks::_check_internals](#) [_internal](#)

12.14.1 Detailed Description

Stores the result of the cell checks.

Definition at line 71 of file [gds-types.h](#).

12.14.2 Field Documentation

12.14.2.1 `_internal`

```
struct gds_cell_checks::_check_internals _internal
```

12.14.2.2 `affected_by_reference_loop`

```
int affected_by_reference_loop
```

1 if the cell is affected by a reference loop and therefore not renderable. Default: [GDS_CELL_CHECK_NOT_RUN](#)

Definition at line 73 of file [gds-types.h](#).

12.14.2.3 `unresolved_child_count`

```
int unresolved_child_count
```

Number of unresolved cell instances inside this cell. Default: [GDS_CELL_CHECK_NOT_RUN](#).

Definition at line 72 of file [gds-types.h](#).

The documentation for this struct was generated from the following file:


- [gds-types.h](#)

12.15 gds_cell_instance Struct Reference

This represents an instance of a cell inside another cell.

```
#include <gds-types.h>
```

Collaboration diagram for gds_cell_instance:



Data Fields

- char `ref_name` [`CELL_NAME_MAX`]
Name of referenced cell.
- struct `gds_cell * cell_ref`
Referenced `gds_cell` structure.
- struct `gds_point origin`
Origin.
- int `flipped`
Mirrored on x-axis before rotation.
- double `angle`
Angle of rotation (counter clockwise) in degrees.
- double `magnification`
magnification

12.15.1 Detailed Description

This represents an instance of a cell inside another cell.

Definition at line 110 of file `gds-types.h`.

12.15.2 Field Documentation

12.15.2.1 angle

```
double angle
```

Angle of rotation (counter clockwise) in degrees.

Definition at line 115 of file [gds-types.h](#).

12.15.2.2 cell_ref

```
struct gds_cell* cell_ref
```

Referenced [gds_cell](#) structure.

Definition at line 112 of file [gds-types.h](#).

12.15.2.3 flipped

```
int flipped
```

Mirrored on x-axis before rotation.

Definition at line 114 of file [gds-types.h](#).

12.15.2.4 magnification

```
double magnification
```

magnification

Definition at line 116 of file [gds-types.h](#).

12.15.2.5 origin

```
struct gds_point origin
```

Origin.

Definition at line 113 of file [gds-types.h](#).

12.15.2.6 ref_name

```
char ref_name[CELL_NAME_MAX]
```

Name of referenced cell.

Definition at line 111 of file [gds-types.h](#).

The documentation for this struct was generated from the following file:

- [gds-types.h](#)

12.16 gds_graphics Struct Reference

A GDS graphics object.

```
#include <gds-types.h>
```

Data Fields

- enum [graphics_type](#) [gfx_type](#)
Type of graphic.
- GList * [vertices](#)
List of [gds_point](#).
- enum [path_type](#) [path_render_type](#)
Line cap.
- int [width_absolute](#)
Width. Not used for objects other than paths.
- int16_t [layer](#)
Layer the graphic object is on.
- uint16_t [datatype](#)

12.16.1 Detailed Description

A GDS graphics object.

Definition at line 98 of file [gds-types.h](#).

12.16.2 Field Documentation

12.16.2.1 datatype

```
uint16_t datatype
```

Definition at line 104 of file [gds-types.h](#).

12.16.2.2 gfx_type

```
enum graphics_type gfx_type
```

Type of graphic.

Definition at line 99 of file [gds-types.h](#).

12.16.2.3 layer

```
int16_t layer
```

Layer the graphic object is on.

Definition at line 103 of file [gds-types.h](#).

12.16.2.4 path_render_type

```
enum path_type path_render_type
```

Line cap.

Definition at line 101 of file [gds-types.h](#).

12.16.2.5 vertices

```
GList* vertices
```

List of [gds_point](#).

Definition at line 100 of file [gds-types.h](#).

12.16.2.6 width_absolute

```
int width_absolute
```

Width. Not used for objects other than paths.

Definition at line 102 of file [gds-types.h](#).

The documentation for this struct was generated from the following file:


- [gds-types.h](#)

12.17 gds_library Struct Reference

GDS Toplevel library.

```
#include <gds-types.h>
```

Collaboration diagram for gds_library:



Data Fields

- char [name](#) [[CELL_NAME_MAX](#)]
- struct [gds_time_field](#) [mod_time](#)
- struct [gds_time_field](#) [access_time](#)
- double [unit_in_meters](#)
- GList * [cells](#)
- GList * [cell_names](#)

12.17.1 Detailed Description

GDS Toplevel library.

Definition at line [135](#) of file [gds-types.h](#).

12.17.2 Field Documentation

12.17.2.1 access_time

```
struct gds\_time\_field access\_time
```

Definition at line [138](#) of file [gds-types.h](#).

12.17.2.2 cell_names

```
GList* cell_names
```

< List of strings that contains all cell names

Definition at line 141 of file [gds-types.h](#).

12.17.2.3 cells

```
GList* cells
```

List of [gds_cell](#) that contains all cells in this library

Definition at line 140 of file [gds-types.h](#).

12.17.2.4 mod_time

```
struct gds_time_field mod_time
```

Definition at line 137 of file [gds-types.h](#).

12.17.2.5 name

```
char name[CELL_NAME_MAX]
```

Definition at line 136 of file [gds-types.h](#).

12.17.2.6 unit_in_meters

```
double unit_in_meters
```

Length of a database unit in meters

Definition at line 139 of file [gds-types.h](#).

The documentation for this struct was generated from the following file:

- [gds-types.h](#)

12.18 gds_point Struct Reference

A point in the 2D plane. Sometimes references as vertex.

```
#include <gds-types.h>
```

Data Fields

- [int x](#)
- [int y](#)

12.18.1 Detailed Description

A point in the 2D plane. Sometimes references as vertex.

Definition at line 63 of file [gds-types.h](#).

12.18.2 Field Documentation

12.18.2.1 x

```
int x
```

Definition at line 64 of file [gds-types.h](#).

12.18.2.2 y

```
int y
```

Definition at line 65 of file [gds-types.h](#).

The documentation for this struct was generated from the following file:

- [gds-types.h](#)

12.19 gds_time_field Struct Reference

Date information for cells and libraries.

```
#include <gds-types.h>
```

Data Fields

- uint16_t [year](#)
- uint16_t [month](#)
- uint16_t [day](#)
- uint16_t [hour](#)
- uint16_t [minute](#)
- uint16_t [second](#)

12.19.1 Detailed Description

Date information for cells and libraries.

Definition at line 86 of file [gds-types.h](#).

12.19.2 Field Documentation

12.19.2.1 day

uint16_t day

Definition at line 89 of file [gds-types.h](#).

12.19.2.2 hour

uint16_t hour

Definition at line 90 of file [gds-types.h](#).

12.19.2.3 minute

uint16_t minute

Definition at line 91 of file [gds-types.h](#).

12.19.2.4 month

uint16_t month

Definition at line 88 of file [gds-types.h](#).

12.19.2.5 second

```
uint16_t second
```

Definition at line 92 of file [gds-types.h](#).

12.19.2.6 year

```
uint16_t year
```

Definition at line 87 of file [gds-types.h](#).

The documentation for this struct was generated from the following file:

- [gds-types.h](#)

12.20 layer_element_dnd_data Struct Reference

This structure holds the necessary data to set up a LayerElement for Drag'n'Drop.

```
#include <layer-element.h>
```

Data Fields

- `GtkTargetEntry * entries`
Array of target entries for the DnD operation.
- `int entry_count`
Count of elements in `layer_element_dnd_data::entries` array.
- `void(* drag_begin)(GtkWidget *, GdkDragContext *, gpointer)`
Callback function for `drag_begin` event.
- `void(* drag_data_get)(GtkWidget *, GdkDragContext *, GtkSelectionData *, guint, guint, gpointer)`
Callback function for `data_get` event.
- `void(* drag_end)(GtkWidget *, GdkDragContext *, gpointer)`
Callback function for `drag_end` event.

12.20.1 Detailed Description

This structure holds the necessary data to set up a LayerElement for Drag'n'Drop.

Definition at line 63 of file [layer-element.h](#).

12.20.2 Field Documentation

12.20.2.1 drag_begin

```
void(* drag_begin) (GtkWidget *, GdkDragContext *, gpointer)
```

Callback function for drag_begin event.

Definition at line 69 of file [layer-element.h](#).

12.20.2.2 drag_data_get

```
void(* drag_data_get) (GtkWidget *, GdkDragContext *, GtkSelectionData *, guint, guint, gpointer)
```

Callback function for data_get event.

Definition at line 71 of file [layer-element.h](#).

12.20.2.3 drag_end

```
void(* drag_end) (GtkWidget *, GdkDragContext *, gpointer)
```

Callback function for drag_end event.

Definition at line 73 of file [layer-element.h](#).

12.20.2.4 entries

```
GtkTargetEntry* entries
```

Array of target entries for the DnD operation.

Definition at line 65 of file [layer-element.h](#).

12.20.2.5 entry_count

```
int entry_count
```

Count of elements in [layer_element_dnd_data::entries](#) array.

Definition at line 67 of file [layer-element.h](#).

The documentation for this struct was generated from the following file:

- [layer-element.h](#)

12.21 layer_info Struct Reference

Layer information.

```
#include <layer-info.h>
```

Data Fields

- int [layer](#)
Layer number.
- char * [name](#)
Layer name.
- int [stacked_position](#)
Position of layer in output.
- GdkRGBA [color](#)
RGBA color used to render this layer.

12.21.1 Detailed Description

Layer information.

This structs contains information on how to render a layer

Definition at line 36 of file [layer-info.h](#).

12.21.2 Field Documentation

12.21.2.1 color

```
GdkRGBA color
```

RGBA color used to render this layer.

Definition at line 41 of file [layer-info.h](#).

12.21.2.2 layer

```
int layer
```

Layer number.

Definition at line 38 of file [layer-info.h](#).

12.21.2.3 name

```
char* name
```

Layer name.

Definition at line 39 of file [layer-info.h](#).

12.21.2.4 stacked_position

```
int stacked_position
```

Position of layer in output.

Warning

This parameter is not used by any renderer so far

Note

Lower is bottom, higher is top

Definition at line 40 of file [layer-info.h](#).

The documentation for this struct was generated from the following file:

- [layer-info.h](#)

12.22 render_settings Struct Reference

This struct holds the renderer configuration.

```
#include <conv-settings-dialog.h>
```

Data Fields

- double [scale](#)
Scale image down by this factor.
- enum [output_renderer](#) [renderer](#)
- gboolean [tex_pdf_layers](#)
- gboolean [tex_standalone](#)

12.22.1 Detailed Description

This struct holds the renderer configuration.

Definition at line 56 of file [conv-settings-dialog.h](#).

12.22.2 Field Documentation

12.22.2.1 `renderer`

```
enum output_renderer renderer
```

The renderer to use

Definition at line 58 of file [conv-settings-dialog.h](#).

12.22.2.2 `scale`

```
double scale
```

Scale image down by this factor.

Note

Used to keep image in bound of maximum coordinate limit

Definition at line 57 of file [conv-settings-dialog.h](#).

12.22.2.3 `tex_pdf_layers`

```
gboolean tex_pdf_layers
```

Create OCG layers when rendering with TikZ

Definition at line 59 of file [conv-settings-dialog.h](#).

12.22.2.4 `tex_standalone`

```
gboolean tex_standalone
```

Create a standalone compile TeX file

Definition at line 60 of file [conv-settings-dialog.h](#).

The documentation for this struct was generated from the following file:

- [conv-settings-dialog.h](#)

12.23 tree_stores Struct Reference

```
#include <tree-store.h>
```

Data Fields

- GtkTreeView * [base_tree_view](#)
- GtkTreeStore * [base_store](#)
- GtkTreeModelFilter * [filter](#)
- GtkEntry * [search_entry](#)

12.23.1 Detailed Description

Definition at line 46 of file [tree-store.h](#).

12.23.2 Field Documentation

12.23.2.1 base_store

```
GtkTreeStore* base_store
```

Definition at line 48 of file [tree-store.h](#).

12.23.2.2 base_tree_view

```
GtkTreeView* base_tree_view
```

Definition at line 47 of file [tree-store.h](#).

12.23.2.3 filter

```
GtkTreeModelFilter* filter
```

Definition at line 49 of file [tree-store.h](#).

12.23.2.4 search_entry

```
GtkEntry* search_entry
```

Definition at line 50 of file [tree-store.h](#).

The documentation for this struct was generated from the following file:

- [tree-store.h](#)

12.24 vector_2d Struct Reference

```
#include <vector-operations.h>
```

Data Fields

- double [x](#)
- double [y](#)

12.24.1 Detailed Description

Definition at line 37 of file [vector-operations.h](#).

12.24.2 Field Documentation

12.24.2.1 x

```
double x
```

Definition at line 38 of file [vector-operations.h](#).

12.24.2.2 y

```
double y
```

Definition at line 39 of file [vector-operations.h](#).

The documentation for this struct was generated from the following file:

- [vector-operations.h](#)

Chapter 13


File Documentation

13.1 bounding-box.c File Reference

Calculation of bounding boxes.

```
#include <stdio.h>
#include <math.h>
#include <gds-render/geometric/bounding-box.h>
```

Include dependency graph for bounding-box.c:



Macros

- `#define MIN(a, b) (((a) < (b)) ? (a) : (b))`
Return smaller number.
- `#define MAX(a, b) (((a) > (b)) ? (a) : (b))`
Return bigger number.
- `#define ABS_DBL(a) ((a) < 0 ? -(a) : (a))`

Functions

- void `bounding_box_calculate_polygon` (`GList *vertices`, `conv_generic_to_vector_2d_t conv_func`, `union bounding_box *box`)
- void `bounding_box_update_box` (`union bounding_box *destination`, `union bounding_box *update`)
- void `bounding_box_prepare_empty` (`union bounding_box *box`)
- static void `calculate_path_miter_points` (`struct vector_2d *a`, `struct vector_2d *b`, `struct vector_2d *c`, `struct vector_2d *m1`, `struct vector_2d *m2`, `double width`)
- void `bounding_box_calculate_path_box` (`GList *vertices`, `double thickness`, `conv_generic_to_vector_2d_t conv_func`, `union bounding_box *box`)
- void `bounding_box_update_point` (`union bounding_box *destination`, `conv_generic_to_vector_2d_t conv_func`, `void *pt`)
- void `bounding_box_apply_transform` (`double scale`, `double rotation_deg`, `bool flip_at_x`, `union bounding_box *box`)

Apply transformations onto bounding box.

13.1.1 Detailed Description

Calculation of bounding boxes.

Author

Mario Hüttel mario.huettel@gmx.net

Definition in file `bounding-box.c`.

13.2 bounding-box.c

```

00001 /*
00002  * GDSII-Converter
00003  * Copyright (C) 2018 Mario Hüttel <mario.huettel@gmx.net>
00004  *
00005  * This file is part of GDSII-Converter.
00006  *
00007  * GDSII-Converter is free software: you can redistribute it and/or modify
00008  * it under the terms of the GNU General Public License version 2 as
00009  * published by the Free Software Foundation.
00010  *
00011  * GDSII-Converter is distributed in the hope that it will be useful,
00012  * but WITHOUT ANY WARRANTY; without even the implied warranty of
00013  * MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE. See the
00014  * GNU General Public License for more details.
00015  *
00016  * You should have received a copy of the GNU General Public License
00017  * along with GDSII-Converter. If not, see <http://www.gnu.org/licenses/>.
00018  */
00019
00031 #include <stdio.h>
00032 #include <math.h>
00033
00034 #include <gds-render/geometric/bounding-box.h>
00035
00036 #define MIN(a,b) (((a) < (b)) ? (a) : (b))
00037 #define MAX(a,b) (((a) > (b)) ? (a) : (b))
00038 #define ABS_DBL(a) ((a) < 0 ? -(a) : (a))
00039
00040 void bounding_box_calculate_polygon(GList *vertices,
    conv_generic_to_vector_2d_t conv_func, union
    bounding_box *box)
00041 {
00042     double xmin = DBL_MAX, xmax = -DBL_MAX, ymin = DBL_MAX, ymax = -DBL_MAX;
00043     struct vector_2d temp_vec;
00044     GList *list_item;
00045
00046     /* Check for errors */

```

```

00047     if (!conv_func || !box || !vertices)
00048         return;
00049
00050     for (list_item = vertices; list_item != NULL; list_item = g_list_next(list_item)) {
00051         /* Convert generic vertex to vector_2d */
00052         if (conv_func)
00053             conv_func((void *)list_item->data, &temp_vec);
00054         else
00055             vector_2d_copy(&temp_vec, (struct vector_2d *)list_item->data);
00056
00057         /* Update bounding coordinates with vertex */
00058         xmin = MIN(xmin, temp_vec.x);
00059         xmax = MAX(xmax, temp_vec.x);
00060         ymin = MIN(ymin, temp_vec.y);
00061         ymax = MAX(ymax, temp_vec.y);
00062     }
00063
00064     /* Fill bounding box with results */
00065     box->vectors.lower_left.x = xmin;
00066     box->vectors.lower_left.y = ymin;
00067     box->vectors.upper_right.x = xmax;
00068     box->vectors.upper_right.y = ymax;
00069 }
00070
00071 void bounding_box_update_box(union bounding_box *destination, union
    bounding_box *update)
00072 {
00073     if (!destination || !update)
00074         return;
00075
00076     destination->vectors.lower_left.x = MIN(destination->
    vectors.lower_left.x,
00077         update->vectors.lower_left.x);
00078     destination->vectors.lower_left.y = MIN(destination->
    vectors.lower_left.y,
00079         update->vectors.lower_left.y);
00080     destination->vectors.upper_right.x = MAX(destination->
    vectors.upper_right.x,
00081         update->vectors.upper_right.x);
00082     destination->vectors.upper_right.y = MAX(destination->
    vectors.upper_right.y,
00083         update->vectors.upper_right.y);
00084 }
00085
00086 void bounding_box_prepare_empty(union bounding_box *box)
00087 {
00088     box->vectors.lower_left.x = DBL_MAX;
00089     box->vectors.lower_left.y = DBL_MAX;
00090     box->vectors.upper_right.x = -DBL_MAX;
00091     box->vectors.upper_right.y = -DBL_MAX;
00092 }
00093
00094 static void calculate_path_miter_points(struct
    vector_2d *a, struct vector_2d *b, struct vector_2d *c,
    struct vector_2d *m1, struct vector_2d *m2, double width)
00095 {
00096     double angle, angle_sin, u;
00097     struct vector_2d ba, bc, u_vec, v_vec, ba_norm;
00098
00099     if (!a || !b || !c || !m1 || !m2)
00100         return;
00101
00102     vector_2d_subtract(&ba, a, b);
00103     vector_2d_subtract(&bc, c, b);
00104
00105     angle = vector_2d_calculate_angle_between(&ba, &bc);
00106
00107     if (ABS_DBL(angle) < 0.05 || ABS_DBL(angle - M_PI) < 0.1) {
00108         /* Special cases Don*/
00109         vector_2d_copy(&ba_norm, &ba);
00110         vector_2d_rotate(&ba_norm, DEG2RAD(90));
00111         vector_2d_normalize(&ba_norm);
00112         vector_2d_scale(&ba_norm, width/2.0);
00113         vector_2d_add(m1, b, &ba_norm);
00114         vector_2d_subtract(m2, b, &ba_norm);
00115         return;
00116     }
00117     angle_sin = sin(angle);
00118     u = width/(2*angle_sin);
00119
00120     vector_2d_copy(&u_vec, &ba);
00121     vector_2d_copy(&v_vec, &bc);
00122     vector_2d_normalize(&u_vec);
00123     vector_2d_normalize(&v_vec);
00124     vector_2d_scale(&u_vec, u);
00125     vector_2d_scale(&v_vec, u);
00126 }
00127

```

```

00128     vector_2d_copy(m1, b);
00129     vector_2d_add(m1, m1, &u_vec);
00130     vector_2d_add(m1, m1, &v_vec);
00131
00132     vector_2d_copy(m2, b);
00133     vector_2d_subtract(m2, m2, &u_vec);
00134     vector_2d_subtract(m2, m2, &v_vec);
00135 }
00136
00137 void bounding_box_calculate_path_box(GList *vertices, double thickness,
00138     conv_generic_to_vector_2d_t conv_func, union
    bounding_box *box)
00139 {
00140     GList *vertex_iterator;
00141     struct vector_2d pt;
00142
00143     printf("Warning! Function bounding_box_calculate_path_box not yet implemented correctly!\n");
00144
00145     if (!vertices || !box)
00146         return;
00147
00148     for (vertex_iterator = vertices; vertex_iterator != NULL; vertex_iterator = g_list_next(vertex_iterator
    )) {
00149
00150         if (conv_func != NULL)
00151             conv_func(vertex_iterator->data, &pt);
00152         else
00153             (void)vector_2d_copy(&pt, (struct vector_2d *)vertex_iterator->data);
00154
00155         /* These are approximations.
00156          * Used as long as miter point calculation is not fully implemented
00157          */
00158         box->vectors.lower_left.x = MIN(box->vectors.
    lower_left.x, pt.x - thickness/2);
00159         box->vectors.lower_left.y = MIN(box->vectors.
    lower_left.y, pt.y - thickness/2);
00160         box->vectors.upper_right.x = MAX(box->vectors.
    upper_right.x, pt.x + thickness/2);
00161         box->vectors.upper_right.y = MAX(box->vectors.
    upper_right.y, pt.y + thickness/2);
00162     }
00163 }
00164
00165 void bounding_box_update_point(union bounding_box *destination,
    conv_generic_to_vector_2d_t conv_func, void *pt)
00166 {
00167     struct vector_2d point;
00168
00169     if (!destination || !pt)
00170         return;
00171
00172     if (conv_func)
00173         conv_func(pt, &point);
00174     else
00175         (void)vector_2d_copy(&point, (struct vector_2d *)pt);
00176
00177     destination->vectors.lower_left.x = MIN(destination->
    vectors.lower_left.x, point.x);
00178     destination->vectors.lower_left.y = MIN(destination->
    vectors.lower_left.y, point.y);
00179     destination->vectors.upper_right.x = MAX(destination->
    vectors.upper_right.x, point.x);
00180     destination->vectors.upper_right.y = MAX(destination->
    vectors.upper_right.y, point.y);
00181 }
00182
00190 void bounding_box_apply_transform(double scale, double rotation_deg, bool
    flip_at_x, union bounding_box *box)
00191 {
00192     int i;
00193
00194     /* Due to linearity, the order of the operations does not matter.
00195      * flip must be applied before rotation as defined by the GDS format
00196      */
00197     for (i = 0; i < 2; i++) {
00198         box->vector_array[i].y *= (flip_at_x ? -1 : 1);
00199         vector_2d_rotate(&box->vector_array[i], rotation_deg * M_PI / 180);
00200         vector_2d_scale(&box->vector_array[i], scale);
00201     }
00202 }
00203


```

13.3 bounding-box.h File Reference


Header for calculation of bounding boxes.

```
#include <glib.h>
#include <gds-render/geometric/vector-operations.h>
#include <stdbool.h>
```

Include dependency graph for bounding-box.h:



This graph shows which files directly or indirectly include this file:



Data Structures

- union [bounding_box](#)
- struct [bounding_box::_vectors](#)

Typedefs

- typedef void(* [conv_generic_to_vector_2d_t](#)) (void *, struct [vector_2d](#) *)

Functions

- void [bounding_box_calculate_polygon](#) (GList *vertices, [conv_generic_to_vector_2d_t](#) conv_func, union [bounding_box](#) *box)
- void [bounding_box_update_box](#) (union [bounding_box](#) *destination, union [bounding_box](#) *update)
- void [bounding_box_prepare_empty](#) (union [bounding_box](#) *box)
- void [bounding_box_update_point](#) (union [bounding_box](#) *destination, [conv_generic_to_vector_2d_t](#) conv_func, void *pt)
- void [bounding_box_apply_transform](#) (double scale, double rotation_deg, bool flip_at_x, union [bounding_box](#) *box)
 - Apply transformations onto bounding box.*
- void [bounding_box_calculate_path_box](#) (GList *vertices, double thickness, [conv_generic_to_vector_2d_t](#) conv_func, union [bounding_box](#) *box)

13.3.1 Detailed Description

Header for calculation of bounding boxes.

Author

Mario Hüttel mario.huettel@gmx.net

Definition in file [bounding-box.h](#).

13.4 bounding-box.h

```

00001 /*
00002  * GDSII-Converter
00003  * Copyright (C) 2018 Mario Hüttel <mario.huettel@gmx.net>
00004  *
00005  * This file is part of GDSII-Converter.
00006  *
00007  * GDSII-Converter is free software: you can redistribute it and/or modify
00008  * it under the terms of the GNU General Public License version 2 as
00009  * published by the Free Software Foundation.
00010  *
00011  * GDSII-Converter is distributed in the hope that it will be useful,
00012  * but WITHOUT ANY WARRANTY; without even the implied warranty of
00013  * MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE. See the
00014  * GNU General Public License for more details.
00015  *
00016  * You should have received a copy of the GNU General Public License
00017  * along with GDSII-Converter. If not, see <http://www.gnu.org/licenses/>.
00018  */
00019
00031 #ifndef _BOUNDING_BOX_H_
00032 #define _BOUNDING_BOX_H_
00033
00034 #include <glib.h>
00035 #include <gds-render/geometric/vector-operations.h>
00036 #include <stdbool.h>
00037
00038 union bounding_box {
00040     struct _vectors {
00041         struct vector_2d lower_left;
00042         struct vector_2d upper_right;
00043     } vectors;
00044     struct vector_2d vector_array[2];

```



```

00045 };
00046
00047 typedef void (*conv_generic_to_vector_2d_t)(void *, struct
vector_2d *);
00048
00049 void bounding_box_calculate_polygon(GList *vertices,
conv_generic_to_vector_2d_t conv_func, union
bounding_box *box);
00050 void bounding_box_update_box(union bounding_box *destination, union
bounding_box *update);
00051 void bounding_box_prepare_empty(union bounding_box *box);
00052 void bounding_box_update_point(union bounding_box *destination,
conv_generic_to_vector_2d_t conv_func, void *pt);
00053 void bounding_box_apply_transform(double scale, double rotation_deg, bool
flip_at_x, union bounding_box *box);
00054 void bounding_box_calculate_path_box(GList *vertices, double thickness,
conv_generic_to_vector_2d_t conv_func, union
bounding_box *box);
00055
00056 #endif /* _BOUNTING_BOX_H_ */
00057

```

13.5 cairo-output.c File Reference


Output renderer for Cairo PDF export.

```

#include <math.h>
#include <stdlib.h>
#include <cairo.h>
#include <cairo-pdf.h>
#include <cairo-svg.h>
#include <gds-render/cairo-renderer/cairo-output.h>

```

Include dependency graph for cairo-output.c:



Data Structures

- struct [cairo_layer](#)

The [cairo_layer](#) struct Each rendered layer is represented by this struct.

Functions

- static void [revert_inherited_transform](#) (struct [cairo_layer](#) *layers)

Revert the last transformation on all layers.

- static void `apply_inherited_transform_to_all_layers` (struct `cairo_layer` *layers, const struct `gds_point` *origin, double magnification, gboolean flipping, double rotation, double scale)
Applies transformation to all layers.
- static void `render_cell` (struct `gds_cell` *cell, struct `cairo_layer` *layers, double scale)
render_cell Render a cell with its sub-cells
- void `cairo_render_cell_to_vector_file` (struct `gds_cell` *cell, GList *layer_infos, char *pdf_file, char *svg_file, double scale)
Render cell to a PDF file specified by pdf_file.

13.5.1 Detailed Description

Output renderer for Cairo PDF export.

Author

Mario Hüttel mario.huettel@gmx.net

Definition in file `cairo-output.c`.

13.6 cairo-output.c

```

00001 /*
00002  * GDSII-Converter
00003  * Copyright (C) 2018 Mario Hüttel <mario.huettel@gmx.net>
00004  *
00005  * This file is part of GDSII-Converter.
00006  *
00007  * GDSII-Converter is free software: you can redistribute it and/or modify
00008  * it under the terms of the GNU General Public License version 2 as
00009  * published by the Free Software Foundation.
00010  *
00011  * GDSII-Converter is distributed in the hope that it will be useful,
00012  * but WITHOUT ANY WARRANTY; without even the implied warranty of
00013  * MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE. See the
00014  * GNU General Public License for more details.
00015  *
00016  * You should have received a copy of the GNU General Public License
00017  * along with GDSII-Converter. If not, see <http://www.gnu.org/licenses/>.
00018  */
00029 #include <math.h>
00030 #include <stdlib.h>
00031 #include <cairo.h>
00032 #include <cairo-pdf.h>
00033 #include <cairo-svg.h>
00034
00035 #include <gds-render/cairo-renderer/cairo-output.h>
00036
00041 struct cairo_layer {
00042     cairo_t *cr;
00043     cairo_surface_t *rec;
00044     struct layer_info *linfo;
00045 };
00046
00051 static void revert_inherited_transform(struct
00052     cairo_layer *layers)
00053 {
00054     int i;
00055     for (i = 0; i < MAX_LAYERS; i++) {
00056         if (layers[i].cr == NULL)
00057             continue;
00058         cairo_restore(layers[i].cr);
00059     }
00060 }
00061
00071 static void apply_inherited_transform_to_all_layers(struct
00072     cairo_layer *layers,
00073     const struct gds_point *origin,

```

```

00073             double magnification,
00074             gboolean flipping,
00075             double rotation,
00076             double scale)
00077 {
00078     int i;
00079     cairo_t *temp_layer_cr;
00080
00081     for (i = 0; i < MAX_LAYERS; i++) {
00082         temp_layer_cr = layers[i].cr;
00083         if (temp_layer_cr == NULL)
00084             continue;
00085
00086         /* Save the state and apply transformation */
00087         cairo_save(temp_layer_cr);
00088         cairo_translate(temp_layer_cr, (double)origin->x/scale, (double)origin->
00089 y/scale);
00089         cairo_rotate(temp_layer_cr, M_PI*rotation/180.0);
00090         cairo_scale(temp_layer_cr, magnification,
00091             (flipping == TRUE ? -magnification : magnification));
00092     }
00093 }
00094
00101 static void render_cell(struct gds_cell *cell, struct
00102 cairo_layer *layers, double scale)
00103 {
00104     GList *instance_list;
00105     struct gds_cell *temp_cell;
00106     struct gds_cell_instance *cell_instance;
00107     GList *gfx_list;
00108     struct gds_graphics *gfx;
00109     GList *vertex_list;
00110     struct gds_point *vertex;
00111     cairo_t *cr;
00112
00113     /* Render child cells */
00114     for (instance_list = cell->child_cells; instance_list != NULL; instance_list = instance_list
00115 ->next) {
00116         cell_instance = (struct gds_cell_instance *)instance_list->data;
00117         if ((temp_cell = cell_instance->cell_ref) != NULL) {
00118             apply_inherited_transform_to_all_layers(layers,
00119                 &cell_instance->origin,
00120                 cell_instance->magnification,
00121                 cell_instance->flipped,
00122                 cell_instance->angle,
00123                 scale);
00124             render_cell(temp_cell, layers, scale);
00125             revert_inherited_transform(layers);
00126         }
00127     }
00128
00129     /* Render graphics */
00130     for (gfx_list = cell->graphic_objs; gfx_list != NULL; gfx_list = gfx_list->next) {
00131         gfx = (struct gds_graphics *)gfx_list->data;
00132
00133         /* Get layer renderer */
00134         if (gfx->layer >= MAX_LAYERS)
00135             continue;
00136         if ((cr = layers[gfx->layer].cr) == NULL)
00137             continue;
00138
00139         /* Apply settings */
00140         cairo_set_line_width(cr, (gfx->width_absolute ? gfx->
00141 width_absolute/scale : 1));
00142
00143         switch (gfx->path_render_type) {
00144             case PATH_FLUSH:
00145                 cairo_set_line_cap(cr, CAIRO_LINE_CAP_BUTT);
00146                 break;
00147             case PATH_ROUNDED:
00148                 cairo_set_line_cap(cr, CAIRO_LINE_CAP_ROUND);
00149                 break;
00150             case PATH_SQUARED:
00151                 cairo_set_line_cap(cr, CAIRO_LINE_CAP_SQUARE);
00152                 break;
00153         }
00154
00155         /* Add vertices */
00156         for (vertex_list = gfx->vertices; vertex_list != NULL; vertex_list = vertex_list->next) {
00157             vertex = (struct gds_point *)vertex_list->data;
00158
00159             /* If first point -> move to, else line to */
00160             if (vertex_list->prev == NULL)
00161                 cairo_move_to(cr, vertex->x/scale, vertex->y/scale);
00162             else
00163                 cairo_line_to(cr, vertex->x/scale, vertex->y/scale);
00164         }
00165     }
00166 }

```

```

00162     }
00163
00164     /* Create graphics object */
00165     switch (gfx->gfx_type) {
00166     case GRAPHIC_PATH:
00167         cairo_stroke(cr);
00168         break;
00169     case GRAPHIC_BOX:
00170     case GRAPHIC_POLYGON:
00171         cairo_set_line_width(cr, 0.1/scale);
00172         cairo_close_path(cr);
00173         cairo_stroke_preserve(cr); // Prevent graphic glitches
00174         cairo_fill(cr);
00175         break;
00176     }
00177
00178     }
00179
00180 }
00181
00182 void cairo_render_cell_to_vector_file(struct
gds_cell *cell, GList *layer_infos, char *pdf_file, char *svg_file, double scale)
00183 {
00184     cairo_surface_t *pdf_surface, *svg_surface;
00185     cairo_t *pdf_cr, *svg_cr;
00186     struct layer_info *linfo;
00187     struct cairo_layer *layers;
00188     struct cairo_layer *lay;
00189     GList *info_list;
00190     int i;
00191     double rec_x0, rec_y0, rec_width, rec_height;
00192     double xmin = INT32_MAX, xmax = INT32_MIN, ymin = INT32_MAX, ymax = INT32_MIN;
00193
00194     if (pdf_file == NULL && svg_file == NULL) {
00195         /* No output specified */
00196         return;
00197     }
00198
00199     layers = (struct cairo_layer *)calloc(MAX_LAYERS, sizeof(struct
cairo_layer));
00200
00201     /* Clear layers */
00202     for (i = 0; i < MAX_LAYERS; i++) {
00203         layers[i].cr = NULL;
00204         layers[i].rec = NULL;
00205     }
00206
00207     /* Create recording surface for each layer */
00208     for (info_list = layer_infos; info_list != NULL; info_list = g_list_next(info_list)) {
00209         linfo = (struct layer_info *)info_list->data;
00210         if (linfo->layer < MAX_LAYERS) {
00211             lay = &(layers[(unsigned int)linfo->layer]);
00212             lay->linfo = linfo;
00213             lay->rec = cairo_recording_surface_create(CAIRO_CONTENT_COLOR_ALPHA,
NULL);
00214             lay->cr = cairo_create(layers[(unsigned int)linfo->layer].rec);
00215             cairo_scale(lay->cr, 1, -1); // Fix coordinate system
00216             cairo_set_source_rgb(lay->cr, linfo->color.red, linfo->color.green, linfo->
color.blue);
00217         } else {
00218             printf("Layer number (%d) too high!\n", linfo->layer);
00219             goto ret_clear_layers;
00220         }
00221     }
00222 }
00223
00224
00225 render_cell(cell, layers, scale);
00226
00227 /* get size of image and top left coordinate */
00228 for (info_list = layer_infos; info_list != NULL; info_list = g_list_next(info_list)) {
00229     linfo = (struct layer_info *)info_list->data;
00230
00231     if (linfo->layer >= MAX_LAYERS) {
00232         printf("Layer outside of Spec.\n");
00233         continue;
00234     }
00235
00236     /* Print size */
00237     cairo_recording_surface_ink_extents(layers[linfo->layer].rec, &rec_x0, &rec_y0,
&rec_width, &rec_height);
00238     printf("Size of layer %d%s%s%s: <%lf x %lf> @ (%lf | %lf)\n",
linfo->layer,
(linfo->name && linfo->name[0] ? " (" : ""),
(linfo->name && linfo->name[0] ? linfo->name : ""),
(linfo->name && linfo->name[0] ? ")" : ""),
rec_width, rec_height, rec_x0, rec_y0);
00244
00245

```

```

00246     /* update bounding box */
00247     xmin = MIN(xmin, rec_x0);
00248     xmax = MAX(xmax, rec_x0);
00249     ymin = MIN(ymin, rec_y0);
00250     ymax = MAX(ymax, rec_y0);
00251     xmin = MIN(xmin, rec_x0+rec_width);
00252     xmax = MAX(xmax, rec_x0+rec_width);
00253     ymin = MIN(ymin, rec_y0+rec_height);
00254     ymax = MAX(ymax, rec_y0+rec_height);
00255
00256 }
00257
00258 printf("Cell bounding box: (%lf | %lf) -- (%lf | %lf)\n", xmin, ymin, xmax, ymax);
00259
00260 if (pdf_file) {
00261     pdf_surface = cairo_pdf_surface_create(pdf_file, xmax-xmin, ymax-ymin);
00262     pdf_cr = cairo_create(pdf_surface);
00263 }
00264
00265 if (svg_file) {
00266     svg_surface = cairo_svg_surface_create(svg_file, xmax-xmin, ymax-ymin);
00267     svg_cr = cairo_create(svg_surface);
00268 }
00269
00270 /* Write layers to PDF */
00271 for (info_list = layer_infos; info_list != NULL; info_list = g_list_next(info_list)) {
00272     linfo = (struct layer_info *)info_list->data;
00273
00274     if (linfo->layer >= MAX_LAYERS) {
00275         printf("Layer outside of Spec.\n");
00276         continue;
00277     }
00278
00279     if (pdf_file) {
00280         cairo_set_source_surface(pdf_cr, layers[linfo->layer].rec, -xmin, -ymin);
00281         cairo_paint_with_alpha(pdf_cr, linfo->color.alpha);
00282     }
00283
00284     if (svg_file) {
00285         cairo_set_source_surface(svg_cr, layers[linfo->layer].rec, -xmin, -ymin);
00286         cairo_paint_with_alpha(svg_cr, linfo->color.alpha);
00287     }
00288
00289 }
00290
00291 if (pdf_file) {
00292     cairo_show_page(pdf_cr);
00293     cairo_destroy(pdf_cr);
00294     cairo_surface_destroy(pdf_surface);
00295 }
00296
00297 if (svg_file) {
00298     cairo_show_page(svg_cr);
00299     cairo_destroy(svg_cr);
00300     cairo_surface_destroy(svg_surface);
00301 }
00302
00303 ret_clear_layers:
00304 for (i = 0; i < MAX_LAYERS; i++) {
00305     lay = &layers[i];
00306     if (lay->cr) {
00307         cairo_destroy(lay->cr);
00308         cairo_surface_destroy(lay->rec);
00309     }
00310 }
00311 free(layers);
00312
00313 printf("cairo export finished. It might still be buggy!\n");
00314 }
00315

```

13.7 cairo-output.h File Reference


Header File for Cairo output renderer.

```


#include <gds-render/gds-utils/gds-types.h>
#include <gds-render/layer/layer-info.h>

```

Include dependency graph for cairo-output.h:



This graph shows which files directly or indirectly include this file:



Macros

- `#define MAX_LAYERS (300)`

Maximum layer count the output renderer can process. Typically GDS only specifies up to 255 layers.

Functions

- `void cairo_render_cell_to_vector_file (struct gds_cell *cell, GList *layer_infos, char *pdf_file, char *svg_file, double scale)`

Render cell to a PDF file specified by pdf_file.

13.7.1 Detailed Description

Header File for Cairo output renderer.

Author

Mario Hüttel mario.huettel@gmx.net

Definition in file [cairo-output.h](#).

13.8 cairo-output.h

```

00001 /*
00002  * GDSII-Converter
00003  * Copyright (C) 2018 Mario Hüttel <mario.huettel@gmx.net>
00004  *
00005  * This file is part of GDSII-Converter.
00006  *
00007  * GDSII-Converter is free software: you can redistribute it and/or modify
00008  * it under the terms of the GNU General Public License version 2 as
00009  * published by the Free Software Foundation.
00010  *
00011  * GDSII-Converter is distributed in the hope that it will be useful,
00012  * but WITHOUT ANY WARRANTY; without even the implied warranty of
00013  * MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE. See the
00014  * GNU General Public License for more details.
00015  *
00016  * You should have received a copy of the GNU General Public License
00017  * along with GDSII-Converter. If not, see <http://www.gnu.org/licenses/>.
00018  */
00024 #ifndef _CAIRO_OUTPUT_H_
00025 #define _CAIRO_OUTPUT_H_
00026
00027 #include <gds-render/gds-utils/gds-types.h>
00028 #include <gds-render/layer/layer-info.h>
00029
00034 #define MAX_LAYERS (300)
00044 void cairo_render_cell_to_vector_file(struct gds_cell *cell, GList *layer_infos, char *pdf_file, char
    *svg_file, double scale);
00045
00048 #endif /* _CAIRO_OUTPUT_H_ */

```

13.9 cairo-renderer.dox File Reference

13.10 cell-geometrics.c File Reference


Calculation of [gds_cell](#) trigonometrics.

```

#include <math.h>
#include <gds-render/geometric/cell-geometrics.h>

```

Include dependency graph for `cell-geometrics.c`:



Functions

- static void `convert_gds_point_to_2d_vector` (struct `gds_point` *pt, struct `vector_2d` *vector)
- static void `update_box_with_gfx` (union `bounding_box` *box, struct `gds_graphics` *gfx)

Update the given bounding box with the bounding box of a graphics element.
- void `calculate_cell_bounding_box` (union `bounding_box` *box, struct `gds_cell` *cell)

calculate_cell_bounding_box Calculate bounding box of gds cell

13.10.1 Detailed Description

Calculation of `gds_cell` trigonometrics.

Author

Mario Hüttel mario.huettel@gmx.net

Definition in file `cell-geometrics.c`.

13.11 cell-geometrics.c

```

00001 /*
00002  * GDSII-Converter
00003  * Copyright (C) 2018 Mario Hüttel <mario.huettel@gmx.net>
00004  *
00005  * This file is part of GDSII-Converter.
00006  *
00007  * GDSII-Converter is free software: you can redistribute it and/or modify
00008  * it under the terms of the GNU General Public License version 2 as
00009  * published by the Free Software Foundation.
00010  *
00011  * GDSII-Converter is distributed in the hope that it will be useful,
00012  * but WITHOUT ANY WARRANTY; without even the implied warranty of
00013  * MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE. See the
00014  * GNU General Public License for more details.
00015  *
00016  * You should have received a copy of the GNU General Public License
00017  * along with GDSII-Converter. If not, see <http://www.gnu.org/licenses/>.
00018  */
00019
00026 #include <math.h>
00027
00028 #include <gds-render/geometric/cell-geometrics.h>
00029
00035 static void convert_gds_point_to_2d_vector(struct
gds_point *pt, struct vector_2d *vector)
00036 {
00037     vector->x = pt->x;
00038     vector->y = pt->y;
00039 }
00040
00046 static void update_box_with_gfx(union bounding_box *box, struct
gds_graphics *gfx)
00047 {
00048     union bounding_box current_box;
00049
00050     bounding_box_prepare_empty(&current_box);
00051
00052     switch (gfx->gfx_type) {
00053     case GRAPHIC_BOX:
00054         /* Expected fallthrough */
00055     case GRAPHIC_POLYGON:
00056         bounding_box_calculate_polygon(gfx->
vertices,
00057                                     (conv_generic_to_vector_2d_t)&
convert_gds_point_to_2d_vector,
00058                                     &current_box);
00059         break;
00060     case GRAPHIC_PATH:
00061         /*
00062          * This is not implemented correctly.
00063          * Please be aware if paths are the outmost elements of your cell.
00064          * You might end up with a completely wrong calculated cell size.
00065          */
00066         bounding_box_calculate_path_box(gfx->
vertices, gfx->width_absolute,
00067                                     (conv_generic_to_vector_2d_t)&
convert_gds_point_to_2d_vector,
00068                                     &current_box);
00069         break;
00070     default:
00071         /* Unknown graphics object. */
00072         /* Print error? Nah.. */
00073         break;
00074     }
00075
00076     /* Update box with results */
00077     bounding_box_update_box(box, &current_box);
00078 }
00079
00080 void calculate_cell_bounding_box(union bounding_box *box, struct
gds_cell *cell)
00081 {
00082     GList *gfx_list;
00083     struct gds_graphics *gfx;
00084     GList *sub_cell_list;
00085     struct gds_cell_instance *sub_cell;
00086     union bounding_box temp_box;
00087
00088     if (!box || !cell)
00089         return;
00090
00091     /* Update box with graphic elements */
00092     for (gfx_list = cell->graphic_objs; gfx_list != NULL; gfx_list = gfx_list->next) {
00093         gfx = (struct gds_graphics *)gfx_list->data;

```

```

00094     update_box_with_gfx(box, gfx);
00095 }
00096
00097 /* Update bounding box with boxes of subcells */
00098 for (sub_cell_list = cell->child_cells; sub_cell_list != NULL;
00099     sub_cell_list = sub_cell_list->next) {
00100     sub_cell = (struct gds_cell_instance *)sub_cell_list->data;
00101     bounding_box_prepare_empty(&temp_box);
00102     /* Recursion Woohoo!! This dies if your GDS is faulty and contains a reference loop */
00103     calculate_cell_bounding_box(&temp_box, sub_cell->
cell_ref);
00104
00105     /* Apply transformations */
00106     bounding_box_apply_transform(ABS(sub_cell->
magnification), sub_cell->angle,
00107                               sub_cell->flipped, &temp_box);
00108
00109     /* Move bounding box to origin */
00110     temp_box.vectors.lower_left.x += sub_cell->origin.
x;
00111     temp_box.vectors.upper_right.x += sub_cell->origin.
x;
00112     temp_box.vectors.lower_left.y += sub_cell->origin.
y;
00113     temp_box.vectors.upper_right.y += sub_cell->origin.
y;
00114
00115     /* update the parent's box */
00116     bounding_box_update_box(box, &temp_box);
00117 }
00118 }
00119

```

13.12 cell-geometrics.h File Reference


Calculation of `gds_cell` geometrics.

```


#include <gds-render/geometric/bounding-box.h>
#include <gds-render/gds-utils/gds-types.h>

```

Include dependency graph for cell-geometrics.h:



This graph shows which files directly or indirectly include this file:



Functions

- void `calculate_cell_bounding_box` (union `bounding_box` *box, struct `gds_cell` *cell)
calculate_cell_bounding_box Calculate bounding box of gds cell

13.12.1 Detailed Description

Calculation of `gds_cell` geometrics.

Author

Mario Hüttel mario.huettel@gmx.net

Definition in file [cell-geometrics.h](#).

13.13 cell-geometrics.h


```

00001 /*
00002  * GDSII-Converter
00003  * Copyright (C) 2018 Mario Hüttel <mario.huettel@gmx.net>
00004  *
00005  * This file is part of GDSII-Converter.
00006  *
00007  * GDSII-Converter is free software: you can redistribute it and/or modify
00008  * it under the terms of the GNU General Public License version 2 as
00009  * published by the Free Software Foundation.
00010  *
00011  * GDSII-Converter is distributed in the hope that it will be useful,
00012  * but WITHOUT ANY WARRANTY; without even the implied warranty of
00013  * MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE. See the
00014  * GNU General Public License for more details.
00015  *
00016  * You should have received a copy of the GNU General Public License
00017  * along with GDSII-Converter. If not, see <http://www.gnu.org/licenses/>.
00018  */
00019
00031 #ifndef _CELL_GEOMETRICS_H_
00032 #define _CELL_GEOMETRICS_H_
00033
00034 #include <gds-render/geometric/bounding-box.h>
00035 #include <gds-render/gds-utils/gds-types.h>
00036
00043 void calculate_cell_bounding_box(union bounding_box *box, struct
    gds_cell *cell);
00044
00045 #endif /* _CELL_GEOMETRICS_H_ */
00046
  
```

13.14 command-line.c File Reference

Function to render according to command line parameters.

```
#include <stdio.h>
#include <gds-render/command-line.h>
#include <gds-render/gds-utils/gds-parser.h>
#include <gds-render/layer/mapping-parser.h>
#include <gds-render/layer/layer-info.h>
#include <gds-render/cairo-renderer/cairo-output.h>
#include <gds-render/latex-renderer/latex-output.h>
#include <gds-render/external-renderer.h>
#include <gds-render/gds-utils/gds-tree-checker.h>
Include dependency graph for command-line.c:
```



Functions

- static void [delete_layer_info_with_name](#) (struct [layer_info](#) *info)

Delete [layer_info](#) and free nem element.
- void [command_line_convert_gds](#) (char *gds_name, char *pdf_name, char *tex_name, gboolean pdf, gboolean tex, char *layer_file, char *cell_name, double scale, gboolean pdf_layers, gboolean pdf_↔standalone, gboolean svg, char *svg_name, char *so_name, char *so_out_file)

Convert GDS according to supplied parameters.

13.14.1 Detailed Description

Function to render according to command line parameters.

Author

Mario Hüttel mario.huettel@gmx.net

Definition in file [command-line.c](#).

13.15 command-line.c

```

00001 /*
00002  * GDSII-Converter
00003  * Copyright (C) 2018 Mario Hüttel <mario.huettel@gmx.net>
00004  *
00005  * This file is part of GDSII-Converter.
00006  *
00007  * GDSII-Converter is free software: you can redistribute it and/or modify
00008  * it under the terms of the GNU General Public License version 2 as
00009  * published by the Free Software Foundation.
00010  *
00011  * GDSII-Converter is distributed in the hope that it will be useful,
00012  * but WITHOUT ANY WARRANTY; without even the implied warranty of
00013  * MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE. See the
00014  * GNU General Public License for more details.
00015  *
00016  * You should have received a copy of the GNU General Public License
00017  * along with GDSII-Converter. If not, see <http://www.gnu.org/licenses/>.
00018  */
00019
00031 #include <stdio.h>
00032
00033 #include <gds-render/command-line.h>
00034 #include <gds-render/gds-utils/gds-parser.h>
00035 #include <gds-render/layer/mapping-parser.h>
00036 #include <gds-render/layer/layer-info.h>
00037 #include <gds-render/cairo-renderer/cairo-output.h>
00038 #include <gds-render/latex-renderer/latex-output.h>
00039 #include <gds-render/external-renderer.h>
00040 #include <gds-render/gds-utils/gds-tree-checker.h>
00041
00049 static void delete_layer_info_with_name(struct
layer_info *info)
00050 {
00051     if (info) {
00052         if (info->name)
00053             g_free(info->name);
00054         free(info);
00055     }
00056 }
00057
00058 void command_line_convert_gds(char *gds_name, char *pdf_name, char *tex_name,
gboolean pdf, gboolean tex,
00059     char *layer_file, char *cell_name, double scale, gboolean pdf_layers,
00060     gboolean pdf_standalone, gboolean svg, char *svg_name, char *so_name, char *so_out_file)
00061 {
00062     GList *libs = NULL;
00063     FILE *tex_file;
00064     int res;
00065     GFile *file;
00066     int i;
00067     GFileInputStream *stream;
00068     GDataInputStream *dstream;
00069     gboolean layer_export;
00070     GdkRGBA layer_color;
00071     int layer;
00072     char *layer_name;
00073     GList *layer_info_list = NULL;
00074     GList *cell_list;
00075     struct layer_info *linfo_temp;
00076     struct gds_library *first_lib;
00077     struct gds_cell *toplevel_cell = NULL, *temp_cell;
00078
00079
00080     /* Check if parameters are valid */
00081     if (!gds_name || (!pdf_name && pdf) || (!tex_name && tex) || !layer_file || !cell_name) {
00082         printf("Probably missing argument. Check --help option\n");
00083         return;
00084     }
00085
00086     /* Load GDS */
00087     clear_lib_list(&libs);
00088     res = parse_gds_from_file(gds_name, &libs);
00089     if (res)
00090         goto ret_destroy_library_list;
00091
00092     file = g_file_new_for_path(layer_file);
00093     stream = g_file_read(file, NULL, NULL);
00094
00095     if (!stream) {
00096         printf("Layer mapping not readable!\n");
00097         goto ret_destroy_file;
00098     }
00099     dstream = g_data_input_stream_new(G_INPUT_STREAM(stream));
00100     i = 0;

```

```

00101     do {
00102         res = mapping_parser_load_line(dstream, &layer_export, &layer_name, &layer,
&layer_color);
00103         if (res == 0) {
00104             if (!layer_export)
00105                 continue;
00106             linfo_temp = (struct layer_info *)malloc(sizeof(struct
layer_info));
00107             if (!linfo_temp) {
00108                 printf("Out of memory\n");
00109                 goto ret_clear_layer_list;
00110             }
00111             linfo_temp->color.alpha = layer_color.alpha;
00112             linfo_temp->color.red = layer_color.red;
00113             linfo_temp->color.green = layer_color.green;
00114             linfo_temp->color.blue = layer_color.blue;
00115             linfo_temp->name = layer_name;
00116             linfo_temp->stacked_position = i++;
00117             linfo_temp->layer = layer;
00118             layer_info_list = g_list_append(layer_info_list, (gpointer)linfo_temp);
00119         }
00120     } while(res >= 0);
00121
00122
00123     /* find_cell in first library. */
00124     if (!libs)
00125         goto ret_clear_layer_list;
00126
00127     first_lib = (struct gds_library *)libs->data;
00128     if (!first_lib) {
00129         fprintf(stderr, "No library in library list. This should not happen.\n");
00130         goto ret_clear_layer_list;
00131     }
00132
00133     for (cell_list = first_lib->cells; cell_list != NULL; cell_list = g_list_next(cell_list)) {
00134         temp_cell = (struct gds_cell *)cell_list->data;
00135         if (!strcmp(temp_cell->name, cell_name)) {
00136             toplevel_cell = temp_cell;
00137             break;
00138         }
00139     }
00140
00141     if (!toplevel_cell) {
00142         printf("Couldn't find cell in first library!\n");
00143         goto ret_clear_layer_list;
00144     }
00145
00146     /* Check if cell passes vital checks */
00147     res = gds_tree_check_reference_loops(toplevel_cell->
parent_library);
00148     if (res < 0) {
00149         fprintf(stderr, "Checking library %s failed.\n", first_lib->name);
00150         goto ret_clear_layer_list;
00151     } else if (res > 0) {
00152         fprintf(stderr, "%d reference loops found.\n", res);
00153
00154         /* do further checking if the specified cell and/or its subcells are affected */
00155         if (toplevel_cell->checks.affected_by_reference_loop == 1) {
00156             fprintf(stderr, "Cell is affected by reference loop. Abort!\n");
00157             goto ret_clear_layer_list;
00158         }
00159     }
00160
00161     if (toplevel_cell->checks.affected_by_reference_loop ==
GDS_CELL_CHECK_NOT_RUN)
00162         fprintf(stderr, "Cell was not checked. This should not happen. Please report this issue. Will
continue either way.\n");
00163
00164     /* Note: unresolved references are not an abort condition.
00165      * Deal with it.
00166      */
00167
00168     /* Render outputs */
00169     if (pdf == TRUE || svg == TRUE) {
00170         cairo_render_cell_to_vector_file(toplevel_cell, layer_info_list, (
pdf == TRUE ? pdf_name : NULL),
00171                                         (svg == TRUE ? svg_name : NULL), scale);
00172     }
00173
00174     if (tex == TRUE) {
00175         tex_file = fopen(tex_name, "w");
00176         if (!tex_file)
00177             goto ret_clear_layer_list;
00178         latex_render_cell_to_code(toplevel_cell, layer_info_list, tex_file, scale,
pdf_layers, pdf_standalone);
00179         fclose(tex_file);
00180     }

```

```
00181
00182     if (so_name && so_out_file) {
00183         if (strlen(so_name) == 0 || strlen(so_out_file) == 0)
00184             goto ret_clear_layer_list;
00185
00186         /* Render output using external renderer */
00187         printf("Invoking external renderer!\n");
00188         external_renderer_render_cell(toplevel_cell, layer_info_list,
00189     so_out_file, so_name);
00189         printf("External renderer finished!\n");
00190     }
00191
00192 ret_clear_layer_list:
00193     g_list_free_full(layer_info_list, (GDestroyNotify)
00194     delete_layer_info_with_name);
00194
00195     g_object_unref(dstream);
00196     g_object_unref(stream);
00197 ret_destroy_file:
00198     g_object_unref(file);
00199     /* Delete all allocated libraries */
00200 ret_destroy_library_list:
00201     clear_lib_list(&libs);
00202 }
00203
```


13.16 command-line.dox File Reference

13.17 command-line.h File Reference


Render according to command line parameters.

```
#include <glib.h>
```

Include dependency graph for command-line.h:



This graph shows which files directly or indirectly include this file:



Functions

- void `command_line_convert_gds` (char *gds_name, char *pdf_name, char *tex_name, gboolean pdf, gboolean tex, char *layer_file, char *cell_name, double scale, gboolean pdf_layers, gboolean pdf_↔standalone, gboolean svg, char *svg_name, char *so_name, char *so_out_file)
Convert GDS according to supplied parameters.

13.17.1 Detailed Description

Render according to command line parameters.

Author

Mario Hüttel mario.huettel@gmx.net

Definition in file [command-line.h](#).

13.18 command-line.h

```

00001 /*
00002  * GDSII-Converter
00003  * Copyright (C) 2018 Mario Hüttel <mario.huettel@gmx.net>
00004  *
00005  * This file is part of GDSII-Converter.
00006  *
00007  * GDSII-Converter is free software: you can redistribute it and/or modify
00008  * it under the terms of the GNU General Public License version 2 as
00009  * published by the Free Software Foundation.
00010  *
00011  * GDSII-Converter is distributed in the hope that it will be useful,
00012  * but WITHOUT ANY WARRANTY; without even the implied warranty of
00013  * MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE. See the
00014  * GNU General Public License for more details.
00015  *
00016  * You should have received a copy of the GNU General Public License
00017  * along with GDSII-Converter. If not, see <http://www.gnu.org/licenses/>.
00018  */
00019
00031 #ifndef _COMMAND_LINE_H_
00032 #define _COMMAND_LINE_H_
00033
00034 #include <glib.h>
00035
00055 void command_line_convert_gds(char *gds_name, char *pdf_name, char *tex_name,
    gboolean pdf, gboolean tex,
00056     char *layer_file, char *cell_name, double scale, gboolean pdf_layers,
00057     gboolean pdf_standalone, gboolean svg, char *svg_name, char *so_name, char *so_out_file);
00058
00059 #endif /* _COMMAND_LINE_H_ */
00060
  
```



13.19 compilation.dox File Reference

13.20 conv-settings-dialog.c File Reference

Implementation of the setting dialog.

```
#include <gds-render/widgets/conv-settings-dialog.h>
```

Include dependency graph for conv-settings-dialog.c:



Data Structures

- [struct `_RendererSettingsDialog`](#)

Enumerations

- `enum { PROP_CELL_NAME = 1, PROP_COUNT }`

Functions

- static void [renderer_settings_dialog_set_property](#) (GObject *object, guint property_id, const GValue *value, GParamSpec *pspec)
- static void [renderer_settings_dialog_get_property](#) (GObject *object, guint property_id, GValue *value, GParamSpec *pspec)
- static void [renderer_settings_dialog_class_init](#) (RendererSettingsDialogClass *klass)
- static void [show_tex_options](#) (RendererSettingsDialog *self)
- static void [hide_tex_options](#) (RendererSettingsDialog *self)
- static void [latex_render_callback](#) (GtkToggleButton *radio, RendererSettingsDialog *dialog)
- static gboolean [shape_drawer_drawing_callback](#) (GtkWidget *widget, cairo_t *cr, gpointer data)
- static double [convert_number_to_engineering](#) (double input, const char **out_prefix)
- static void [renderer_settings_dialog_update_labels](#) (RendererSettingsDialog *self)
- static void [scale_value_changed](#) (GtkRange *range, gpointer user_data)

- static void `renderer_settings_dialog_init` (RendererSettingsDialog *self)
- RendererSettingsDialog * `renderer_settings_dialog_new` (GtkWindow *parent)
Create a new RedererSettingsDialog GObject.
- void `renderer_settings_dialog_get_settings` (RendererSettingsDialog *dialog, struct `render_settings` *settings)
Get the settings configured in the dialog.
- G_END_DECLS void `renderer_settings_dialog_set_settings` (RendererSettingsDialog *dialog, struct `render_settings` *settings)
Apply settings to dialog.
- void `renderer_settings_dialog_set_cell_width` (RendererSettingsDialog *dialog, unsigned int width)
renderer_settings_dialog_set_cell_width Set width for rendered cell
- void `renderer_settings_dialog_set_cell_height` (RendererSettingsDialog *dialog, unsigned int height)
renderer_settings_dialog_set_cell_height Set height for rendered cell
- void `renderer_settings_dialog_set_database_unit_scale` (RendererSettingsDialog *dialog, double unit_in_meters)
renderer_settings_dialog_set_database_unit_scale Set database scale

Variables

- static GParamSpec * `properties` [PROP_COUNT]

13.20.1 Detailed Description

Implementation of the setting dialog.

Author

Mario Hüttel mario.huettel@gmx.net

Definition in file [conv-settings-dialog.c](#).

13.21 conv-settings-dialog.c

```

00001 /*
00002  * GDSII-Converter
00003  * Copyright (C) 2018 Mario Hüttel <mario.huettel@gmx.net>
00004  *
00005  * This file is part of GDSII-Converter.
00006  *
00007  * GDSII-Converter is free software: you can redistribute it and/or modify
00008  * it under the terms of the GNU General Public License version 2 as
00009  * published by the Free Software Foundation.
00010  *
00011  * GDSII-Converter is distributed in the hope that it will be useful,
00012  * but WITHOUT ANY WARRANTY; without even the implied warranty of
00013  * MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE. See the
00014  * GNU General Public License for more details.
00015  *
00016  * You should have received a copy of the GNU General Public License
00017  * along with GDSII-Converter. If not, see <http://www.gnu.org/licenses/>.
00018  */
00019
00032 #include <gds-render/widgets/conv-settings-dialog.h>
00033
00034 struct _RendererSettingsDialog {
00035     GtkDialog parent;
00036     /* Private loot */
00037     GtkWidget *radio_latex;

```

```

00038     GtkWidget *radio_cairo_pdf;
00039     GtkWidget *radio_cairo_svg;
00040     GtkWidget *scale;
00041     GtkWidget *layer_check;
00042     GtkWidget *standalone_check;
00043     GtkDrawingArea *shape_drawing;
00044     GtkLabel *x_label;
00045     GtkLabel *y_label;
00046
00047     GtkLabel *x_output_label;
00048     GtkLabel *y_output_label;
00049
00050     unsigned int cell_height;
00051     unsigned int cell_width;
00052     double unit_in_meters;
00053 };
00054
00055 G_DEFINE_TYPE(RendererSettingsDialog, renderer_settings_dialog, GTK_TYPE_DIALOG)
00056
00057 enum {
00058     PROP_CELL_NAME = 1,
00059     PROP_COUNT
00060 };
00061
00062 static GParamSpec *properties[PROP_COUNT];
00063
00064 static void renderer_settings_dialog_set_property(GObject *object,
00065     guint property_id,
00066     const GValue *value, GParamSpec *pspec)
00067 {
00068     const gchar *title = NULL;
00069
00070     switch (property_id) {
00071     case PROP_CELL_NAME:
00072         title = g_value_get_string(value);
00073         if (title)
00074             gtk_window_set_title(GTK_WINDOW(object), title);
00075         break;
00076     default:
00077         G_OBJECT_WARN_INVALID_PROPERTY_ID(object, property_id, pspec);
00078         break;
00079     }
00080 }
00081
00082 static void renderer_settings_dialog_get_property(GObject *object,
00083     guint property_id,
00084     GValue *value, GParamSpec *pspec)
00085 {
00086     const gchar *title;
00087
00088     switch (property_id) {
00089     case PROP_CELL_NAME:
00090         title = gtk_window_get_title(GTK_WINDOW(object));
00091         g_value_set_string(value, title);
00092         break;
00093     default:
00094         G_OBJECT_WARN_INVALID_PROPERTY_ID(object, property_id, pspec);
00095         break;
00096     }
00097 }
00098
00099 static void renderer_settings_dialog_class_init(
00100     RendererSettingsDialogClass *klass)
00101 {
00102     GObjectClass *oclass = G_OBJECT_CLASS(klass);
00103
00104     /* Override virtual functions */
00105     oclass->set_property = renderer_settings_dialog_set_property;
00106     oclass->get_property = renderer_settings_dialog_get_property;
00107
00108     properties[PROP_CELL_NAME] = g_param_spec_string("cell-name",
00109         "cell-name",
00110         "Cell name to be displayed in header bar",
00111         "",
00112         G_PARAM_READWRITE);
00113     g_object_class_install_properties(oclass, PROP_COUNT, properties);
00114 }
00115
00116 static void show_tex_options(RendererSettingsDialog *self)
00117 {
00118     gtk_widget_show(self->layer_check);
00119     gtk_widget_show(self->standalone_check);
00120 }
00121
00122 static void hide_tex_options(RendererSettingsDialog *self)
00123 {

```

```

00122     gtk_widget_hide(self->layer_check);
00123     gtk_widget_hide(self->standalone_check);
00124 }
00125
00126 static void latex_render_callback(GtkToggleButton *radio, RendererSettingsDialog *
dialog)
00127 {
00128     if (gtk_toggle_button_get_active(radio))
00129         show_tex_options(dialog);
00130     else
00131         hide_tex_options(dialog);
00132 }
00133
00134 static gboolean shape_drawer_drawing_callback(GtkWidget *widget, cairo_t *cr,
gpointer data)
00135 {
00136     int width;
00137     int height;
00138     GtkStyleContext *style_context;
00139     GdkRGBA foreground_color;
00140     RendererSettingsDialog *dialog = (RendererSettingsDialog *)data;
00141     double usable_width;
00142     double usable_height;
00143     double height_scale;
00144     double width_scale;
00145     double final_scale_value;
00146
00147     style_context = gtk_widget_get_style_context(widget);
00148     width = gtk_widget_get_allocated_width(widget);
00149     height = gtk_widget_get_allocated_height(widget);
00150
00151     gtk_render_background(style_context, cr, 0, 0, width, height);
00152
00153     gtk_style_context_get_color(style_context, gtk_style_context_get_state(style_context),
&foreground_color);
00154
00155     gdk_cairo_set_source_rgba(cr, &foreground_color);
00156
00157     cairo_save(cr);
00158
00159     /* Transform coordiante system */
00160     cairo_scale(cr, 1, -1);
00161     cairo_translate(cr, (double)width/2.0, -(double)height/2.0);
00162
00163     /* Define usable drawing area */
00164     usable_width = (0.95*(double)width) - 15.0;
00165     usable_height = (0.95*(double)height) - 15.0;
00166
00167     width_scale = usable_width/(double)dialog->cell_width;
00168     height_scale = usable_height/(double)dialog->cell_height;
00169
00170     final_scale_value = (width_scale < height_scale ? width_scale : height_scale);
00171
00172     cairo_rectangle(cr, -(double)dialog->cell_width*final_scale_value/2.0, -(double)dialog->cell_height*
final_scale_value/2.0,
00173         (double)dialog->cell_width*final_scale_value, (double)dialog->cell_height*final_scale_value);
00174     cairo_stroke(cr);
00175     cairo_restore(cr);
00176
00177     return FALSE;
00178 }
00179 }
00180
00181 static double convert_number_to_engineering(double input, const char **
out_prefix)
00182 {
00183     const char *selected_prefix = NULL;
00184     double return_val = 0.0;
00185     int idx;
00186     const static char * prefixes[] = {"y", "z", "a", "f", "p", "n", "u", "m", "c", "d", /* < 1 */
00187         "", /* 1 */
00188         "h", "k", "M", "G", "T", "P", "E", "Z", "Y"}; /* > 1 */
00189     const static double scale[] = {1E-24, 1E-21, 1E-18, 1E-15, 1E-12, 1E-9, 1E-6, 1E-3, 1E-2, 1E-1,
00190         1,
00191         1E2, 1E3, 1E6, 1E9, 1E12, 1E15, 1E18, 1E21, 1E24};
00192     const int prefix_count = (int)(sizeof(prefixes)/sizeof(char *));
00193
00194     /* If pointer is invalid, return NaN */
00195     if (!out_prefix)
00196         return 0.0 / 0.0;
00197
00198     /* Start with the 2nd smallest prefix */
00199     for (idx = 1; idx < prefix_count; idx++) {
00200         if (input < scale[idx]) {
00201             /* This prefix is bigger than the number. Take the previous one */
00202             selected_prefix = prefixes[idx-1];
00203             return_val = input / scale[idx-1];
00204             break;

```

```

00205     }
00206 }
00207
00208 /* Check if prefix was set by loop. Else take the largest in the list */
00209 if (selected_prefix == NULL) {
00210     selected_prefix = prefixes[prefix_count-1];
00211     return_val = input / scale[prefix_count-1];
00212 }
00213
00214 if (out_prefix)
00215     *out_prefix = selected_prefix;
00216
00217 return return_val;
00218 }
00219
00220 static void renderer_settings_dialog_update_labels(
00221     RendererSettingsDialog *self)
00222 {
00223     char default_buff[100];
00224     double scale;
00225     double width_meters;
00226     double height_meters;
00227     double width_engineering;
00228     const char *width_prefix;
00229     double height_engineering;
00230     const char *height_prefix;
00231
00232     if (!self)
00233         return;
00234
00235     width_meters = (double)self->cell_width * self->unit_in_meters;
00236     height_meters = (double)self->cell_height * self->unit_in_meters;
00237
00238     width_engineering = convert_number_to_engineering(width_meters, &
00239 width_prefix);
00240     height_engineering = convert_number_to_engineering(height_meters, &
00241 height_prefix);
00242
00243     snprintf(default_buff, sizeof(default_buff), "Width: %.3lf %sm", width_engineering, width_prefix);
00244     gtk_label_set_text(self->x_label, default_buff);
00245     snprintf(default_buff, sizeof(default_buff), "Height: %.3lf %sm", height_engineering, height_prefix);
00246     gtk_label_set_text(self->y_label, default_buff);
00247
00248     scale = gtk_range_get_value(GTK_RANGE(self->scale));
00249
00250     /* Set the pixel sizes */
00251     snprintf(default_buff, sizeof(default_buff), "Output Width: %u px",
00252 (unsigned int)((double)self->cell_width / scale));
00253     gtk_label_set_text(self->x_output_label, default_buff);
00254     snprintf(default_buff, sizeof(default_buff), "Output Height: %u px",
00255 (unsigned int)((double)self->cell_height / scale));
00256     gtk_label_set_text(self->y_output_label, default_buff);
00257 }
00258
00259 static void scale_value_changed(GtkRange *range, gpointer user_data)
00260 {
00261     (void)range;
00262     RendererSettingsDialog *dialog;
00263
00264     dialog = RENDERER_SETTINGS_DIALOG(user_data);
00265     renderer_settings_dialog_update_labels(dialog);
00266 }
00267
00268 static void renderer_settings_dialog_init(RendererSettingsDialog *self)
00269 {
00270     GtkBuilder *builder;
00271     GtkWidget *box;
00272     GtkDialog *dialog;
00273
00274     dialog = &self->parent;
00275
00276     builder = gtk_builder_new_from_resource("/dialog.glade");
00277     box = GTK_WIDGET(gtk_builder_get_object(builder, "dialog-box"));
00278     self->radio_latex = GTK_WIDGET(gtk_builder_get_object(builder, "latex-radio"));
00279     self->radio_cairo_pdf = GTK_WIDGET(gtk_builder_get_object(builder, "cairo-pdf-radio"));
00280     self->radio_cairo_svg = GTK_WIDGET(gtk_builder_get_object(builder, "cairo-svg-radio"));
00281     self->scale = GTK_WIDGET(gtk_builder_get_object(builder, "dialog-scale"));
00282     self->standalone_check = GTK_WIDGET(gtk_builder_get_object(builder, "standalone-check"));
00283     self->layer_check = GTK_WIDGET(gtk_builder_get_object(builder, "layer-check"));
00284     self->shape_drawing = GTK_DRAWING_AREA(gtk_builder_get_object(builder, "shape-drawer"));
00285     self->x_label = GTK_LABEL(gtk_builder_get_object(builder, "x-label"));
00286     self->y_label = GTK_LABEL(gtk_builder_get_object(builder, "y-label"));
00287     self->x_output_label = GTK_LABEL(gtk_builder_get_object(builder, "x-output-label"));
00288     self->y_output_label = GTK_LABEL(gtk_builder_get_object(builder, "y-output-label"));
00289
00290     gtk_dialog_add_buttons(dialog, "Cancel", GTK_RESPONSE_CANCEL, "OK", GTK_RESPONSE_OK, NULL);
00291     gtk_container_add(GTK_CONTAINER(gtk_dialog_get_content_area(dialog)), box);

```

```

00289     gtk_window_set_title(GTK_WINDOW(self), "Renderer Settings");
00290
00291     g_signal_connect(self->radio_latex, "toggled", G_CALLBACK(
latex_render_callback), (gpointer)self);
00292     g_signal_connect(G_OBJECT(self->shape_drawing),
00293         "draw", G_CALLBACK(shape_drawer_drawing_callback), (gpointer)
self);
00294
00295     g_signal_connect(self->scale, "value-changed", G_CALLBACK(
scale_value_changed), (gpointer)self);
00296
00297     /* Default values */
00298     self->cell_width = 1;
00299     self->cell_height = 1;
00300     self->unit_in_meters = 1E-6;
00301     renderer_settings_dialog_update_labels(self);
00302
00303     g_object_unref(builder);
00304 }
00305
00306 RendererSettingsDialog *renderer_settings_dialog_new(GtkWindow *parent)
00307 {
00308     RendererSettingsDialog *res;
00309
00310     res = RENDERER_SETTINGS_DIALOG(g_object_new(RENDERER_TYPE_SETTINGS_DIALOG,
NULL));
00311     if (res && parent) {
00312         gtk_window_set_transient_for(GTK_WINDOW(res), parent);
00313     }
00314     return res;
00315 }
00316
00317 void renderer_settings_dialog_get_settings(RendererSettingsDialog *
dialog, struct render_settings *settings)
00318 {
00319
00320     if (!settings || !dialog)
00321         return;
00322     settings->scale = gtk_range_get_value(GTK_RANGE(dialog->scale));
00323
00324     /* Get active radio button selection */
00325     if (gtk_toggle_button_get_active(GTK_TOGGLE_BUTTON(dialog->radio_latex)) == TRUE) {
00326         settings->renderer = RENDERER_LATEX_TIKZ;
00327     } else if (gtk_toggle_button_get_active(GTK_TOGGLE_BUTTON(dialog->radio_cairo_pdf)) == TRUE) {
00328         settings->renderer = RENDERER_CAIROGRAPHICS_PDF;
00329     } else if (gtk_toggle_button_get_active(GTK_TOGGLE_BUTTON(dialog->radio_cairo_svg)) == TRUE) {
00330         settings->renderer = RENDERER_CAIROGRAPHICS_SVG;
00331     }
00332
00333     settings->tex_pdf_layers = gtk_toggle_button_get_active(GTK_TOGGLE_BUTTON(dialog->
layer_check));
00334     settings->tex_standalone = gtk_toggle_button_get_active(GTK_TOGGLE_BUTTON(dialog->
standalone_check));
00335 }
00336
00337 void renderer_settings_dialog_set_settings(RendererSettingsDialog *
dialog, struct render_settings *settings)
00338 {
00339     if (!settings || !dialog)
00340         return;
00341
00342     gtk_range_set_value(GTK_RANGE(dialog->scale), settings->scale);
00343     gtk_toggle_button_set_active(GTK_TOGGLE_BUTTON(dialog->layer_check), settings->
tex_pdf_layers);
00344     gtk_toggle_button_set_active(GTK_TOGGLE_BUTTON(dialog->standalone_check), settings->
tex_standalone);
00345
00346     switch (settings->renderer) {
00347     case RENDERER_LATEX_TIKZ:
00348         gtk_toggle_button_set_active(GTK_TOGGLE_BUTTON(dialog->radio_latex), TRUE);
00349         show_tex_options(dialog);
00350         break;
00351     case RENDERER_CAIROGRAPHICS_PDF:
00352         hide_tex_options(dialog);
00353         gtk_toggle_button_set_active(GTK_TOGGLE_BUTTON(dialog->radio_cairo_pdf), TRUE);
00354         break;
00355     case RENDERER_CAIROGRAPHICS_SVG:
00356         hide_tex_options(dialog);
00357         gtk_toggle_button_set_active(GTK_TOGGLE_BUTTON(dialog->radio_cairo_svg), TRUE);
00358         break;
00359     }
00360 }
00361
00362 void renderer_settings_dialog_set_cell_width(RendererSettingsDialog
*dialog, unsigned int width)
00363 {
00364     if (!dialog)

```


```
00365     return;
00366
00367     if (width == 0)
00368         width = 1;
00369
00370     dialog->cell_width = width;
00371     renderer_settings_dialog_update_labels(dialog);
00372 }
00373
00374 void renderer_settings_dialog_set_cell_height(
    RendererSettingsDialog *dialog, unsigned int height)
00375 {
00376     if (!dialog)
00377         return;
00378
00379     if (height == 0)
00380         height = 1;
00381
00382     dialog->cell_height = height;
00383     renderer_settings_dialog_update_labels(dialog);
00384 }
00385
00386 void renderer_settings_dialog_set_database_unit_scale(
    RendererSettingsDialog *dialog, double unit_in_meters)
00387 {
00388     if (!dialog)
00389         return;
00390
00391     if (unit_in_meters < 0)
00392         unit_in_meters *= -1;
00393
00394     dialog->unit_in_meters = unit_in_meters;
00395     renderer_settings_dialog_update_labels(dialog);
00396 }
00397
```

13.22 conv-settings-dialog.h File Reference


Header file for the Conversion Settings Dialog.

```
#include <gtk/gtk.h>
```

Include dependency graph for conv-settings-dialog.h:



This graph shows which files directly or indirectly include this file:



Data Structures

- struct [renderer_settings](#)
This struct holds the renderer configuration.

Macros

- #define [RENDERER_TYPE_SETTINGS_DIALOG](#) ([renderer_settings_dialog_get_type\(\)](#))

Enumerations

- enum [output_renderer](#) { [RENDERER_LATEX_TIKZ](#), [RENDERER_CAIROGRAPHICS_PDF](#), [RENDERER_CAIROGRAPHICS_PNG](#) }
- return type of the [RendererSettingsDialog](#)*

Functions

- [RendererSettingsDialog](#) * [renderer_settings_dialog_new](#) ([GtkWindow](#) *parent)
Create a new [RendererSettingsDialog](#) GObject.
- G_END_DECLS void [renderer_settings_dialog_set_settings](#) ([RendererSettingsDialog](#) *dialog, struct [renderer_settings](#) *settings)
Apply settings to dialog.
- void [renderer_settings_dialog_get_settings](#) ([RendererSettingsDialog](#) *dialog, struct [renderer_settings](#) *settings)
Get the settings configured in the dialog.
- void [renderer_settings_dialog_set_cell_width](#) ([RendererSettingsDialog](#) *dialog, unsigned int width)
[renderer_settings_dialog_set_cell_width](#) Set width for rendered cell
- void [renderer_settings_dialog_set_cell_height](#) ([RendererSettingsDialog](#) *dialog, unsigned int height)
[renderer_settings_dialog_set_cell_height](#) Set height for rendered cell
- void [renderer_settings_dialog_set_database_unit_scale](#) ([RendererSettingsDialog](#) *dialog, double unit_in_↔ meters)
[renderer_settings_dialog_set_database_unit_scale](#) Set database scale

13.22.1 Detailed Description

Header file for the Conversion Settings Dialog.

Author

`Mario.Huettel@gmx.net` `mario.huettel@gmx.net`

Definition in file `conv-settings-dialog.h`.

13.23 conv-settings-dialog.h

```


00001 /*
00002  * GDSII-Converter
00003  * Copyright (C) 2018 Mario Hüttel <mario.huettel@gmx.net>
00004  *
00005  * This file is part of GDSII-Converter.
00006  *
00007  * GDSII-Converter is free software: you can redistribute it and/or modify
00008  * it under the terms of the GNU General Public License version 2 as
00009  * published by the Free Software Foundation.
00010  *
00011  * GDSII-Converter is distributed in the hope that it will be useful,
00012  * but WITHOUT ANY WARRANTY; without even the implied warranty of
00013  * MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE. See the
00014  * GNU General Public License for more details.
00015  *
00016  * You should have received a copy of the GNU General Public License
00017  * along with GDSII-Converter. If not, see <http://www.gnu.org/licenses/>.
00018  */
00019
00032 #ifndef __CONV_SETTINGS_DIALOG_H__
00033 #define __CONV_SETTINGS_DIALOG_H__
00034
00035 #include <gtk/gtk.h>
00036
00037 G_BEGIN_DECLS
00038
00040 enum output_renderer { RENDERER_LATEX_TIKZ,
00041                       RENDERER_CAIROGRAPHICS_PDF, RENDERER_CAIROGRAPHICS_SVG }
00042 ;
00043
00044 G_DECLARE_FINAL_TYPE(RendererSettingsDialog, renderer_settings_dialog, RENDERER,
00045                     SETTINGS_DIALOG, GtkDialog)
00046
00047
00048
00049
00050
00051 #define RENDERER_TYPE_SETTINGS_DIALOG (renderer_settings_dialog_get_type())
00052
00053
00054 struct render_settings {
00055     double scale;
00056     enum output_renderer renderer;
00057     gboolean tex_pdf_layers;
00058     gboolean tex_standalone;
00059 };
00060
00061 G_END_DECLS
00062
00063
00064
00065 void renderer_settings_dialog_set_settings(RendererSettingsDialog *
00066     dialog, struct render_settings *settings);
00067
00068
00069 void renderer_settings_dialog_get_settings(RendererSettingsDialog *
00070     dialog, struct render_settings *settings);
00071
00072
00073 void renderer_settings_dialog_set_cell_width(RendererSettingsDialog
00074     *dialog, unsigned int width);
00075
00076
00077 void renderer_settings_dialog_set_cell_height(
00078     RendererSettingsDialog *dialog, unsigned int height);
00079
00080
00081 void renderer_settings_dialog_set_database_unit_scale(
00082     RendererSettingsDialog *dialog, double unit_in_meters);
00083
00084
00085 #endif /* __CONV_SETTINGS_DIALOG_H__ */

```

13.24 external-renderer.c File Reference

This file implements the dynamic library loading for the external rendering feature.

```
#include <dlfcn.h>
#include <stdio.h>
#include <gds-render/external-renderer.h>
Include dependency graph for external-renderer.c:
```



Functions

- int [external_renderer_render_cell](#) (struct [gds_cell](#) *toplevel_cell, GList *layer_info_list, char *output_file, char *so_path)
external_renderer_render_cell

13.24.1 Detailed Description

This file implements the dynamic library loading for the external rendering feature.

Author

Mario Hüttel mario.huettel@gmx.net

Definition in file [external-renderer.c](#).

13.25 external-renderer.c

```

00001 /*
00002  * GDSII-Converter
00003  * Copyright (C) 2018 Mario Hüttel <mario.huettel@gmx.net>
00004  *
00005  * This file is part of GDSII-Converter.
00006  *
00007  * GDSII-Converter is free software: you can redistribute it and/or modify
00008  * it under the terms of the GNU General Public License version 2 as
00009  * published by the Free Software Foundation.
00010  *
00011  * GDSII-Converter is distributed in the hope that it will be useful,
00012  * but WITHOUT ANY WARRANTY; without even the implied warranty of
00013  * MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE. See the
00014  * GNU General Public License for more details.
00015  *
00016  * You should have received a copy of the GNU General Public License
00017  * along with GDSII-Converter. If not, see <http://www.gnu.org/licenses/>.
00018  */
00019
00031 #include <dlfcn.h>
00032 #include <stdio.h>
00033
00034 #include <gds-render/external-renderer.h>
00035
00036 int external_renderer_render_cell(struct gds_cell *toplevel_cell,
                                GList *layer_info_list,
                                char *output_file, char *so_path)
00037 {
00038     int (*so_render_func)(struct gds_cell *, GList *, char *) = NULL;
00039     void *so_handle = NULL;
00040     char *error_msg;
00041     int ret = 0;
00042
00043     /* Check parameter sanity */
00044     if (!output_file || !so_path || !toplevel_cell || !layer_info_list)
00045         return -3000;
00046
00047     /* Load shared object */
00048     so_handle = dlopen(so_path, RTLD_LAZY);
00049     if (!so_handle) {
00050         printf("Could not load external library '%s'\nDetailed error is:\n%s\n", so_path, dlerror());
00051         return -2000;
00052     }
00053
00054     /* Load symbol from library */
00055     so_render_func = (int (*)(struct gds_cell *, GList *, char *))dlsym(so_handle,
                                EXTERNAL_LIBRARY_FUNCTION);
00056     error_msg = dlerror();
00057     if (error_msg != NULL) {
00058         printf("Rendering function not found in library:\n%s\n", error_msg);
00059         goto ret_close_so_handle;
00060     }
00061
00062     /* Execute */
00063     if (so_render_func)
00064         so_render_func(toplevel_cell, layer_info_list, output_file);
00065
00066 ret_close_so_handle:
00067     dlclose(so_handle);
00068     return ret;
00069 }
00070
00071


```

13.26 external-renderer.dox File Reference


13.27 external-renderer.h File Reference

Render according to command line parameters.

```
#include <gds-render/gds-utils/gds-types.h>
#include <glib.h>
Include dependency graph for external-renderer.h:
```



This graph shows which files directly or indirectly include this file:



Macros

- `#define EXTERNAL_LIBRARY_FUNCTION "render_cell_to_file"`
function name expected to be found in external library.

Functions

- `int external_renderer_render_cell (struct gds_cell *toplevel_cell, GList *layer_info_list, char *output_file, char *so_path)`
external_renderer_render_cell

13.27.1 Detailed Description

Render according to command line parameters.

Author

Mario Hüttel mario.huettel@gmx.net

Definition in file [external-renderer.h](#).

13.28 external-renderer.h

```

00001 /*
00002  * GDSII-Converter
00003  * Copyright (C) 2018 Mario Hüttel <mario.huettel@gmx.net>
00004  *
00005  * This file is part of GDSII-Converter.
00006  *
00007  * GDSII-Converter is free software: you can redistribute it and/or modify
00008  * it under the terms of the GNU General Public License version 2 as
00009  * published by the Free Software Foundation.
00010  *
00011  * GDSII-Converter is distributed in the hope that it will be useful,
00012  * but WITHOUT ANY WARRANTY; without even the implied warranty of
00013  * MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE. See the
00014  * GNU General Public License for more details.
00015  *
00016  * You should have received a copy of the GNU General Public License
00017  * along with GDSII-Converter. If not, see <http://www.gnu.org/licenses/>.
00018  */
00019
00031 #ifndef _EXTERNAL_RENDERER_H_
00032 #define _EXTERNAL_RENDERER_H_
00033
00034 #include <gds-render/gds-utils/gds-types.h>
00035 #include <glib.h>
00036
00045 #define EXTERNAL_LIBRARY_FUNCTION "render_cell_to_file"
00046
00055 int external_renderer_render_cell(struct gds_cell *toplevel_cell,
    GList *layer_info_list, char *output_file, char *so_path);
00056
00057 #endif /* _EXTERNAL_RENDERER_H_ */
00058

```

13.29 gds-parser.c File Reference


Implementation of the GDS-Parser.

```

#include <stdlib.h>
#include <stdio.h>
#include <string.h>
#include <stdbool.h>
#include <math.h>
#include <cairo.h>

```

```
#include <gds-render/gds-utils/gds-parser.h>
Include dependency graph for gds-parser.c:
```



Data Structures

- struct [gds_cell_array_instance](#)
Struct representing an array instantiation.

Macros

- #define [GDS_DEFAULT_UNITS](#) (10E-9)
Default units assumed for library.
- #define [GDS_ERROR](#)(fmt, ...) printf("[PARSE_ERROR] " fmt "\n", ##__VA_ARGS__)
Print GDS error.
- #define [GDS_WARN](#)(fmt, ...) printf("[PARSE_WARNING] " fmt "\n", ##__VA_ARGS__)
Print GDS warning.
- #define [GDS_INF](#)(fmt, ...)

Enumerations

- enum [gds_record](#) {
[INVALID](#) = 0x0000, [HEADER](#) = 0x0002, [BGNLIB](#) = 0x0102, [LIBNAME](#) = 0x0206,
[UNITS](#) = 0x0305, [ENDLIB](#) = 0x0400, [BGNSTR](#) = 0x0502, [STRNAME](#) = 0x0606,
[ENDSTR](#) = 0x0700, [BOUNDARY](#) = 0x0800, [PATH](#) = 0x0900, [SREF](#) = 0x0A00,
[ENDEL](#) = 0x1100, [XY](#) = 0x1003, [MAG](#) = 0x1B05, [ANGLE](#) = 0x1C05,
[SNAME](#) = 0x1206, [STRANS](#) = 0x1A01, [BOX](#) = 0x2D00, [LAYER](#) = 0x0D02,
[WIDTH](#) = 0x0F03, [PATHTYPE](#) = 0x2102, [COLROW](#) = 0x1302, [AREF](#) = 0x0B00 }

Functions

- static int [name_cell_ref](#) (struct [gds_cell_instance](#) *cell_inst, unsigned int bytes, char *data)
Name cell reference.
- static int [name_array_cell_ref](#) (struct [gds_cell_array_instance](#) *cell_inst, unsigned int bytes, char *data)
Name cell reference.
- static double [gds_convert_double](#) (const char *data)

- Convert GDS 8-byte real to double.*

 - static signed int `gds_convert_signed_int` (const char *data)

Convert GDS INT32 to int.
- static int16_t `gds_convert_signed_int16` (const char *data)

Convert GDS INT16 to int16.
- static uint16_t `gds_convert_unsigend_int16` (const char *data)

Convert GDS UINT16 String to uint16.
- static GList * `append_library` (GList *curr_list, struct `gds_library` **library_ptr)

Append library to list.
- static GList * `append_graphics` (GList *curr_list, enum `graphics_type` type, struct `gds_graphics` **graphics_ptr)

Append graphics to list.
- static GList * `append_vertex` (GList *curr_list, int x, int y)

Appends vertex List.
- static GList * `append_cell` (GList *curr_list, struct `gds_cell` **cell_ptr)

append_cell Append a gds_cell to a list
- static GList * `append_cell_ref` (GList *curr_list, struct `gds_cell_instance` **instance_ptr)

Append a cell reference to the reference GList.
- static int `name_library` (struct `gds_library` *current_library, unsigned int bytes, char *data)

Name a gds_library.
- static int `name_cell` (struct `gds_cell` *cell, unsigned int bytes, char *data, struct `gds_library` *lib)

Names a gds_cell.
- static void `parse_reference_list` (gpointer gcell_ref, gpointer glibrary)

Search for cell reference gcell_ref in glibrary.
- static void `scan_cell_reference_dependencies` (gpointer gcell, gpointer library)

Scans cell references inside cell This function searches all the references in gcell and updates the gds_cell_instance::cell_ref field in each instance.
- static void `scan_library_references` (gpointer library_list_item, gpointer user)

Scans library's cell references.
- static void `gds_parse_date` (const char *buffer, int length, struct `gds_time_field` *mod_date, struct `gds_time_field` *access_date)

gds_parse_date
- static void `convert_aref_to_sref` (struct `gds_cell_array_instance` *aref, struct `gds_cell` *container_cell)

Convert AREF to a bunch of SREFs and append them to container_cell.
- int `parse_gds_from_file` (const char *filename, GList **library_list)
- static void `delete_cell_inst_element` (struct `gds_cell_instance` *cell_inst)

delete_cell_inst_element
- static void `delete_vertex` (struct `gds_point` *vertex)

delete_vertex
- static void `delete_graphics_obj` (struct `gds_graphics` *gfx)

delete_graphics_obj
- static void `delete_cell_element` (struct `gds_cell` *cell)

delete_cell_element
- static void `delete_library_element` (struct `gds_library` *lib)

delete_library_element
- int `clear_lib_list` (GList **library_list)

Deletes all libraries including cells, references etc.

13.29.1 Detailed Description

Implementation of the GDS-Parser.

Author

Mario Hüttel mario.huettel@gmx.net

What's missing? - A lot: Support for 4 Byte real Support for pathtypes Support for datatypes (only layer so far) etc...

Definition in file [gds-parser.c](#).

13.30 gds-parser.c

```

00001 /*
00002  * GDSII-Converter
00003  * Copyright (C) 2018 Mario Hüttel <mario.huettel@gmx.net>
00004  *
00005  * This file is part of GDSII-Converter.
00006  *
00007  * GDSII-Converter is free software: you can redistribute it and/or modify
00008  * it under the terms of the GNU General Public License version 2 as
00009  * published by the Free Software Foundation.
00010  *
00011  * GDSII-Converter is distributed in the hope that it will be useful,
00012  * but WITHOUT ANY WARRANTY; without even the implied warranty of
00013  * MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE. See the
00014  * GNU General Public License for more details.
00015  *
00016  * You should have received a copy of the GNU General Public License
00017  * along with GDSII-Converter. If not, see <http://www.gnu.org/licenses/>.
00018  */
00019
00037 #include <stdlib.h>
00038 #include <stdio.h>
00039 #include <string.h>
00040 #include <stdbool.h>
00041 #include <math.h>
00042 #include <cairo.h>
00043
00044 #include <gds-render/gds-utils/gds-parser.h>
00045
00050 #define GDS_DEFAULT_UNITS (10E-9)
00051
00052 #define GDS_ERROR(fmt, ...) printf("[PARSE_ERROR] " fmt "\n", ##__VA_ARGS__)
00053 #define GDS_WARN(fmt, ...) printf("[PARSE_WARNING] " fmt "\n", ##__VA_ARGS__)
00055 #if GDS_PRINT_DEBUG_INFOS
00056 #define GDS_INF(fmt, ...) printf(fmt, ##__VA_ARGS__)
00057 #else
00058 #define GDS_INF(fmt, ...)
00059 #endif
00060 enum gds_record {
00061     INVALID = 0x0000,
00062     HEADER = 0x0002,
00063     BGNLIB = 0x0102,
00064     LIBNAME = 0x0206,
00065     UNITS = 0x0305,
00066     ENDLIB = 0x0400,
00067     BGNSTR = 0x0502,
00068     STRNAME = 0x0606,
00069     ENDSTR = 0x0700,
00070     BOUNDARY = 0x0800,
00071     PATH = 0x0900,
00072     SREF = 0x0A00,
00073     ENDEL = 0x1100,
00074     XY = 0x1003,
00075     MAG = 0x1B05,
00076     ANGLE = 0x1C05,
00077     SNAME = 0x1206,
00078     STRANS = 0x1A01,
00079     BOX = 0x2D00,
00080     LAYER = 0x0D02,
00081     WIDTH = 0x0F03,
00082     PATHTYPE = 0x2102,
00083     COLROW = 0x1302,

```



```

00084     AREF = 0x0B00
00085 };
00086
00093 struct gds_cell_array_instance {
00094     char ref_name[CELL_NAME_MAX];
00095     struct gds_cell *cell_ref;
00096     struct gds_point control_points[3];
00097     int flipped;
00098     double angle;
00099     double magnification;
00100     int columns;
00101     int rows;
00102 };
00103
00111 static int name_cell_ref(struct gds_cell_instance *cell_inst,
00112     unsigned int bytes, char *data)
00113 {
00114     int len;
00115
00116     if (cell_inst == NULL) {
00117         GDS_ERROR("Naming cell ref with no opened cell ref");
00118         return -1;
00119     }
00120     data[bytes] = 0; // Append '0'
00121     len = (int)strlen(data);
00122     if (len > CELL_NAME_MAX-1) {
00123         GDS_ERROR("Cell name '%s' too long: %d\n", data, len);
00124         return -1;
00125     }
00126
00127     /* else: */
00128     strcpy(cell_inst->ref_name, data);
00129     GDS_INF("\tCell referenced: %s\n", cell_inst->ref_name);
00130
00131     return 0;
00132 }
00133
00141 static int name_array_cell_ref(struct gds_cell_array_instance *
00142     cell_inst,
00143     unsigned int bytes, char *data)
00144 {
00145     int len;
00146
00147     if (cell_inst == NULL) {
00148         GDS_ERROR("Naming array cell ref with no opened cell ref");
00149         return -1;
00150     }
00151     data[bytes] = 0; // Append '0'
00152     len = (int)strlen(data);
00153     if (len > CELL_NAME_MAX-1) {
00154         GDS_ERROR("Cell name '%s' too long: %d\n", data, len);
00155         return -1;
00156     }
00157
00158     /* else: */
00159     strcpy(cell_inst->ref_name, data);
00160     GDS_INF("\tCell referenced: %s\n", cell_inst->ref_name);
00161
00162     return 0;
00163 }
00169 static double gds_convert_double(const char *data)
00170 {
00171     bool sign_bit;
00172     int i;
00173     double ret_val;
00174     char current_byte;
00175     int bit = 0;
00176     int exponent;
00177
00178     sign_bit = ((data[0] & 0x80) ? true : false);
00179
00180     /* Check for real 0 */
00181     for (i = 0; i < 8; i++) {
00182         if (data[i] != 0)
00183             break;
00184         if (i == 7) {
00185             /* All 8 bytes are 0 */
00186             return 0.0;
00187         }
00188     }
00189
00190     /* Value is other than 0 */
00191     ret_val = 0.0;
00192     for (i = 8; i < 64; i++) {
00193         current_byte = data[i/8];
00194         bit = i % 8;

```

```

00195     /* isolate bit */
00196     if ((current_byte & (0x80 >> bit)))
00197         ret_val += pow(2, ((double)(-i+7)));
00198
00199     }
00200
00201     /* Parse exponent and sign bit */
00202     exponent = (int)(data[0] & 0x7F);
00203     exponent -= 64;
00204     ret_val *= pow(16, exponent) * (sign_bit == true ? -1 : 1);
00205
00206     return ret_val;
00207 }
00208
00214 static signed int gds_convert_signed_int(const char *data)
00215 {
00216     int ret;
00217
00218     if (!data) {
00219         GDS_ERROR("This should not happen");
00220         return 0;
00221     }
00222
00223     ret = (signed int)((((int)data[0] & 0xFF) << 24) |
00224          (((int)data[1] & 0xFF) << 16) |
00225          (((int)(data[2]) & 0xFF) << 8) |
00226          (((int)(data[3]) & 0xFF) << 0));
00227     return ret;
00228 }
00229
00235 static int16_t gds_convert_signed_int16(const char *data)
00236 {
00237     if (!data) {
00238         GDS_ERROR("This should not happen");
00239         return 0;
00240     }
00241     return (int16_t)((((int16_t)(data[0]) & 0xFF) << 8) |
00242                (((int16_t)(data[1]) & 0xFF) << 0));
00243 }
00244
00250 static uint16_t gds_convert_unsigned_int16(const char *data)
00251 {
00252     if (!data) {
00253         GDS_ERROR("This should not happen");
00254         return 0;
00255     }
00256     return (uint16_t)((((uint16_t)(data[0]) & 0xFF) << 8) |
00257                    (((uint16_t)(data[1]) & 0xFF) << 0));
00258 }
00259
00266 static GList *append_library(GList *curr_list, struct gds_library **library_ptr)
00267 {
00268     struct gds_library *lib;
00269
00270     lib = (struct gds_library *)malloc(sizeof(struct gds_library));
00271     if (lib) {
00272         lib->cells = NULL;
00273         lib->name[0] = 0;
00274         lib->unit_in_meters = GDS_DEFAULT_UNITS; // Default. Will be
overwritten
00275         lib->cell_names = NULL;
00276     } else
00277         return NULL;
00278     if (library_ptr)
00279         *library_ptr = lib;
00280
00281     return g_list_append(curr_list, lib);
00282 }
00283
00291 static GList *append_graphics(GList *curr_list, enum
graphics_type type,
                                struct gds_graphics **graphics_ptr)
00292 {
00293     struct gds_graphics *gfx;
00294
00295     gfx = (struct gds_graphics *)malloc(sizeof(struct gds_graphics));
00296     if (gfx) {
00297         gfx->datatype = 0;
00298         gfx->layer = 0;
00299         gfx->vertices = NULL;
00300         gfx->width_absolute = 0;
00301         gfx->gfx_type = type;
00302         gfx->path_render_type = PATH_FLUSH;
00303     } else
00304         return NULL;
00305
00306     if (graphics_ptr)
00307

```

```

00308     *graphics_ptr = gfx;
00309
00310     return g_list_append(curr_list, gfx);
00311 }
00312
00320 static GList *append_vertex(GList *curr_list, int x, int y)
00321 {
00322     struct gds_point *vertex;
00323
00324     vertex = (struct gds_point *)malloc(sizeof(struct gds_point));
00325     if (vertex) {
00326         vertex->x = x;
00327         vertex->y = y;
00328     } else
00329         return NULL;
00330     return g_list_append(curr_list, vertex);
00331 }
00332
00341 static GList *append_cell(GList *curr_list, struct gds_cell **cell_ptr)
00342 {
00343     struct gds_cell *cell;
00344
00345     cell = (struct gds_cell *)malloc(sizeof(struct gds_cell));
00346     if (cell) {
00347         cell->child_cells = NULL;
00348         cell->graphic_objs = NULL;
00349         cell->name[0] = 0;
00350         cell->parent_library = NULL;
00351         cell->checks.unresolved_child_count =
GDS_CELL_CHECK_NOT_RUN;
00352         cell->checks.affected_by_reference_loop =
GDS_CELL_CHECK_NOT_RUN;
00353     } else
00354         return NULL;
00355     /* return cell */
00356     if (cell_ptr)
00357         *cell_ptr = cell;
00358
00359     return g_list_append(curr_list, cell);
00360 }
00361
00370 static GList *append_cell_ref(GList *curr_list, struct
gds_cell_instance **instance_ptr)
00371 {
00372     struct gds_cell_instance *inst;
00373
00374     inst = (struct gds_cell_instance *)
malloc(sizeof(struct gds_cell_instance));
00375     if (inst) {
00376         inst->cell_ref = NULL;
00377         inst->ref_name[0] = 0;
00378         inst->magnification = 1.0;
00379         inst->flipped = 0;
00380         inst->angle = 0.0;
00381     } else
00382         return NULL;
00383
00384     if (instance_ptr)
00385         *instance_ptr = inst;
00386
00387     return g_list_append(curr_list, inst);
00388 }
00389 }
00390
00398 static int name_library(struct gds_library *current_library,
unsigned int bytes, char *data)
00399 {
00400     int len;
00401
00402     if (current_library == NULL) {
00403         GDS_ERROR("Naming cell with no opened library");
00404         return -1;
00405     }
00406
00407     data[bytes] = 0; // Append '0'
00408     len = (int)strlen(data);
00409     if (len > CELL_NAME_MAX-1) {
00410         GDS_ERROR("Library name '%s' too long: %d\n", data, len);
00411         return -1;
00412     }
00413
00414     strcpy(current_library->name, data);
00415     GDS_INF("Named library: %s\n", current_library->name);
00416
00417     return 0;
00418 }
00419 }
00420
00429 static int name_cell(struct gds_cell *cell, unsigned int bytes,

```

```

00430         char *data, struct gds_library *lib)
00431 {
00432     int len;
00433
00434     if (cell == NULL) {
00435         GDS_ERROR("Naming library with no opened library");
00436         return -1;
00437     }
00438     data[bytes] = 0; // Append '0'
00439     len = (int)strlen(data);
00440     if (len > CELL_NAME_MAX-1) {
00441         GDS_ERROR("Cell name '%s' too long: %d\n", data, len);
00442         return -1;
00443     }
00444
00445     strcpy(cell->name, data);
00446     GDS_INF("Named cell: %s\n", cell->name);
00447
00448     /* Append cell name to lib's list of names */
00449     lib->cell_names = g_list_append(lib->cell_names, cell->
name);
00450
00451     return 0;
00452 }
00453
00461 static void parse_reference_list(gpointer gcell_ref, gpointer glibrary)
00462 {
00463     struct gds_cell_instance *inst = (struct gds_cell_instance *)
gcell_ref;
00464     struct gds_library *lib = (struct gds_library *)glibrary;
00465     GList *cell_item;
00466     struct gds_cell *cell;
00467
00468     GDS_INF("\t\t\tReference: %s: ", inst->ref_name);
00469     /* Find cell */
00470     for (cell_item = lib->cells; cell_item != NULL;
cell_item = cell_item->next) {
00471
00472         cell = (struct gds_cell *)cell_item->data;
00473         /* Check if cell is found */
00474         if (!strcmp(cell->name, inst->ref_name)) {
00475             GDS_INF("found\n");
00476             /* update reference link */
00477             inst->cell_ref = cell;
00478             return;
00479         }
00480     }
00481 }
00482
00483     GDS_INF("MISSING!\n");
00484     GDS_WARN("referenced cell could not be found in library");
00485 }
00486
00493 static void scan_cell_reference_dependencies(gpointer gcell, gpointer
library)
00494 {
00495     struct gds_cell *cell = (struct gds_cell *)gcell;
00496
00497     GDS_INF("\tScanning cell: %s\n", cell->name);
00498
00499     /* Scan all library references */
00500     g_list_foreach(cell->child_cells, parse_reference_list, library);
00501 }
00502 }
00503
00511 static void scan_library_references(gpointer library_list_item, gpointer user)
00512 {
00513     struct gds_library *lib = (struct gds_library *)library_list_item;
00514     (void)user;
00515
00516     GDS_INF("Scanning Library: %s\n", lib->name);
00517     g_list_foreach(lib->cells, scan_cell_reference_dependencies, lib);
00518 }
00519
00527 static void gds_parse_date(const char *buffer, int length, struct
gds_time_field *mod_date, struct gds_time_field *access_date)
00528 {
00529
00530     struct gds_time_field *temp_date;
00531
00532     if (!access_date || !mod_date) {
00533         GDS_WARN("Date structures invalid");
00534         return;
00535     }
00536
00537     if (length != (2*6*2)) {
00538         GDS_WARN("Could not parse date field! Not the specified length");
00539         return;

```

```

00540     }
00541
00542     for (temp_date = mod_date; 1; temp_date = access_date) {
00543         temp_date->year = gds_convert_unsigend_int16(buffer);
00544         buffer += 2;
00545         temp_date->month = gds_convert_unsigend_int16(buffer);
00546         buffer += 2;
00547         temp_date->day = gds_convert_unsigend_int16(buffer);
00548         buffer += 2;
00549         temp_date->hour = gds_convert_unsigend_int16(buffer);
00550         buffer += 2;
00551         temp_date->minute = gds_convert_unsigend_int16(buffer);
00552         buffer += 2;
00553         temp_date->second = gds_convert_unsigend_int16(buffer);
00554         buffer += 2;
00555
00556         if (temp_date == access_date)
00557             break;
00558     }
00559 }
00560
00572 static void convert_aref_to_sref(struct
gds_cell_array_instance *aref, struct gds_cell *container_cell)
00573 {
00574     struct gds_point origin;
00575     struct gds_point row_shift_vector;
00576     struct gds_point col_shift_vector;
00577     struct gds_cell_instance *sref_inst;
00578     int col;
00579     int row;
00580
00581     if (!aref || !container_cell)
00582         return;
00583
00584     if (aref->columns == 0 || aref->rows == 0) {
00585         GDS_ERROR("Conversion of array instance aborted. No rows / columns.");
00586         return;
00587     }
00588     origin.x = aref->control_points[0].x;
00589     origin.y = aref->control_points[0].y;
00590
00591     row_shift_vector.x = (aref->control_points[2].x - origin.
x) / aref->rows;
00592     row_shift_vector.y = (aref->control_points[2].y - origin.
y) / aref->rows;
00593     col_shift_vector.x = (aref->control_points[1].x - origin.
x) / aref->columns;
00594     col_shift_vector.y = (aref->control_points[1].y - origin.
y) / aref->columns;
00595
00596     /* Iterate over columns and rows */
00597     for (col = 0; col < aref->columns; col++) {
00598         for (row = 0; row < aref->rows; row++) {
00599             /* Create new instance for this row/column and configure data */
00600             container_cell->child_cells = append_cell_ref(container_cell->
child_cells, &sref_inst);
00601             if (!sref_inst) {
00602                 GDS_ERROR("Appending cell ref failed!");
00603                 continue;
00604             }
00605
00606             sref_inst->angle = aref->angle;
00607             sref_inst->magnification = aref->magnification;
00608             sref_inst->flipped = aref->flipped;
00609             strncpy(sref_inst->ref_name, aref->ref_name,
CELL_NAME_MAX);
00610             sref_inst->origin.x = origin.x + row_shift_vector.x * row + col_shift_vector.
x * col;
00611             sref_inst->origin.y = origin.y + row_shift_vector.y * row + col_shift_vector.
y * col;
00612         }
00613     }
00614     GDS_INF("Converted AREF to SREFs\n");
00615 }
00616
00617 int parse_gds_from_file(const char *filename, GList **library_list)
00618 {
00619     char *workbuff;
00620     int read;
00621     int i;
00622     int run = 1;
00623     FILE *gds_file = NULL;
00624     uint16_t rec_data_length;
00625     enum gds_record rec_type;
00626     struct gds_library *current_lib = NULL;
00627     struct gds_cell *current_cell = NULL;
00628     struct gds_graphics *current_graphics = NULL;

```

```

00629     struct gds_cell_instance *current_s_reference = NULL;
00630     struct gds_cell_array_instance *current_a_reference = NULL;
00631     struct gds_cell_array_instance temp_a_reference;
00632     int x, y;
00633     GList *lib_list;
00634
00635     lib_list = *library_list;
00636
00637     /* Allocate working buffer */
00638     workbuff = (char *)malloc(sizeof(char)*128*1024);
00639
00640     if(!workbuff)
00641         return -100;
00642
00643     /* open File */
00644     gds_file = fopen(filename, "rb");
00645     if (gds_file == NULL) {
00646         GDS_ERROR("Could not open File %s", filename);
00647         return -1;
00648     }
00649
00650     /* Record parser */
00651     while (run == 1) {
00652         rec_type = INVALID;
00653         read = fread(workbuff, sizeof(char), 2, gds_file);
00654         if (read != 2 && (current_cell != NULL ||
00655             current_graphics != NULL ||
00656             current_lib != NULL ||
00657             current_s_reference != NULL)) {
00658             GDS_ERROR("End of File. with openend structs/libs");
00659             run = -2;
00660             break;
00661         } else if (read != 2) {
00662             /* EOF */
00663             run = 0;
00664             break;
00665         }
00666     }
00667
00668     rec_data_length = gds_convert_unsigend_int16(workbuff);
00669
00670     if (rec_data_length < 4) {
00671         /* Possible Zero-Padding: */
00672         run = 0;
00673         GDS_WARN("Zero Padding detected!");
00674         if (current_cell != NULL ||
00675             current_graphics != NULL ||
00676             current_lib != NULL ||
00677             current_s_reference != NULL) {
00678             GDS_ERROR("Not all structures closed");
00679             run = -2;
00680         }
00681         break;
00682     }
00683     rec_data_length -= 4;
00684
00685     read = fread(workbuff, sizeof(char), 2, gds_file);
00686     if (read != 2) {
00687         run = -2;
00688         GDS_ERROR("Unexpected end of file");
00689         break;
00690     }
00691     rec_type = gds_convert_unsigend_int16(workbuff);
00692
00693     /* if begin: Allocate structures */
00694     switch (rec_type) {
00695     case BGNLIB:
00696         lib_list = append_library(lib_list, &current_lib);
00697         if (lib_list == NULL) {
00698             GDS_ERROR("Allocating memory failed");
00699             run = -3;
00700             break;
00701         }
00702
00703         GDS_INF("Entering Lib\n");
00704         break;
00705     case ENDLIB:
00706         if (current_lib == NULL) {
00707             run = -4;
00708             GDS_ERROR("Closing Library with no opened library");
00709             break;
00710         }
00711     }
00712
00713     /* Check for open Cells */
00714     if (current_cell != NULL) {
00715         run = -4;
00716         GDS_ERROR("Closing Library with opened cells");

```

```

00717         break;
00718     }
00719     current_lib = NULL;
00720     GDS_INF("Leaving Library\n");
00721     break;
00722 case BGNSTR:
00723     if (current_lib == NULL) {
00724         GDS_ERROR("Defining Cell outside of library!\n");
00725         run = -4;
00726         break;
00727     }
00728     current_lib->cells = append_cell(current_lib->cells, &current_cell);
00729     if (current_lib->cells == NULL) {
00730         GDS_ERROR("Allocating memory failed");
00731         run = -3;
00732         break;
00733     }
00734
00735     current_cell->parent_library = current_lib;
00736
00737     GDS_INF("Entering cell\n");
00738     break;
00739 case ENDSTR:
00740     if (current_cell == NULL) {
00741         run = -4;
00742         GDS_ERROR("Closing cell with no opened cell");
00743         break;
00744     }
00745     /* Check for open Elements */
00746     if (current_graphics != NULL || current_s_reference != NULL) {
00747         run = -4;
00748         GDS_ERROR("Closing cell with opened Elements");
00749         break;
00750     }
00751     current_cell = NULL;
00752     GDS_INF("Leaving Cell\n");
00753     break;
00754 case BOX:
00755 case BOUNDARY:
00756     if (current_cell == NULL) {
00757         GDS_ERROR("Boundary/Box outside of cell");
00758         run = -3;
00759         break;
00760     }
00761     current_cell->graphic_objs = append_graphics(current_cell->
graphic_objs,
00762         (rec_type == BOUNDARY ?
GRAPHIC_POLYGON : GRAPHIC_BOX),
00763         &current_graphics);
00764     if (current_cell->graphic_objs == NULL) {
00765         GDS_ERROR("Memory allocation failed");
00766         run = -4;
00767         break;
00768     }
00769     GDS_INF("\tEntering boundary/Box\n");
00770     break;
00771 case SREF:
00772     if (current_cell == NULL) {
00773         GDS_ERROR("Cell Reference outside of cell");
00774         run = -3;
00775         break;
00776     }
00777     current_cell->child_cells = append_cell_ref(current_cell->
child_cells,
00778         &current_s_reference);
00779     if (current_cell->child_cells == NULL) {
00780         GDS_ERROR("Memory allocation failed");
00781         run = -4;
00782         break;
00783     }
00784
00785     GDS_INF("\tEntering reference\n");
00786     break;
00787 case PATH:
00788     if (current_cell == NULL) {
00789         GDS_ERROR("Path outside of cell");
00790         run = -3;
00791         break;
00792     }
00793     current_cell->graphic_objs = append_graphics(current_cell->
graphic_objs,
00794         GRAPHIC_PATH, &current_graphics);
00795     if (current_cell->graphic_objs == NULL) {
00796         GDS_ERROR("Memory allocation failed");
00797         run = -4;
00798         break;
00799     }

```

```

00800         GDS_INF("\tEntering Path\n");
00801         break;
00802     case ENDEL:
00803         if (current_graphics != NULL) {
00804             GRAPHIC_POLYGON ? "boundary" : "path");
00805             current_graphics = NULL;
00806         }
00807         if (current_s_reference != NULL) {
00808             GDS_INF("\tLeaving Reference\n");
00809             current_s_reference = NULL;
00810         }
00811         if (current_a_reference != NULL) {
00812             GDS_INF("\tLeaving Array Reference\n");
00813             convert_aref_to_sref(current_a_reference, current_cell);
00814             current_a_reference = NULL;
00815         }
00816     }
00817     break;
00818     case XY:
00819         if (current_graphics) {
00820         } else if (current_s_reference) {
00821             if (rec_data_length != 8) {
00822                 GDS_WARN("Instance has weird coordinates. Rendered output might be screwed!");
00823             }
00824         } else if (current_a_reference) {
00825             if (rec_data_length != (3*(4+4)))
00826                 GDS_WARN("Array instance has weird coordinates. Rendered output might be
00827 screwed!");
00828         }
00829         break;
00830     case AREF:
00831         if (current_cell == NULL) {
00832             GDS_ERROR("Cell array reference outside of cell");
00833             run = -3;
00834             break;
00835         }
00836
00837         if (current_a_reference != NULL) {
00838             GDS_ERROR("Recursive cell array reference");
00839             run = -3;
00840             break;
00841         }
00842
00843         GDS_INF("Entering Array Reference\n");
00844
00845         /* Array references are converted after fully declared. Therefore,
00846          * only a static buffer is needed
00847          */
00848         current_a_reference = &temp_a_reference;
00849         current_a_reference->ref_name[0] = '\0';
00850         current_a_reference->angle = 0.0;
00851         current_a_reference->magnification = 1.0;
00852         current_a_reference->flipped = 0;
00853         current_a_reference->rows = 0;
00854         current_a_reference->columns = 0;
00855         break;
00856     case COLROW:
00857     case MAG:
00858     case ANGLE:
00859     case STRANS:
00860     case WIDTH:
00861     case PATHTYPE:
00862     case UNITS:
00863     case LIBNAME:
00864     case SNAME:
00865     case LAYER:
00866     case STRNAME:
00867         break;
00868     default:
00869         GDS_INF("Unhandled Record: %04x, len: %u\n", (unsigned int)rec_type, (unsigned int)
rec_data_length);
00870         break;
00871     } /* switch(rec_type) */
00872
00873
00874     /* No Data -> No Processing, go back to top */
00875     if (!rec_data_length || run != 1) continue;
00876
00877     read = fread(workbuff, sizeof(char), rec_data_length, gds_file);
00878
00879     if (read != rec_data_length) {
00880         GDS_ERROR("Could not read enough data: requested: %u, read: %u | Type: 0x%04x\n",
00881             (unsigned int)rec_data_length, (unsigned int)read, (unsigned int)rec_type);
00882         run = -5;
00883         break;

```



```

00884     }
00885
00886     switch (rec_type) {
00887     case AREF:
00888     case HEADER:
00889     case ENDLIB:
00890     case ENDSTR:
00891     case BOUNDARY:
00892     case PATH:
00893     case SREF:
00894     case ENDEL:
00895     case BOX:
00896     case INVALID:
00897         break;
00898
00899     case COLROW:
00900         if (!current_a_reference) {
00901             GDS_ERROR("COLROW record defined outside of array instance");
00902             break;
00903         }
00904         if (rec_data_length != 4 || read != 4) {
00905             GDS_ERROR("COLUMN/ROW count record contains too few data. Won't set column and row
counts (%d, %d)",
00906                 rec_data_length, read);
00907             break;
00908         }
00909         current_a_reference->columns = (int)gds_convert_signed_int16(&
workbuff[0]);
00910         current_a_reference->rows = (int)gds_convert_signed_int16(&workbuff
[2]);
00911         GDS_INF("\tRows: %d\n\tColumns: %d\n", current_a_reference->
rows, current_a_reference->columns);
00912         break;
00913     case UNITS:
00914         if (!current_lib) {
00915             GDS_WARN("Units defined outside of library!\n");
00916             break;
00917         }
00918
00919         if (rec_data_length != 16) {
00920             GDS_WARN("Unit define incomplete. Will assume database unit of %E meters\n",
current_lib->unit_in_meters);
00921             break;
00922         }
00923
00924         current_lib->unit_in_meters = gds_convert_double(&workbuff[8]);
00925         GDS_INF("Length of database unit: %E meters\n", current_lib->
unit_in_meters);
00926         break;
00927     case BGNLIB:
00928         /* Parse date record */
00929         gds_parse_date(workbuff, read, &current_lib->mod_time, &current_lib->
access_time);
00930         break;
00931     case BGNSTR:
00932         gds_parse_date(workbuff, read, &current_cell->mod_time, &current_cell->
access_time);
00933         break;
00934     case LIBNAME:
00935         name_library(current_lib, (unsigned int)read, workbuff);
00936         break;
00937     case STRNAME:
00938         name_cell(current_cell, (unsigned int)read, workbuff, current_lib);
00939         break;
00940     case XY:
00941         if (current_s_reference) {
00942             /* Get origin of reference */
00943             current_s_reference->origin.x = gds_convert_signed_int (
workbuff);
00944             current_s_reference->origin.y = gds_convert_signed_int (&
workbuff[4]);
00945             GDS_INF("\t\tSet origin to: %d/%d\n", current_s_reference->
origin.x,
00946                 current_s_reference->origin.y);
00947         } else if (current_graphics) {
00948             for (i = 0; i < read/8; i++) {
00949                 x = gds_convert_signed_int (&workbuff[i*8]);
00950                 y = gds_convert_signed_int (&workbuff[i*8+4]);
00951                 current_graphics->vertices =
00952                     append_vertex(current_graphics->
vertices, x, y);
00953                 GDS_INF("\t\tSet coordinate: %d/%d\n", x, y);
00954             }
00955         }
00956     } else if (current_a_reference) {
00957         for (i = 0; i < 3; i++) {
00958             x = gds_convert_signed_int (&workbuff[i*8]);

```

```

00959         y = gds_convert_signed_int(&workbuff[i*8+4]);
00960         current_a_reference->control_points[i].x = x;
00961         current_a_reference->control_points[i].y = y;
00962         GDS_INF("\tSet control point %d: %d/%d\n", i, x, y);
00963     }
00964 }
00965 break;
00966 case STRANS:
00967     if (current_s_reference) {
00968         current_s_reference->flipped = ((workbuff[0] & 0x80) ? 1 : 0);
00969     } else if (current_a_reference) {
00970         current_a_reference->flipped = ((workbuff[0] & 0x80) ? 1 : 0);
00971     } else {
00972         GDS_ERROR("Transformation defined outside of instance");
00973         break;
00974     }
00975 break;
00976 case SNAME:
00977     if (current_s_reference) {
00978         name_cell_ref(current_s_reference, (unsigned int)read, workbuff);
00979     } else if (current_a_reference) {
00980         name_array_cell_ref(current_a_reference, (unsigned int)read, workbuff);
00981     } else {
00982         GDS_ERROR("reference name set outside of cell reference.\n");
00983     }
00984 break;
00985 case WIDTH:
00986     if (!current_graphics) {
00987         GDS_WARN("Width defined outside of path element");
00988     }
00989     current_graphics->width_absolute =
00990     gds_convert_signed_int(workbuff);
00991 break;
00992 case LAYER:
00993     if (!current_graphics) {
00994         GDS_WARN("Layer has to be defined inside graphics object. Probably unknown object.
Implement it yourself!");
00995         break;
00996     }
00997     current_graphics->layer = gds_convert_signed_int16(workbuff);
00998     if (current_graphics->layer < 0) {
00999         GDS_WARN("Layer negative!\n");
01000     }
01001     GDS_INF("\t\tAdded layer %d\n", (int)current_graphics->layer);
01002 break;
01003 case MAG:
01004     if (rec_data_length != 8) {
01005         GDS_WARN("Magnification is not an 8 byte real. Results may be wrong");
01006     }
01007     if (current_graphics != NULL && current_s_reference != NULL) {
01008         GDS_ERROR("Open Graphics and Cell Reference\n\tMissing ENDEL?");
01009         run = -6;
01010         break;
01011     }
01012     if (current_s_reference != NULL) {
01013         current_s_reference->magnification =
01014         gds_convert_double(workbuff);
01015         GDS_INF("\t\tMagnification defined: %lf\n", current_s_reference->
magnification);
01016     }
01017     if (current_a_reference != NULL) {
01018         current_a_reference->magnification =
01019         gds_convert_double(workbuff);
01020         GDS_INF("\t\tMagnification defined: %lf\n", current_a_reference->
magnification);
01021     }
01022 break;
01023 case ANGLE:
01024     if (rec_data_length != 8) {
01025         GDS_WARN("Angle is not an 8 byte real. Results may be wrong");
01026     }
01027     if (current_graphics != NULL && current_s_reference != NULL && current_a_reference != NULL) {
01028         GDS_ERROR("Open Graphics and Cell Reference\n\tMissing ENDEL?");
01029         run = -6;
01030         break;
01031     }
01032     if (current_s_reference != NULL) {
01033         current_s_reference->angle = gds_convert_double(workbuff);
01034         GDS_INF("\t\tAngle defined: %lf\n", current_s_reference->
angle);
01035     }
01036     if (current_a_reference != NULL) {
01037         current_a_reference->angle = gds_convert_double(workbuff);
01038         GDS_INF("\t\tAngle defined: %lf\n", current_a_reference->
angle);
01039     }
01040 break;

```

```

01038     case PATHTYPE:
01039         if (current_graphics == NULL) {
01040             GDS_WARN("Path type defined outside of path. Ignoring");
01041             break;
01042         }
01043         if (current_graphics->gfx_type == GRAPHIC_PATH) {
01044             current_graphics->path_render_type = (enum
01045 path_type)gds_convert_signed_int16(workbuff);
01045             GDS_INF("\t\tPathtype: %d\n", current_graphics->
path_render_type);
01046         } else {
01047             GDS_WARN("Path type defined inside non-path graphics object. Ignoring");
01048         }
01049         break;
01050     }
01051 }
01052 } /* while(run == 1) */
01053
01054 fclose(gds_file);
01055
01056 if (!run) {
01057     /* Iterate and find references to cells */
01058     g_list_foreach(lib_list, scan_library_references, NULL);
01059 }
01060
01061 *library_list = lib_list;
01062
01063 free(workbuff);
01064
01065 return run;
01066 }
01067 }
01068
01073 static void delete_cell_inst_element(struct
gds_cell_instance *cell_inst)
01074 {
01075     if (cell_inst)
01076         free(cell_inst);
01077 }
01078
01083 static void delete_vertex(struct gds_point *vertex)
01084 {
01085     if (vertex)
01086         free(vertex);
01087 }
01088
01093 static void delete_graphics_obj(struct gds_graphics *gfx)
01094 {
01095     if (!gfx)
01096         return;
01097
01098     g_list_free_full(gfx->vertices, (GDestroyNotify)delete_vertex);
01099     free(gfx);
01100 }
01101
01106 static void delete_cell_element(struct gds_cell *cell)
01107 {
01108     if (!cell)
01109         return;
01110
01111     g_list_free_full(cell->child_cells, (GDestroyNotify)
delete_cell_inst_element);
01112     g_list_free_full(cell->graphic_objs, (GDestroyNotify)
delete_graphics_obj);
01113     free(cell);
01114 }
01115
01120 static void delete_library_element(struct gds_library *lib)
01121 {
01122     if (!lib)
01123         return;
01124
01125     g_list_free(lib->cell_names);
01126     g_list_free_full(lib->cells, (GDestroyNotify)delete_cell_element);
01127     free(lib);
01128 }
01129
01130 int clear_lib_list(GList **library_list)
01131 {
01132     if (!library_list)
01133         return 0;
01134
01135     if (*library_list == NULL)
01136         return 0;
01137
01138     g_list_free_full(*library_list, (GDestroyNotify)delete_library_element);
01139     *library_list = NULL;

```

```

01140     return 0;
01141 }
01142

```

13.31 gds-parser.h File Reference


Header file for the GDS-Parser.

```


#include <glib.h>
#include <gds-render/gds-utils/gds-types.h>

```

Include dependency graph for gds-parser.h:



This graph shows which files directly or indirectly include this file:



Macros

- `#define GDS_PRINT_DEBUG_INFOS (0)`
1: Print infos, 0: Don't print

Functions

- int `parse_gds_from_file` (const char *filename, GList **library_list)
- int `clear_lib_list` (GList **library_list)

Deletes all libraries including cells, references etc.

13.31.1 Detailed Description

Header file for the GDS-Parser.

Author

Mario Hüttel mario.huettel@gmx.net

Definition in file [gds-parser.h](#).

13.32 gds-parser.h

```

00001 /*
00002  * GDSII-Converter
00003  * Copyright (C) 2018 Mario Hüttel <mario.huettel@gmx.net>
00004  *
00005  * This file is part of GDSII-Converter.
00006  *
00007  * GDSII-Converter is free software: you can redistribute it and/or modify
00008  * it under the terms of the GNU General Public License version 2 as
00009  * published by the Free Software Foundation.
00010  *
00011  * GDSII-Converter is distributed in the hope that it will be useful,
00012  * but WITHOUT ANY WARRANTY; without even the implied warranty of
00013  * MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE. See the
00014  * GNU General Public License for more details.
00015  *
00016  * You should have received a copy of the GNU General Public License
00017  * along with GDSII-Converter. If not, see <http://www.gnu.org/licenses/>.
00018  */
00019
00031 #ifndef _GDSPARSER_H_
00032 #define _GDSPARSER_H_
00033
00034 #include <glib.h>
00035
00036 #include <gds-render/gds-utils/gds-types.h>
00037
00038 #define GDS_PRINT_DEBUG_INFOS (0)
00040 int parse_gds_from_file(const char *filename, GList **library_array);
00041
00046 int clear_lib_list(GList **library_list);
00047
00050 #endif /* _GDSPARSE_H_ */

```

13.33 gds-render-gui.c File Reference

Handling of GUI.


```

#include <stdio.h>
#include <gtk/gtk.h>
#include <gds-render/gds-render-gui.h>
#include <gds-render/gds-utils/gds-parser.h>
#include <gds-render/gds-utils/gds-tree-checker.h>
#include <gds-render/layer/layer-selector.h>

```

```
#include <gds-render/tree-renderer/tree-store.h>
#include <gds-render/tree-renderer/lib-cell-renderer.h>
#include <gds-render/latex-renderer/latex-output.h>
#include <gds-render/cairo-renderer/cairo-output.h>
#include <gds-render/widgets/conv-settings-dialog.h>
#include <gds-render/geometric/cell-geometrics.h>
#include <gds-render/version.h>
```

Include dependency graph for gds-render-gui.c:



Data Structures

- struct [_GdsRenderGui](#)

Enumerations

- enum [gds_render_gui_signal_sig_ids](#) { [SIGNAL_WINDOW_CLOSED](#) = 0, [SIGNAL_COUNT](#) }

Functions

- static gboolean [on_window_close](#) (gpointer window, GdkEvent *event, gpointer user)

Main window close event.
- static GString * [generate_string_from_date](#) (struct [gds_time_field](#) *date)

generate string from [gds_time_field](#)
- static void [on_load_gds](#) (gpointer button, gpointer user)

Callback function of Load GDS button.
- static void [on_convert_clicked](#) (gpointer button, gpointer user)

Convert button callback.
- static void [cell_tree_view_activated](#) (gpointer tree_view, GtkTreePath *path, GtkTreeViewColumn *column, gpointer user)

cell_tree_view_activated Callback for 'double click' on cell selector element
- static void [cell_selection_changed](#) (GtkTreeSelection *sel, GdsRenderGui *self)

Callback for cell-selection change event.
- static void [sort_up_callback](#) (GtkWidget *widget, gpointer user)
- static void [sort_down_callback](#) (GtkWidget *widget, gpointer user)
- static void [gds_render_gui_dispose](#) (GObject *gobject)
- static void [gds_render_gui_class_init](#) (GdsRenderGuiClass *klass)
- GtkWidget * [gds_render_gui_get_main_window](#) (GdsRenderGui *gui)

Get main window.
- static void [gds_render_gui_init](#) (GdsRenderGui *self)
- GdsRenderGui * [gds_render_gui_new](#) ()

Create new GdsRenderGui Object.

Variables

- static quint [gds_render_gui_signals](#) [SIGNAL_COUNT]

13.33.1 Detailed Description

Handling of GUI.

Author

Mario Hüttel mario.huettel@gmx.net

Definition in file [gds-render-gui.c](#).

13.34 gds-render-gui.c

```

00001 /*
00002  * GDSII-Converter
00003  * Copyright (C) 2018 Mario Hüttel <mario.huettel@gmx.net>
00004  *
00005  * This file is part of GDSII-Converter.
00006  *
00007  * GDSII-Converter is free software: you can redistribute it and/or modify
00008  * it under the terms of the GNU General Public License version 2 as
00009  * published by the Free Software Foundation.
00010  *
00011  * GDSII-Converter is distributed in the hope that it will be useful,
00012  * but WITHOUT ANY WARRANTY; without even the implied warranty of
00013  * MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE. See the
00014  * GNU General Public License for more details.
00015  *
00016  * You should have received a copy of the GNU General Public License
00017  * along with GDSII-Converter. If not, see <http://www.gnu.org/licenses/>.
00018  */
00019
00030 #include <stdio.h>
00031 #include <gtk/gtk.h>
00032
00033 #include <gds-render/gds-render-gui.h>
00034 #include <gds-render/gds-utils/gds-parser.h>
00035 #include <gds-render/gds-utils/gds-tree-checker.h>
00036 #include <gds-render/layer/layer-selector.h>
00037 #include <gds-render/tree-renderer/tree-store.h>
00038 #include <gds-render/tree-renderer/lib-cell-renderer.h>
00039 #include <gds-render/latex-renderer/latex-output.h>
00040 #include <gds-render/cairo-renderer/cairo-output.h>
00041 #include <gds-render/widgets/conv-settings-dialog.h>
00042 #include <gds-render/geometric/cell-geometrics.h>
00043 #include <gds-render/version.h>
00044
00045 enum gds_render_gui_signal_sig_ids {
00046     SIGNAL_WINDOW_CLOSED = 0, SIGNAL_COUNT};
00047 static quint gds_render_gui_signals[SIGNAL_COUNT];
00048
00049 struct _GdsRenderGui {
00050     /* Parent GObject */
00051     GObject parent;
00052
00053     /* Custom fields */
00054     GtkWidget *main_window;
00055     GtkWidget *convert_button;
00056     GtkTreeStore *cell_tree_store;
00057     GtkWidget *cell_search_entry;
00058     LayerSelector *layer_selector;
00059     GtkTreeView *cell_tree_view;
00060     GList *gds_libraries;
00061     struct render_settings render_dialog_settings;
00062 };
00063
00064 G_DEFINE_TYPE(GdsRenderGui, gds_render_gui, G_TYPE_OBJECT)
00065

```

```

00066
00073 static gboolean on_window_close(gpointer window, GdkEvent *event, gpointer user)
00074 {
00075     GdsRenderGui *self;
00076
00077     self = RENDERER_GUI(user);
00078     /* Don't close window in case of error */
00079     if (!self)
00080         return TRUE;
00081
00082     /* Close Window. Leads to termination of the program/the current instance */
00083     g_clear_object(&self->main_window);
00084     gtk_widget_destroy(GTK_WIDGET(window));
00085
00086     /* Delete loaded library data */
00087     clear_lib_list(&self->gds_libraries);
00088
00089     g_signal_emit(self, gds_render_gui_signals[
00090         SIGNAL_WINDOW_CLOSED], 0);
00091
00092     return TRUE;
00093 }
00093
00099 static GString *generate_string_from_date(struct
00100     gds_time_field *date)
00101 {
00102     GString *str;
00103
00104     str = g_string_new_len(NULL, 50);
00105     g_string_printf(str, "%02u.%02u.%u - %02u:%02u",
00106         (unsigned int)date->day,
00107         (unsigned int)date->month,
00108         (unsigned int)date->year,
00109         (unsigned int)date->hour,
00110         (unsigned int)date->minute);
00111     return str;
00112 }
00112
00118 static void on_load_gds(gpointer button, gpointer user)
00119 {
00120     GList *cell;
00121     GtkTreeIter libiter;
00122     GtkTreeIter celliter;
00123     GList *lib;
00124     struct gds_library *gds_lib;
00125     struct gds_cell *gds_c;
00126     GdsRenderGui *self;
00127     GtkWidget *open_dialog;
00128     GtkFileChooser *file_chooser;
00129     GtkFileFilter *filter;
00130     GtkStyleContext *button_style;
00131     gint dialog_result;
00132     int gds_result;
00133     char *filename;
00134     GString *mod_date;
00135     GString *acc_date;
00136     unsigned int cell_error_level;
00137
00138     self = RENDERER_GUI(user);
00139     if (!self)
00140         return;
00141
00142     open_dialog = gtk_file_chooser_dialog_new("Open GDSII File", self->main_window,
00143         GTK_FILE_CHOOSER_ACTION_OPEN,
00144         "Cancel", GTK_RESPONSE_CANCEL,
00145         "Open GDSII", GTK_RESPONSE_ACCEPT,
00146         NULL);
00147     file_chooser = GTK_FILE_CHOOSER(open_dialog);
00148
00149     /* Add GDS II Filter */
00150     filter = gtk_file_filter_new();
00151     gtk_file_filter_add_pattern(filter, "*.gds");
00152     gtk_file_filter_set_name(filter, "GDSII-Files");
00153     gtk_file_chooser_add_filter(file_chooser, filter);
00154
00155     dialog_result = gtk_dialog_run(GTK_DIALOG(open_dialog));
00156
00157     if (dialog_result != GTK_RESPONSE_ACCEPT)
00158         goto end_destroy;
00159
00160     /* Get File name */
00161     filename = gtk_file_chooser_get_filename(file_chooser);
00162
00163     gtk_tree_store_clear(self->cell_tree_store);
00164     clear_lib_list(&self->gds_libraries);
00165
00166     /* Parse new GDSII file */

```



```

00167     gds_result = parse_gds_from_file(filename, &self->gds_libraries);
00168
00169     /* Delete file name afterwards */
00170     g_free(filename);
00171     if (gds_result)
00172         goto end_destroy;
00173
00174     /* remove suggested action from Open button */
00175     button_style = gtk_widget_get_style_context(GTK_WIDGET(button));
00176     gtk_style_context_remove_class(button_style, "suggested-action");
00177
00178     for (lib = self->gds_libraries; lib != NULL; lib = lib->next) {
00179         gds_lib = (struct gds_library *)lib->data;
00180         /* Create top level iter */
00181         gtk_tree_store_append(self->cell_tree_store, &libiter, NULL);
00182
00183         /* Convert dates to String */
00184         mod_date = generate_string_from_date(&gds_lib->
mod_time);
00185         acc_date = generate_string_from_date(&gds_lib->
access_time);
00186
00187         gtk_tree_store_set(self->cell_tree_store, &libiter,
00188             CELL_SEL_LIBRARY, gds_lib,
00189             CELL_SEL_MODDATE, mod_date->str,
00190             CELL_SEL_ACCESSDATE, acc_date->str,
00191             -1);
00192
00193         /* Check this library. This might take a while */
00194         (void)gds_tree_check_cell_references(gds_lib);
00195         (void)gds_tree_check_reference_loops(gds_lib);
00196         /* Delete GStrings including string data. */
00197         /* Cell store copies String type data items */
00198         g_string_free(mod_date, TRUE);
00199         g_string_free(acc_date, TRUE);
00200
00201         for (cell = gds_lib->cells; cell != NULL; cell = cell->next) {
00202             gds_c = (struct gds_cell *)cell->data;
00203             gtk_tree_store_append(self->cell_tree_store, &celliter, &libiter);
00204             /* Convert dates to String */
00205             mod_date = generate_string_from_date(&gds_c->
mod_time);
00206             acc_date = generate_string_from_date(&gds_c->
access_time);
00207
00208             /* Get the checking results for this cell */
00209             cell_error_level = 0;
00210             if (gds_c->checks.unresolved_child_count)
00211                 cell_error_level |= LIB_CELL_RENDERER_ERROR_WARN;
00212
00213             /* Check if it is completely broken */
00214             if (gds_c->checks.affected_by_reference_loop)
00215                 cell_error_level |= LIB_CELL_RENDERER_ERROR_ERR;
00216
00217             /* Add cell to tree store model */
00218             gtk_tree_store_set(self->cell_tree_store, &celliter,
00219                 CELL_SEL_CELL, gds_c,
00220                 CELL_SEL_MODDATE, mod_date->str,
00221                 CELL_SEL_ACCESSDATE, acc_date->str,
00222                 CELL_SEL_CELL_ERROR_STATE, cell_error_level,
00223                 -1);
00224
00225             /* Delete GStrings including string data. */
00226             /* Cell store copies String type data items */
00227             g_string_free(mod_date, TRUE);
00228             g_string_free(acc_date, TRUE);
00229         } /* for cells */
00230     } /* for libraries */
00231
00232     /* Create Layers in Layer Box */
00233     layer_selector_generate_layer_widgets(self->layer_selector, self->
gds_libraries);
00234
00235 end_destroy:
00236     /* Destroy dialog and filter */
00237     gtk_widget_destroy(open_dialog);
00238 }
00239
00245 static void on_convert_clicked(gpointer button, gpointer user)
00246 {
00247     (void)button;
00248     GdsRenderGui *self;
00249     GtkTreeSelection *selection;
00250     GtkTreeIter iter;
00251     GtkTreeModel *model;
00252     GList *layer_list;
00253     struct gds_cell *cell_to_render;

```

```

00254     FILE *output_file;
00255     GtkWidget *dialog;
00256     RendererSettingsDialog *settings;
00257     GtkFileFilter *filter;
00258     gint res;
00259     char *file_name;
00260     union bounding_box cell_box;
00261     unsigned int height, width;
00262     struct render_settings *sett;
00263
00264     self = RENDERER_GUI(user);
00265
00266     if (!self)
00267         return;
00268
00269     sett = &self->render_dialog_settings;
00270
00271     /* Get selected cell */
00272     selection = gtk_tree_view_get_selection(self->cell_tree_view);
00273     if (gtk_tree_selection_get_selected(selection, &model, &iter) == FALSE)
00274         return;
00275
00276     gtk_tree_model_get(model, &iter, CELL_SEL_CELL, &cell_to_render, -1);
00277
00278     if (!cell_to_render)
00279         return;
00280
00281     /* Get layers that are rendered */
00282     layer_list = layer_selector_export_rendered_layer_info(self->
layer_selector);
00283
00284     /* Calculate cell size in DB units */
00285     bounding_box_prepare_empty(&cell_box);
00286     calculate_cell_bounding_box(&cell_box, cell_to_render);
00287
00288     /* Calculate size in database units
00289     * Note that the results are bound to be positive,
00290     * so casting them to unsigned int is absolutely valid
00291     */
00292     height = (unsigned int)(cell_box.vectors.upper_right.y - cell_box.
vectors.lower_left.y);
00293     width = (unsigned int)(cell_box.vectors.upper_right.x - cell_box.
vectors.lower_left.x);
00294
00295     /* Show settings dialog */
00296     settings = renderer_settings_dialog_new(GTK_WINDOW(self->main_window));
00297     renderer_settings_dialog_set_settings(settings, sett);
00298     renderer_settings_dialog_set_database_unit_scale(
settings, cell_to_render->parent_library->unit_in_meters);
00299     renderer_settings_dialog_set_cell_height(settings, height);
00300     renderer_settings_dialog_set_cell_width(settings, width);
00301     g_object_set(G_OBJECT(settings), "cell-name", cell_to_render->name, NULL);
00302
00303     res = gtk_dialog_run(GTK_DIALOG(settings));
00304     if (res == GTK_RESPONSE_OK) {
00305         renderer_settings_dialog_get_settings(settings, sett);
00306         gtk_widget_destroy(GTK_WIDGET(settings));
00307     } else {
00308         gtk_widget_destroy(GTK_WIDGET(settings));
00309         goto ret_layer_destroy;
00310     }
00311
00312     /* save file dialog */
00313     dialog = gtk_file_chooser_dialog_new((sett->renderer ==
RENDERER_LATEX_TIKZ
00314                                     ? "Save LaTeX File" : "Save PDF"),
00315                                     GTK_WINDOW(self->main_window), GTK_FILE_CHOOSER_ACTION_SAVE,
00316                                     "Cancel", GTK_RESPONSE_CANCEL, "Save", GTK_RESPONSE_ACCEPT, NULL);
00317     /* Set file filter according to settings */
00318     filter = gtk_file_filter_new();
00319     switch (sett->renderer) {
00320     case RENDERER_LATEX_TIKZ:
00321         gtk_file_filter_add_pattern(filter, "*.tex");
00322         gtk_file_filter_set_name(filter, "LaTeX-Files");
00323         break;
00324     case RENDERER_CAIROGRAPHICS_PDF:
00325         gtk_file_filter_add_pattern(filter, "*.pdf");
00326         gtk_file_filter_set_name(filter, "PDF-Files");
00327         break;
00328     case RENDERER_CAIROGRAPHICS_SVG:
00329         gtk_file_filter_add_pattern(filter, "*.svg");
00330         gtk_file_filter_set_name(filter, "SVG-Files");
00331         break;
00332     }
00333
00334     gtk_file_chooser_add_filter(GTK_FILE_CHOOSER(dialog), filter);
00335

```

```

00336     gtk_file_chooser_set_do_overwrite_confirmation(GTK_FILE_CHOOSER(dialog), TRUE);
00337
00338     res = gtk_dialog_run(GTK_DIALOG(dialog));
00339     if (res == GTK_RESPONSE_ACCEPT) {
00340         file_name = gtk_file_chooser_get_filename(GTK_FILE_CHOOSER(dialog));
00341         gtk_widget_destroy(dialog);
00342
00343         switch (sett->renderer) {
00344             case RENDERER_LATEX_TIKZ:
00345                 output_file = fopen(file_name, "w");
00346                 latex_render_cell_to_code(cell_to_render, layer_list, output_file,
sett->scale,
00347                                     sett->tex_pdf_layers, sett->
tex_standalone);
00348                 fclose(output_file);
00349                 break;
00350             case RENDERER_CAIROGRAPHICS_SVG:
00351             case RENDERER_CAIROGRAPHICS_PDF:
00352                 cairo_render_cell_to_vector_file(cell_to_render, layer_list,
00353                                                 (sett->renderer ==
RENDERER_CAIROGRAPHICS_PDF
00354                                                  ? file_name
00355                                                  : NULL),
00356                                                 (sett->renderer ==
RENDERER_CAIROGRAPHICS_SVG
00357                                                  ? file_name
00358                                                  : NULL),
00359                                                 sett->scale);
00360                 break;
00361             }
00362             g_free(file_name);
00363         } else {
00364             gtk_widget_destroy(dialog);
00365         }
00366     }
00367     ret_layer_destroy:
00368     g_list_free_full(layer_list, (GDestroyNotify)layer_info_delete_struct);
00369 }
00370
00378 static void cell_tree_view_activated(gpointer tree_view, GtkTreePath *path,
00379                                     GtkTreeViewColumn *column, gpointer user)
00380 {
00381     (void)tree_view;
00382     (void)path;
00383     (void)column;
00384
00385     on_convert_clicked(NULL, user);
00386 }
00387
00388
00397 static void cell_selection_changed(GtkTreeSelection *sel, GdsRenderGui *self)
00398 {
00399     GtkTreeModel *model = NULL;
00400     GtkTreeIter iter;
00401
00402     if (gtk_tree_selection_get_selected(sel, &model, &iter)) {
00403         /* Node selected. Show button */
00404         gtk_widget_set_sensitive(self->convert_button, TRUE);
00405     } else {
00406         gtk_widget_set_sensitive(self->convert_button, FALSE);
00407     }
00408 }
00409
00410 static void sort_up_callback(GtkWidget *widget, gpointer user)
00411 {
00412     (void)widget;
00413     GdsRenderGui *self;
00414
00415     self = RENDERER_GUI(user);
00416     if (!self)
00417         return;
00418     layer_selector_force_sort(self->layer_selector,
LAYER_SELECTOR_SORT_UP);
00419 }
00420
00421 static void sort_down_callback(GtkWidget *widget, gpointer user)
00422 {
00423     (void)widget;
00424     GdsRenderGui *self;
00425
00426     self = RENDERER_GUI(user);
00427     if (!self)
00428         return;
00429     layer_selector_force_sort(self->layer_selector,
LAYER_SELECTOR_SORT_DOWN);
00430 }
00431

```

```

00432 static void gds_render_gui_dispose(GObject *gobject)
00433 {
00434     GdsRenderGui *self;
00435
00436     self = RENDERER_GUI(gobject);
00437
00438     clear_lib_list(&self->gds_libraries);
00439
00440     g_clear_object(&self->cell_tree_view);
00441     g_clear_object(&self->convert_button);
00442     g_clear_object(&self->layer_selector);
00443     g_clear_object(&self->cell_tree_store);
00444     g_clear_object(&self->cell_search_entry);
00445
00446     if (self->main_window) {
00447         g_signal_handlers_destroy(self->main_window);
00448         gtk_widget_destroy(GTK_WIDGET(self->main_window));
00449         self->main_window = NULL;
00450     }
00451
00452     /* Chain up */
00453     G_OBJECT_CLASS(gds_render_gui_parent_class)->dispose(gobject);
00454 }
00455
00456 static void gds_render_gui_class_init(GdsRenderGuiClass *klass)
00457 {
00458     GObjectClass *gobject_class = G_OBJECT_CLASS(klass);
00459
00460     gds_render_gui_signals[SIGNAL_WINDOW_CLOSED] =
00461         g_signal_newv("window-closed", RENDERER_TYPE_GUI,
00462             G_SIGNAL_RUN_LAST | G_SIGNAL_NO_RECURSE,
00463             NULL,
00464             NULL,
00465             NULL,
00466             NULL,
00467             G_TYPE_NONE,
00468             0,
00469             NULL);
00470
00471     gobject_class->dispose = gds_render_gui_dispose;
00472 }
00473
00474 GtkWidget *gds_render_gui_get_main_window(GdsRenderGui *gui)
00475 {
00476     return gui->main_window;
00477 }
00478
00479 static void gds_render_gui_init(GdsRenderGui *self)
00480 {
00481     GtkBuilder *main_builder;
00482     GtkWidget *listbox;
00483     GtkHeaderBar *header_bar;
00484     struct tree_stores *cell_selector_stores;
00485     GtkWidget *sort_up_button;
00486     GtkWidget *sort_down_button;
00487
00488     main_builder = gtk_builder_new_from_resource("/main.glade");
00489
00490     self->cell_tree_view = GTK_TREE_VIEW(gtk_builder_get_object(main_builder, "cell-tree"));
00491     self->cell_search_entry = GTK_WIDGET(gtk_builder_get_object(main_builder, "cell-search"));
00492
00493     cell_selector_stores = setup_cell_selector(self->cell_tree_view, GTK_ENTRY(self->
cell_search_entry));
00494
00495     self->cell_tree_store = cell_selector_stores->base_store;
00496
00497     self->main_window = GTK_WINDOW(gtk_builder_get_object(main_builder, "main-window"));
00498     g_signal_connect(GTK_WIDGET(gtk_builder_get_object(main_builder, "button-load-gds")),
00499         "clicked", G_CALLBACK(on_load_gds), (gpointer)self);
00500
00501     self->convert_button = GTK_WIDGET(gtk_builder_get_object(main_builder, "convert-button"));
00502     g_signal_connect(self->convert_button, "clicked", G_CALLBACK(
on_convert_clicked), (gpointer)self);
00503
00504     listbox = GTK_WIDGET(gtk_builder_get_object(main_builder, "layer-list"));
00505     /* Create layer selector */
00506     self->layer_selector = layer_selector_new(GTK_LIST_BOX(listbox));
00507
00508
00509     /* Callback for selection change of cell selector */
00510     g_signal_connect(G_OBJECT(gtk_tree_view_get_selection(self->cell_tree_view)), "changed",
00511         G_CALLBACK(cell_selection_changed), self);
00512     g_signal_connect(self->cell_tree_view, "row-activated", G_CALLBACK(
cell_tree_view_activated), self);
00513
00514     /* Set version in main window subtitle */
00515     header_bar = GTK_HEADER_BAR(gtk_builder_get_object(main_builder, "header-bar"));

```

```

00516     gtk_header_bar_set_subtitle(header_bar, _app_version_string);
00517
00518     /* Get layer sorting buttons and set callbacks */
00519     sort_up_button = GTK_WIDGET(gtk_builder_get_object(main_builder, "button-up-sort"));
00520     sort_down_button = GTK_WIDGET(gtk_builder_get_object(main_builder, "button-down-sort"));
00521
00522     g_signal_connect(sort_up_button, "clicked", G_CALLBACK(sort_up_callback), self);
00523     g_signal_connect(sort_down_button, "clicked", G_CALLBACK(sort_down_callback), self);
00524
00525     /* Set buttons for loading and saving */
00526     layer_selector_set_load_mapping_button(self->layer_selector,
00527     GTK_WIDGET(gtk_builder_get_object(main_builder, "button-load-mapping")),
00528     self->main_window);
00529     layer_selector_set_save_mapping_button(self->layer_selector,
00530     GTK_WIDGET(gtk_builder_get_object(main_builder, "button-save-mapping")),
00531     self->main_window);
00532
00533     /* Connect delete-event */
00534     g_signal_connect(GTK_WIDGET(self->main_window), "delete-event",
00535     G_CALLBACK(on_window_close), self);
00536
00537     g_object_unref(main_builder);
00538
00539     /* Set default conversion/rendering settings */
00540     self->render_dialog_settings.scale = 1000;
00541     self->render_dialog_settings.renderer = RENDERER_LATEX_TIKZ;
00542     self->render_dialog_settings.tex_pdf_layers = FALSE;
00543     self->render_dialog_settings.tex_standalone = FALSE;
00544
00545     /* Reference all objects referenced by this object */
00546     g_object_ref(self->main_window);
00547     g_object_ref(self->cell_tree_view);
00548     g_object_ref(self->convert_button);
00549     g_object_ref(self->layer_selector);
00550     g_object_ref(self->cell_tree_store);
00551     g_object_ref(self->cell_search_entry);
00552 }
00553
00554 GdsRenderGui *gds_render_gui_new()
00555 {
00556     return RENDERER_GUI(g_object_new(RENDERER_TYPE_GUI, NULL));
00557 }
00558

```


13.35 gds-render-gui.h File Reference

Header for GdsRenderGui Object.


```

#include <gtk/gtk.h>
Include dependency graph for gds-render-gui.h:

```



This graph shows which files directly or indirectly include this file:



Macros

- #define [RENDERER_TYPE_GUI](#) (gds_render_gui_get_type())

Functions

- G_BEGIN_DECLS [G_DECLARE_FINAL_TYPE](#) (GdsRenderGui, gds_render_gui, RENDERER, GUI, G↔Object)
- GdsRenderGui * [gds_render_gui_new](#) ()
Create new GdsRenderGui Object.
- GtkWidget * [gds_render_gui_get_main_window](#) (GdsRenderGui *gui)
Get main window.

13.35.1 Detailed Description

Header for GdsRenderGui Object.

Author

Mario Hüttel mario.huettel@gmx.net

Definition in file [gds-render-gui.h](#).

13.36 gds-render-gui.h

```

00001 /*
00002  * GDSII-Converter
00003  * Copyright (C) 2018 Mario Hüttel <mario.huettel@gmx.net>
00004  *
00005  * This file is part of GDSII-Converter.
00006  *
00007  * GDSII-Converter is free software: you can redistribute it and/or modify
00008  * it under the terms of the GNU General Public License version 2 as
00009  * published by the Free Software Foundation.
00010  *
00011  * GDSII-Converter is distributed in the hope that it will be useful,
00012  * but WITHOUT ANY WARRANTY; without even the implied warranty of
  
```

```

00013  * MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE.  See the
00014  * GNU General Public License for more details.
00015  *
00016  * You should have received a copy of the GNU General Public License
00017  * along with GDSII-Converter.  If not, see <http://www.gnu.org/licenses/>.
00018  */
00019
00026 #ifndef _GDS_RENDER_GUI_
00027 #define _GDS_RENDER_GUI_
00028
00034 #include <gtk/gtk.h>
00035
00036 G_BEGIN_DECLS
00037
00038 G_DECLARE_FINAL_TYPE(GdsRenderGui, gds_render_gui, RENDERER, GUI, GObject);
00039
00040 #define RENDERER_TYPE_GUI (gds_render_gui_get_type())
00041
00046 GdsRenderGui *gds_render_gui_new();
00047
00055 GtkWidget *gds_render_gui_get_main_window(GdsRenderGui *gui);
00056
00057 G_END_DECLS
00058
00061 #endif /* _GDS_RENDER_GUI_ */

```

13.37 gds-tree-checker.c File Reference


Checking functions of a cell tree.

```

#include <stdio.h>
#include <gds-render/gds-utils/gds-tree-checker.h>

```

Include dependency graph for gds-tree-checker.c:



Functions

- `int gds_tree_check_cell_references (struct gds_library *lib)`

- gds_tree_check_cell_references* checks if all child cell references can be resolved in the given library

 - static int `gds_tree_check_list_contains_cell` (GList *list, struct `gds_cell` *cell)
 - Check if list contains a cell.
 - static int `gds_tree_check_iterate_ref_and_check` (struct `gds_cell` *cell_to_check, GList **visited_cells)
 - This function follows down the reference list of a cell and marks each visited subcell and detects loops.
 - int `gds_tree_check_reference_loops` (struct `gds_library` *lib)
 - gds_tree_check_reference_loops* checks if the given library contains reference loops

13.37.1 Detailed Description

Checking functions of a cell tree.

This file contains checking functions for the GDS cell tree. These functions include checks if all child references could be resolved, and if the cell tree contains loops.

Author

Mario Hüttel mario.huettel@gmx.net

Definition in file [gds-tree-checker.c](#).

13.38 gds-tree-checker.c

```

00001 /*
00002  * GDSII-Converter
00003  * Copyright (C) 2019 Mario Hüttel <mario.huettel@gmx.net>
00004  *
00005  * This file is part of GDSII-Converter.
00006  *
00007  * GDSII-Converter is free software: you can redistribute it and/or modify
00008  * it under the terms of the GNU General Public License version 2 as
00009  * published by the Free Software Foundation.
00010  *
00011  * GDSII-Converter is distributed in the hope that it will be useful,
00012  * but WITHOUT ANY WARRANTY; without even the implied warranty of
00013  * MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE. See the
00014  * GNU General Public License for more details.
00015  *
00016  * You should have received a copy of the GNU General Public License
00017  * along with GDSII-Converter. If not, see <http://www.gnu.org/licenses/>.
00018  */
00019
00036 #include <stdio.h>
00037
00038 #include <gds-render/gds-utils/gds-tree-checker.h>
00039
00040 int gds_tree_check_cell_references(struct
    gds_library *lib)
00041 {
00042     GList *cell_iter;
00043     struct gds_cell *cell;
00044     GList *instance_iter;
00045     struct gds_cell_instance *cell_inst;
00046     int total_unresolved_count = 0;
00047
00048     if (!lib)
00049         return -1;
00050
00051     /* Iterate over all cells in library */
00052     for (cell_iter = lib->cells; cell_iter != NULL; cell_iter = g_list_next(cell_iter)) {
00053         cell = (struct gds_cell *)cell_iter->data;
00054
00055         /* Check if this list element is broken. This should never happen */
00056         if (!cell) {
00057             fprintf(stderr, "Broken cell list item found. Will continue.\n");
00058             continue;
00059         }

```



```

00060
00061     /* Reset the unresolved cell reference counter to 0 */
00062     cell->checks.unresolved_child_count = 0;
00063
00064     /* Iterate through all child cell references and check if the references are set */
00065     for (instance_iter = cell->child_cells; instance_iter != NULL;
00066         instance_iter = g_list_next(instance_iter)) {
00067         cell_inst = (struct gds_cell_instance *)instance_iter->data;
00068
00069         /* Check if broken. This should not happen */
00070         if (!cell_inst) {
00071             fprintf(stderr, "Broken cell list item found in cell %s. Will continue.\n",
00072                 cell->name);
00073             continue;
00074         }
00075
00076         /* Check if instance is valid; else increment "error" counter of cell */
00077         if (!cell_inst->cell_ref) {
00078             total_unresolved_count++;
00079             cell->checks.unresolved_child_count++;
00080         }
00081     }
00082 }
00083
00084 return total_unresolved_count;
00085 }
00086
00093 static int gds_tree_check_list_contains_cell(GList *list, struct
00094     gds_cell *cell) {
00095     GList *iter;
00096
00097     for (iter = list; iter != NULL; iter = g_list_next(iter)) {
00098         if ((struct gds_cell *)iter->data == cell)
00099             return 1;
00100     }
00101     return 0;
00102 }
00103
00110 static int gds_tree_check_iterate_ref_and_check(struct
00111     gds_cell *cell_to_check, GList **visited_cells)
00112 {
00113     GList *ref_iter;
00114     struct gds_cell_instance *ref;
00115     struct gds_cell *sub_cell;
00116     int res;
00117
00118     if (!cell_to_check)
00119         return -1;
00120
00121     /* Check if this cell is already contained in visited cells. This indicates a loop */
00122     if (gds_tree_check_list_contains_cell(*visited_cells, cell_to_check))
00123         return 1;
00124
00125     /* Add cell to visited cell list */
00126     *visited_cells = g_list_append(*visited_cells, (gpointer)cell_to_check);
00127
00128     /* Mark references and process sub cells */
00129     for (ref_iter = cell_to_check->child_cells; ref_iter != NULL; ref_iter = g_list_next(ref_iter)) {
00130         ref = (struct gds_cell_instance *)ref_iter->data;
00131
00132         if (!ref)
00133             return -1;
00134
00135         sub_cell = ref->cell_ref;
00136
00137         /* If cell is not resolved, ignore. No harm there */
00138         if (!sub_cell)
00139             continue;
00140
00141         res = gds_tree_check_iterate_ref_and_check(sub_cell,
00142             visited_cells);
00143         if (res < 0) {
00144             /* Error. return. */
00145             return -3;
00146         } else if (res > 0) {
00147             /* Loop in subcell found. Propagate to top */
00148             return 1;
00149         }
00150     }
00151
00152     /* Remove cell from visited cells */
00153     *visited_cells = g_list_remove(*visited_cells, cell_to_check);
00154
00155     /* No error found in this chain */
00156     return 0;
00157 }

```

```


00156
00157 int gds_tree_check_reference_loops(struct
    gds_library *lib)
00158 {
00159     int res;
00160     int loop_count = 0;
00161     GList *cell_iter;
00162     struct gds_cell *cell_to_check;
00163     GList *visited_cells = NULL;
00164
00165
00166     if (!lib)
00167         return -1;
00168
00169     for (cell_iter = lib->cells; cell_iter != NULL; cell_iter = g_list_next(cell_iter)) {
00170         cell_to_check = (struct gds_cell *)cell_iter->data;
00171
00172         /* A broken cell reference will be counted fatal in this case */
00173         if (!cell_to_check)
00174             return -2;
00175
00176         /* iterate through references and check if loop exists */
00177         res = gds_tree_check_iterate_ref_and_check(cell_to_check, &
    visited_cells);
00178
00179         if (visited_cells) {
00180             /* If cell contains no loop, print error when list not empty.
00181              * In case of a loop, it is completely normal that the list is not empty,
00182              * due to the instant return from gds_tree_check_iterate_ref_and_check()
00183              */
00184             if (res == 0)
00185                 fprintf(stderr, "Visited cell list should be empty. This is a bug. Please report this.\n");
00186             g_list_free(visited_cells);
00187             visited_cells = NULL;
00188         }
00189
00190         if (res < 0) {
00191             /* Error */
00192             return res;
00193         } else if (res > 0) {
00194             /* Loop found: increment loop count and flag cell */
00195             cell_to_check->checks.affected_by_reference_loop = 1;
00196             loop_count++;
00197         } else if (res == 0) {
00198             /* No error found for this cell */
00199             cell_to_check->checks.affected_by_reference_loop = 0;
00200         }
00201
00202     }
00203
00204     return loop_count;
00205 }
00206 }
00207

```


13.39 gds-tree-checker.h File Reference

Checking functions of a cell tree (Header)

```
#include <gds-render/gds-utils/gds-types.h>  
Include dependency graph for gds-tree-checker.h:
```



This graph shows which files directly or indirectly include this file:



Functions

- int [gds_tree_check_cell_references](#) (struct [gds_library](#) *lib)
gds_tree_check_cell_references checks if all child cell references can be resolved in the given library
- int [gds_tree_check_reference_loops](#) (struct [gds_library](#) *lib)
gds_tree_check_reference_loops checks if the given library contains reference loops

13.39.1 Detailed Description

Checking functions of a cell tree (Header)

Author

Mario Hüttel mario.huettel@gmx.net

Definition in file [gds-tree-checker.h](#).

13.40 gds-tree-checker.h

```

00001 /*
00002  * GDSII-Converter
00003  * Copyright (C) 2019 Mario Hüttel <mario.huettel@gmx.net>
00004  *
00005  * This file is part of GDSII-Converter.
00006  *
00007  * GDSII-Converter is free software: you can redistribute it and/or modify
00008  * it under the terms of the GNU General Public License version 2 as
00009  * published by the Free Software Foundation.
00010  *
00011  * GDSII-Converter is distributed in the hope that it will be useful,
00012  * but WITHOUT ANY WARRANTY; without even the implied warranty of
00013  * MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE. See the
00014  * GNU General Public License for more details.
00015  *
00016  * You should have received a copy of the GNU General Public License
00017  * along with GDSII-Converter. If not, see <http://www.gnu.org/licenses/>.
00018  */
00019
00031 #ifndef _GDS_TREE_CHECKER_H_
00032 #define _GDS_TREE_CHECKER_H_
00033
00034 #include <gds-render/gds-utils/gds-types.h>
00035
00049 int gds_tree_check_cell_references(struct
    gds_library *lib);
00050
00057 int gds_tree_check_reference_loops(struct
    gds_library *lib);
00058
00059 #endif /* _GDS_TREE_CHECKER_H_ */
00060

```


13.41 gds-types.h File Reference

Defines types and macros used by the GDS-Parser.


```
#include <stdint.h>
```

```
#include <glib.h>
```

Include dependency graph for gds-types.h:



This graph shows which files directly or indirectly include this file:



Data Structures

- struct [gds_point](#)
A point in the 2D plane. Sometimes references as vertex.
- struct [gds_cell_checks](#)
Stores the result of the cell checks.
- struct [gds_cell_checks::_check_internals](#)
For the internal use of the checker.
- struct [gds_time_field](#)
Date information for cells and libraries.
- struct [gds_graphics](#)
A GDS graphics object.
- struct [gds_cell_instance](#)
This represents an instanc of a cell inside another cell.
- struct [gds_cell](#)
A Cell inside a [gds_library](#).
- struct [gds_library](#)
GDS Toplevel library.

Macros

- #define [CELL_NAME_MAX](#) (100)
Maximum length of a [gds_cell::name](#) or a [gds_library::name](#).
- #define [MIN](#)(a, b) (((a) < (b)) ? (a) : (b))
Return smaller number.
- #define [MAX](#)(a, b) (((a) > (b)) ? (a) : (b))
Return bigger number.

Enumerations

- enum { [GDS_CELL_CHECK_NOT_RUN](#) = -1 }
Definition of check counter default value that indicates that the corresponding check has not yet been executed.
- enum [graphics_type](#) { [GRAPHIC_PATH](#) = 0, [GRAPHIC_POLYGON](#) = 1, [GRAPHIC_BOX](#) = 2 }
Types of graphic objects.
- enum [path_type](#) { [PATH_FLUSH](#) = 0, [PATH_ROUNDED](#) = 1, [PATH_SQUARED](#) = 2 }
Defines the line caps of a path.

13.41.1 Detailed Description

Defines types and macros used by the GDS-Parser.

Author

Mario Hüttel mario.huettel@gmx.net

Definition in file [gds-types.h](#).

13.42 gds-types.h

```

00001 /*
00002  * GDSII-Converter
00003  * Copyright (C) 2018 Mario Hüttel <mario.huettel@gmx.net>
00004  *
00005  * This file is part of GDSII-Converter.
00006  *
00007  * GDSII-Converter is free software: you can redistribute it and/or modify
00008  * it under the terms of the GNU General Public License version 2 as
00009  * published by the Free Software Foundation.
00010  *
00011  * GDSII-Converter is distributed in the hope that it will be useful,
00012  * but WITHOUT ANY WARRANTY; without even the implied warranty of
00013  * MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE. See the
00014  * GNU General Public License for more details.
00015  *
00016  * You should have received a copy of the GNU General Public License
00017  * along with GDSII-Converter. If not, see <http://www.gnu.org/licenses/>.
00018  */
00019
00031 #ifndef __GDS_TYPES_H__
00032 #define __GDS_TYPES_H__
00033
00034 #include <stdint.h>
00035 #include <glib.h>
00036
00037 #define CELL_NAME_MAX (100)
00039 /* Maybe use the macros that ship with the compiler? */
00040 #define MIN(a,b) (((a) < (b)) ? (a) : (b))
00041 #define MAX(a,b) (((a) > (b)) ? (a) : (b))
00045 enum {GDS_CELL_CHECK_NOT_RUN = -1};
00046
00048 enum graphics_type
00049 {
00050     GRAPHIC_PATH = 0,
00051     GRAPHIC_POLYGON = 1,
00052     GRAPHIC_BOX = 2
00053 };
00054
00058 enum path_type {PATH_FLUSH = 0, PATH_ROUNDED = 1,
PATH_SQUARED = 2};
00063 struct gds_point {
00064     int x;
00065     int y;
00066 };
00067
00071 struct gds_cell_checks {
00072     int unresolved_child_count;
00073     int affected_by_reference_loop;
00078     struct _check_internals {
00079         int marker;
00080     } _internal;
00081 };
00082
00086 struct gds_time_field {
00087     uint16_t year;
00088     uint16_t month;
00089     uint16_t day;
00090     uint16_t hour;
00091     uint16_t minute;
00092     uint16_t second;
00093 };
00094
00098 struct gds_graphics {
00099     enum graphics_type gfx_type;
00100     GList *vertices;
00101     enum path_type path_render_type;
00102     int width_absolute;
00103     int16_t layer;
00104     uint16_t datatype;
00105 };
00106
00110 struct gds_cell_instance {
00111     char ref_name[CELL_NAME_MAX];
00112     struct gds_cell *cell_ref;
00113     struct gds_point origin;
00114     int flipped;
00115     double angle;
00116     double magnification;
00117 };
00118
00122 struct gds_cell {
00123     char name[CELL_NAME_MAX];
00124     struct gds_time_field mod_time;
00125     struct gds_time_field access_time;

```

```

00126     GList *child_cells;
00127     GList *graphic_objs;
00128     struct gds_library *parent_library;
00129     struct gds_cell_checks checks;
00130 };
00131
00135 struct gds_library {
00136     char name[CELL_NAME_MAX];
00137     struct gds_time_field mod_time;
00138     struct gds_time_field access_time;
00139     double unit_in_meters;
00140     GList *cells;
00141     GList *cell_names ;
00142 };
00143
00146 #endif /* __GDS_TYPES_H__ */

```

13.43 geometric.dox File Reference

13.44 gpl-2.0.md File Reference

13.45 gpl-2.0.md

```

00001 ### GNU GENERAL PUBLIC LICENSE
00002
00003 Version 2, June 1991
00004
00005     Copyright (C) 1989, 1991 Free Software Foundation, Inc.
00006     51 Franklin Street, Fifth Floor, Boston, MA 02110-1301, USA
00007
00008     Everyone is permitted to copy and distribute verbatim copies
00009     of this license document, but changing it is not allowed.
00010
00011 ### Preamble
00012
00013 The licenses for most software are designed to take away your freedom
00014 to share and change it. By contrast, the GNU General Public License is
00015 intended to guarantee your freedom to share and change free
00016 software--to make sure the software is free for all its users. This
00017 General Public License applies to most of the Free Software
00018 Foundation's software and to any other program whose authors commit to
00019 using it. (Some other Free Software Foundation software is covered by
00020 the GNU Lesser General Public License instead.) You can apply it to
00021 your programs, too.
00022
00023 When we speak of free software, we are referring to freedom, not
00024 price. Our General Public Licenses are designed to make sure that you
00025 have the freedom to distribute copies of free software (and charge for
00026 this service if you wish), that you receive source code or can get it
00027 if you want it, that you can change the software or use pieces of it
00028 in new free programs; and that you know you can do these things.
00029
00030 To protect your rights, we need to make restrictions that forbid
00031 anyone to deny you these rights or to ask you to surrender the rights.
00032 These restrictions translate to certain responsibilities for you if
00033 you distribute copies of the software, or if you modify it.
00034
00035 For example, if you distribute copies of such a program, whether
00036 gratis or for a fee, you must give the recipients all the rights that
00037 you have. You must make sure that they, too, receive or can get the
00038 source code. And you must show them these terms so they know their
00039 rights.
00040
00041 We protect your rights with two steps: (1) copyright the software, and
00042 (2) offer you this license which gives you legal permission to copy,
00043 distribute and/or modify the software.
00044
00045 Also, for each author's protection and ours, we want to make certain
00046 that everyone understands that there is no warranty for this free
00047 software. If the software is modified by someone else and passed on,
00048 we want its recipients to know that what they have is not the
00049 original, so that any problems introduced by others will not reflect
00050 on the original authors' reputations.
00051
00052 Finally, any free program is threatened constantly by software
00053 patents. We wish to avoid the danger that redistributors of a free

```

00054 program will individually obtain patent licenses, in effect making the
00055 program proprietary. To prevent this, we have made it clear that any
00056 patent must be licensed for everyone's free use or not licensed at
00057 all.
00058
00059 The precise terms and conditions for copying, distribution and
00060 modification follow.
00061
00062 ### TERMS AND CONDITIONS FOR COPYING, DISTRIBUTION AND MODIFICATION
00063
00064 **0.** This License applies to any program or other work which
00065 contains a notice placed by the copyright holder saying it may be
00066 distributed under the terms of this General Public License. The
00067 "Program", below, refers to any such program or work, and a "work
00068 based on the Program" means either the Program or any derivative work
00069 under copyright law: that is to say, a work containing the Program or
00070 a portion of it, either verbatim or with modifications and/or
00071 translated into another language. (Hereinafter, translation is
00072 included without limitation in the term "modification".) Each licensee
00073 is addressed as "you".
00074
00075 Activities other than copying, distribution and modification are not
00076 covered by this License; they are outside its scope. The act of
00077 running the Program is not restricted, and the output from the Program
00078 is covered only if its contents constitute a work based on the Program
00079 (independent of having been made by running the Program). Whether that
00080 is true depends on what the Program does.
00081
00082 **1.** You may copy and distribute verbatim copies of the Program's
00083 source code as you receive it, in any medium, provided that you
00084 conspicuously and appropriately publish on each copy an appropriate
00085 copyright notice and disclaimer of warranty; keep intact all the
00086 notices that refer to this License and to the absence of any warranty;
00087 and give any other recipients of the Program a copy of this License
00088 along with the Program.
00089
00090 You may charge a fee for the physical act of transferring a copy, and
00091 you may at your option offer warranty protection in exchange for a
00092 fee.
00093
00094 **2.** You may modify your copy or copies of the Program or any
00095 portion of it, thus forming a work based on the Program, and copy and
00096 distribute such modifications or work under the terms of Section 1
00097 above, provided that you also meet all of these conditions:
00098
00099
00100 **a)** You must cause the modified files to carry prominent notices
00101 stating that you changed the files and the date of any change.
00102
00103
00104 **b)** You must cause any work that you distribute or publish, that in
00105 whole or in part contains or is derived from the Program or any part
00106 thereof, to be licensed as a whole at no charge to all third parties
00107 under the terms of this License.
00108
00109
00110 **c)** If the modified program normally reads commands interactively
00111 when run, you must cause it, when started running for such interactive
00112 use in the most ordinary way, to print or display an announcement
00113 including an appropriate copyright notice and a notice that there is
00114 no warranty (or else, saying that you provide a warranty) and that
00115 users may redistribute the program under these conditions, and telling
00116 the user how to view a copy of this License. (Exception: if the
00117 Program itself is interactive but does not normally print such an
00118 announcement, your work based on the Program is not required to print
00119 an announcement.)
00120
00121 These requirements apply to the modified work as a whole. If
00122 identifiable sections of that work are not derived from the Program,
00123 and can be reasonably considered independent and separate works in
00124 themselves, then this License, and its terms, do not apply to those
00125 sections when you distribute them as separate works. But when you
00126 distribute the same sections as part of a whole which is a work based
00127 on the Program, the distribution of the whole must be on the terms of
00128 this License, whose permissions for other licensees extend to the
00129 entire whole, and thus to each and every part regardless of who wrote
00130 it.
00131
00132 Thus, it is not the intent of this section to claim rights or contest
00133 your rights to work written entirely by you; rather, the intent is to
00134 exercise the right to control the distribution of derivative or
00135 collective works based on the Program.
00136
00137 In addition, mere aggregation of another work not based on the Program
00138 with the Program (or with a work based on the Program) on a volume of
00139 a storage or distribution medium does not bring the other work under
00140 the scope of this License.

00141
00142 **3.** You may copy and distribute the Program (or a work based on it,
00143 under Section 2) in object code or executable form under the terms of
00144 Sections 1 and 2 above provided that you also do one of the following:
00145
00146
00147 **a)** Accompany it with the complete corresponding machine-readable
00148 source code, which must be distributed under the terms of Sections 1
00149 and 2 above on a medium customarily used for software interchange; or,
00150
00151
00152 **b)** Accompany it with a written offer, valid for at least three
00153 years, to give any third party, for a charge no more than your cost of
00154 physically performing source distribution, a complete machine-readable
00155 copy of the corresponding source code, to be distributed under the
00156 terms of Sections 1 and 2 above on a medium customarily used for
00157 software interchange; or,
00158
00159
00160 **c)** Accompany it with the information you received as to the offer
00161 to distribute corresponding source code. (This alternative is allowed
00162 only for noncommercial distribution and only if you received the
00163 program in object code or executable form with such an offer, in
00164 accord with Subsection b above.)
00165
00166 The source code for a work means the preferred form of the work for
00167 making modifications to it. For an executable work, complete source
00168 code means all the source code for all modules it contains, plus any
00169 associated interface definition files, plus the scripts used to
00170 control compilation and installation of the executable. However, as a
00171 special exception, the source code distributed need not include
00172 anything that is normally distributed (in either source or binary
00173 form) with the major components (compiler, kernel, and so on) of the
00174 operating system on which the executable runs, unless that component
00175 itself accompanies the executable.
00176
00177 If distribution of executable or object code is made by offering
00178 access to copy from a designated place, then offering equivalent
00179 access to copy the source code from the same place counts as
00180 distribution of the source code, even though third parties are not
00181 compelled to copy the source along with the object code.
00182
00183 **4.** You may not copy, modify, sublicense, or distribute the Program
00184 except as expressly provided under this License. Any attempt otherwise
00185 to copy, modify, sublicense or distribute the Program is void, and
00186 will automatically terminate your rights under this License. However,
00187 parties who have received copies, or rights, from you under this
00188 License will not have their licenses terminated so long as such
00189 parties remain in full compliance.
00190
00191 **5.** You are not required to accept this License, since you have not
00192 signed it. However, nothing else grants you permission to modify or
00193 distribute the Program or its derivative works. These actions are
00194 prohibited by law if you do not accept this License. Therefore, by
00195 modifying or distributing the Program (or any work based on the
00196 Program), you indicate your acceptance of this License to do so, and
00197 all its terms and conditions for copying, distributing or modifying
00198 the Program or works based on it.
00199
00200 **6.** Each time you redistribute the Program (or any work based on
00201 the Program), the recipient automatically receives a license from the
00202 original licensor to copy, distribute or modify the Program subject to
00203 these terms and conditions. You may not impose any further
00204 restrictions on the recipients' exercise of the rights granted herein.
00205 You are not responsible for enforcing compliance by third parties to
00206 this License.
00207
00208 **7.** If, as a consequence of a court judgment or allegation of
00209 patent infringement or for any other reason (not limited to patent
00210 issues), conditions are imposed on you (whether by court order,
00211 agreement or otherwise) that contradict the conditions of this
00212 License, they do not excuse you from the conditions of this License.
00213 If you cannot distribute so as to satisfy simultaneously your
00214 obligations under this License and any other pertinent obligations,
00215 then as a consequence you may not distribute the Program at all. For
00216 example, if a patent license would not permit royalty-free
00217 redistribution of the Program by all those who receive copies directly
00218 or indirectly through you, then the only way you could satisfy both it
00219 and this License would be to refrain entirely from distribution of the
00220 Program.
00221
00222 If any portion of this section is held invalid or unenforceable under
00223 any particular circumstance, the balance of the section is intended to
00224 apply and the section as a whole is intended to apply in other
00225 circumstances.
00226
00227 It is not the purpose of this section to induce you to infringe any

00228 patents or other property right claims or to contest validity of any
00229 such claims; this section has the sole purpose of protecting the
00230 integrity of the free software distribution system, which is
00231 implemented by public license practices. Many people have made
00232 generous contributions to the wide range of software distributed
00233 through that system in reliance on consistent application of that
00234 system; it is up to the author/donor to decide if he or she is willing
00235 to distribute software through any other system and a licensee cannot
00236 impose that choice.

00237
00238 This section is intended to make thoroughly clear what is believed to
00239 be a consequence of the rest of this License.

00240
00241 ****8.**** If the distribution and/or use of the Program is restricted in
00242 certain countries either by patents or by copyrighted interfaces, the
00243 original copyright holder who places the Program under this License
00244 may add an explicit geographical distribution limitation excluding
00245 those countries, so that distribution is permitted only in or among
00246 countries not thus excluded. In such case, this License incorporates
00247 the limitation as if written in the body of this License.

00248
00249 ****9.**** The Free Software Foundation may publish revised and/or new
00250 versions of the General Public License from time to time. Such new
00251 versions will be similar in spirit to the present version, but may
00252 differ in detail to address new problems or concerns.

00253
00254 Each version is given a distinguishing version number. If the Program
00255 specifies a version number of this License which applies to it and
00256 "any later version", you have the option of following the terms and
00257 conditions either of that version or of any later version published by
00258 the Free Software Foundation. If the Program does not specify a
00259 version number of this License, you may choose any version ever
00260 published by the Free Software Foundation.

00261
00262 ****10.**** If you wish to incorporate parts of the Program into other
00263 free programs whose distribution conditions are different, write to
00264 the author to ask for permission. For software which is copyrighted by
00265 the Free Software Foundation, write to the Free Software Foundation;
00266 we sometimes make exceptions for this. Our decision will be guided by
00267 the two goals of preserving the free status of all derivatives of our
00268 free software and of promoting the sharing and reuse of software
00269 generally.

00270
00271 ****NO WARRANTY****

00272
00273 ****11.**** BECAUSE THE PROGRAM IS LICENSED FREE OF CHARGE, THERE IS NO
00274 WARRANTY FOR THE PROGRAM, TO THE EXTENT PERMITTED BY APPLICABLE LAW.
00275 EXCEPT WHEN OTHERWISE STATED IN WRITING THE COPYRIGHT HOLDERS AND/OR
00276 OTHER PARTIES PROVIDE THE PROGRAM "AS IS" WITHOUT WARRANTY OF ANY
00277 KIND, EITHER EXPRESSED OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE
00278 IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR
00279 PURPOSE. THE ENTIRE RISK AS TO THE QUALITY AND PERFORMANCE OF THE
00280 PROGRAM IS WITH YOU. SHOULD THE PROGRAM PROVE DEFECTIVE, YOU ASSUME
00281 THE COST OF ALL NECESSARY SERVICING, REPAIR OR CORRECTION.

00282
00283 ****12.**** IN NO EVENT UNLESS REQUIRED BY APPLICABLE LAW OR AGREED TO IN
00284 WRITING WILL ANY COPYRIGHT HOLDER, OR ANY OTHER PARTY WHO MAY MODIFY
00285 AND/OR REDISTRIBUTE THE PROGRAM AS PERMITTED ABOVE, BE LIABLE TO YOU
00286 FOR DAMAGES, INCLUDING ANY GENERAL, SPECIAL, INCIDENTAL OR
00287 CONSEQUENTIAL DAMAGES ARISING OUT OF THE USE OR INABILITY TO USE THE
00288 PROGRAM (INCLUDING BUT NOT LIMITED TO LOSS OF DATA OR DATA BEING
00289 RENDERED INACCURATE OR LOSSES SUSTAINED BY YOU OR THIRD PARTIES OR A
00290 FAILURE OF THE PROGRAM TO OPERATE WITH ANY OTHER PROGRAMS), EVEN IF
00291 SUCH HOLDER OR OTHER PARTY HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH
00292 DAMAGES.

00293
00294 **### END OF TERMS AND CONDITIONS**

00295
00296 **### How to Apply These Terms to Your New Programs**

00297
00298 If you develop a new program, and you want it to be of the greatest
00299 possible use to the public, the best way to achieve this is to make it
00300 free software which everyone can redistribute and change under these
00301 terms.

00302
00303 To do so, attach the following notices to the program. It is safest to
00304 attach them to the start of each source file to most effectively
00305 convey the exclusion of warranty; and each file should have at least
00306 the "copyright" line and a pointer to where the full notice is found.

00307
00308 one line to give the program's name and an idea of what it does.
00309 Copyright (C) yyyy name of author

00310
00311 This program is free software; you can redistribute it and/or
00312 modify it under the terms of the GNU General Public License
00313 as published by the Free Software Foundation; either version 2
00314 of the License, or (at your option) any later version.

```

00315
00316 This program is distributed in the hope that it will be useful,
00317 but WITHOUT ANY WARRANTY; without even the implied warranty of
00318 MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE. See the
00319 GNU General Public License for more details.
00320
00321 You should have received a copy of the GNU General Public License
00322 along with this program; if not, write to the Free Software
00323 Foundation, Inc., 51 Franklin Street, Fifth Floor, Boston, MA 02110-1301, USA.
00324
00325 Also add information on how to contact you by electronic and paper
00326 mail.
00327
00328 If the program is interactive, make it output a short notice like this
00329 when it starts in an interactive mode:
00330
00331 Gnomovision version 69, Copyright (C) year name of author
00332 Gnomovision comes with ABSOLUTELY NO WARRANTY; for details
00333 type 'show w'. This is free software, and you are welcome
00334 to redistribute it under certain conditions; type 'show c'
00335 for details.
00336
00337 The hypothetical commands '\show w' and '\show c' should show the
00338 appropriate parts of the General Public License. Of course, the
00339 commands you use may be called something other than '\show w' and
00340 '\show c'; they could even be mouse-clicks or menu items--whatever
00341 suits your program.
00342
00343 You should also get your employer (if you work as a programmer) or
00344 your school, if any, to sign a "copyright disclaimer" for the program,
00345 if necessary. Here is a sample; alter the names:
00346
00347 Yoyodyne, Inc., hereby disclaims all copyright
00348 interest in the program 'Gnomovision'
00349 (which makes passes at compilers) written
00350 by James Hacker.
00351
00352 signature of Ty Coon, 1 April 1989
00353 Ty Coon, President of Vice
00354
00355 This General Public License does not permit incorporating your program
00356 into proprietary programs. If your program is a subroutine library,
00357 you may consider it more useful to permit linking proprietary
00358 applications with the library. If this is what you want to do, use the
00359 [GNU Lesser General Public
00360 License](https://www.gnu.org/licenses/lgpl.html) instead of this
00361 License.

```

13.46 gui.dox File Reference

13.47 latex-output.c File Reference


LaTeX output renderer.

```

#include <math.h>
#include <gds-render/latex-renderer/latex-output.h>

```

Include dependency graph for latex-output.c:



Macros

- #define `WRITEOUT_BUFFER(buff) fwrite((buff)->str, sizeof(char), (buff)->len, tex_file)`
Writes a GString buffer to the fixed file tex_file.

Functions

- static void `write_layer_definitions(FILE *tex_file, GList *layer_infos, GString *buffer)`
Write the layer declarration to TeX file.
- static gboolean `write_layer_env(FILE *tex_file, GdkRGBA *color, int layer, GList *linfo, GString *buffer)`
Write layer Envirmonment.
- static void `generate_graphics(FILE *tex_file, GList *graphics, GList *linfo, GString *buffer, double scale)`
Writes a graphics object to the specified tex_file.
- static void `render_cell(struct gds_cell *cell, GList *layer_infos, FILE *tex_file, GString *buffer, double scale)`
Render cell to file.
- void `latex_render_cell_to_code(struct gds_cell *cell, GList *layer_infos, FILE *tex_file, double scale, gboolean create_pdf_layers, gboolean standalone_document)`
Render cell to LateX/TikZ code.

13.47.1 Detailed Description

LaTeX output renderer.

Author

Mario Hüttel mario.huettel@gmx.net

Definition in file [latex-output.c](#).

13.48 latex-output.c

```

00001 /*
00002  * GDSII-Converter
00003  * Copyright (C) 2018 Mario Hüttel <mario.huettel@gmx.net>
00004  *
00005  * This file is part of GDSII-Converter.
00006  *
00007  * GDSII-Converter is free software: you can redistribute it and/or modify
00008  * it under the terms of the GNU General Public License version 2 as
00009  * published by the Free Software Foundation.
00010  *
00011  * GDSII-Converter is distributed in the hope that it will be useful,
00012  * but WITHOUT ANY WARRANTY; without even the implied warranty of
00013  * MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE. See the
00014  * GNU General Public License for more details.
00015  *
00016  * You should have received a copy of the GNU General Public License
00017  * along with GDSII-Converter. If not, see <http://www.gnu.org/licenses/>.
00018  */
00019
00026 #include <math.h>
00027
00028 #include <gds-render/latex-renderer/latex-output.h>
00029
00036 #define WRITEOUT_BUFFER(buff) fwrite((buff)->str, sizeof(char), (buff)->len, tex_file)
00037
00050 static void write_layer_definitions(FILE *tex_file, GList *layer_infos, GString *
    buffer)
00051 {
00052     GList *list;
00053     struct layer_info *lifo;
00054     char *end_str;
00055
00056     for (list = layer_infos; list != NULL; list = list->next) {
00057         lifo = (struct layer_info *)list->data;
00058         g_string_printf(buffer, "\\pgfdeclarelayer{l%d}\n\\definecolor{c%d}{rgb}{%lf,%lf,%lf}\n",
00059             lifo->layer, lifo->layer,
00060             lifo->color.red, lifo->color.green, lifo->color.blue);
00061         WRITEOUT_BUFFER(buffer);
00062     }
00063
00064     g_string_printf(buffer, "\\pgfsetlayers{");
00065     WRITEOUT_BUFFER(buffer);
00066
00067     for (list = layer_infos; list != NULL; list = list->next) {
00068         lifo = (struct layer_info *)list->data;
00069
00070         if (list->next == NULL)
00071             end_str = ",main>";
00072         else
00073             end_str = ",";
00074         g_string_printf(buffer, "l%d%s", lifo->layer, end_str);
00075         WRITEOUT_BUFFER(buffer);
00076     }
00077     fwrite("\n", sizeof(char), 1, tex_file);
00078 }
00079
00106 static gboolean write_layer_env(FILE *tex_file, GdkRGBA *color, int
    layer, GList *linfo, GString *buffer)
00107 {
00108     GList *temp;
00109     struct layer_info *inf;
00110
00111     for (temp = linfo; temp != NULL; temp = temp->next) {
00112         inf = (struct layer_info *)temp->data;
00113         if (inf->layer == layer) {
00114             color->alpha = inf->color.alpha;
00115             color->red = inf->color.red;
00116             color->green = inf->color.green;
00117             color->blue = inf->color.blue;
00118             g_string_printf(buffer, "\\begin{pgfonlayer}{l%d}\n\\ifcreatepdflayers\n\\
    begin{scope}[ocg={ref=%d, status=visible,name={%s}}]\n\\fi\n",
00119                 layer, layer, inf->name);
00120             WRITEOUT_BUFFER(buffer);
00121             return TRUE;
00122         }
00123     }
00124     return FALSE;
00125 }
00126
00138 static void generate_graphics(FILE *tex_file, GList *graphics, GList *linfo, GString *
    buffer, double scale)
00139 {
00140     GList *temp;
00141     GList *temp_vertex;

```

```

00142     struct gds_graphics *gfx;
00143     struct gds_point *pt;
00144     GdkRGBA color;
00145     static const char *line_caps[] = {"butt", "round", "rect"};
00146
00147     for (temp = graphics; temp != NULL; temp = temp->next) {
00148         gfx = (struct gds_graphics *)temp->data;
00149         if (write_layer_env(tex_file, &color, (int)gfx->layer, linfo, buffer) == TRUE)
00150         {
00151             /* Layer is defined => create graphics */
00152             if (gfx->gfx_type == GRAPHIC_POLYGON || gfx->
gfx_type == GRAPHIC_BOX ) {
00153                 g_string_printf(buffer, "\\draw[line width=0.00001 pt, draw={c%d}, fill={c%d}, fill
opacity={%lf}] ",
00154                               gfx->layer, gfx->layer, color.alpha);
00155                 WRITEOUT_BUFFER(buffer);
00156                 /* Append vertices */
00157                 for (temp_vertex = gfx->vertices; temp_vertex != NULL; temp_vertex = temp_vertex->
next) {
00158                     pt = (struct gds_point *)temp_vertex->data;
00159                     g_string_printf(buffer, "%lf pt, %lf pt) -- ", ((double)pt->
x)/scale, ((double)pt->y)/scale);
00160                     WRITEOUT_BUFFER(buffer);
00161                 }
00162                 g_string_printf(buffer, "cycle;\n");
00163                 WRITEOUT_BUFFER(buffer);
00164             } else if (gfx->gfx_type == GRAPHIC_PATH) {
00165                 if (g_list_length(gfx->vertices) < 2) {
00166                     printf("Cannot write path with less than 2 points\n");
00167                     break;
00168                 }
00169
00170                 if (gfx->path_render_type < 0 || gfx->
path_render_type > 2) {
00171                     printf("Path type unrecognized. Setting to 'flushed'\n");
00172                     gfx->path_render_type = PATH_FLUSH;
00173                 }
00174
00175                 g_string_printf(buffer, "\\draw[line width=%lf pt, draw={c%d}, opacity={%lf}, cap=%s] ",
00176                               gfx->width_absolute/scale, gfx->layer, color.alpha,
00177                               line_caps[gfx->path_render_type]);
00178                 WRITEOUT_BUFFER(buffer);
00179
00180                 /* Append vertices */
00181                 for (temp_vertex = gfx->vertices; temp_vertex != NULL; temp_vertex = temp_vertex->
next) {
00182                     pt = (struct gds_point *)temp_vertex->data;
00183                     g_string_printf(buffer, "%lf pt, %lf pt)%s",
00184                                   ((double)pt->x)/scale,
00185                                   ((double)pt->y)/scale,
00186                                   (temp_vertex->next ? " -- " : ""));
00187                     WRITEOUT_BUFFER(buffer);
00188                 }
00189                 g_string_printf(buffer, ";\n");
00190                 WRITEOUT_BUFFER(buffer);
00191             }
00192
00193             g_string_printf(buffer, "\\ifcreatepdflayers\n\\end{scope}\n\\fi\n\\end{pgfonlayer}\n");
00194             WRITEOUT_BUFFER(buffer);
00195         }
00196     } /* For graphics */
00197 }
00198
00199
00200
00209 static void render_cell(struct gds_cell *cell, GList *layer_infos, FILE *tex_file,
GString *buffer, double scale)
00210 {
00211     GList *list_child;
00212     struct gds_cell_instance *inst;
00213
00214     /* Draw polygons of current cell */
00215     generate_graphics(tex_file, cell->graphic_objs, layer_infos, buffer, scale
);
00216
00217     /* Draw polygons of childs */
00218     for (list_child = cell->child_cells; list_child != NULL; list_child = list_child->next) {
00219         inst = (struct gds_cell_instance *)list_child->data;
00220
00221         /* Abort if cell has no reference */
00222         if (!inst->cell_ref)
00223             continue;
00224
00225         /* generate translation scope */
00226         g_string_printf(buffer, "\\begin{scope}[shift={({%lf pt,%lf pt})}]\n",

```

```


00228         ((double) inst->origin.x)/scale, ((double) inst->origin.
y)/scale);
00229     WRITEOUT_BUFFER(buffer);
00230
00231     g_string_printf(buffer, "\\begin{scope}[rotate=%lf]\n", inst->angle);
00232     WRITEOUT_BUFFER(buffer);
00233
00234     g_string_printf(buffer, "\\begin{scope}[yscale=%lf, xscale=%lf]\n", (inst->
flipped ? -1*inst->magnification : inst->magnification),
inst->magnification);
00235     WRITEOUT_BUFFER(buffer);
00236
00237     render_cell(inst->cell_ref, layer_infos, tex_file, buffer, scale);
00238
00239     g_string_printf(buffer, "\\end{scope}\n");
00240     WRITEOUT_BUFFER(buffer);
00241
00242     g_string_printf(buffer, "\\end{scope}\n");
00243     WRITEOUT_BUFFER(buffer);
00244
00245     g_string_printf(buffer, "\\end{scope}\n");
00246     WRITEOUT_BUFFER(buffer);
00247 }
00248
00249 void latex_render_cell_to_code(struct gds_cell *cell, GList *layer_infos,
FILE *tex_file, double scale,
gboolean create_pdf_layers, gboolean standalone_document)
00250 {
00251     GString *working_line;
00252
00253     if (!tex_file || !layer_infos || !cell)
00254         return;
00255
00256     /* 10 kB Line working buffer should be enough */
00257     working_line = g_string_new_len(NULL, LATEX_LINE_BUFFER_KB*1024);
00258
00259     /* standalone foo */
00260     g_string_printf(working_line, "\\newif\\iftestmode\n\\testmode%s\n",
(standalone_document ? "true" : "false"));
00261     WRITEOUT_BUFFER(working_line);
00262     g_string_printf(working_line, "\\newif\\ifcreatepdflayers\n\\createpdflayers%s\n",
(create_pdf_layers ? "true" : "false"));
00263     WRITEOUT_BUFFER(working_line);
00264     g_string_printf(working_line, "\\iftestmode\n");
00265     WRITEOUT_BUFFER(working_line);
00266     g_string_printf(working_line, "\\documentclass[tikz]{standalone}\n\\usepackage{xcolor}\n\\
usetikzlibrary{ocg}\n\\begin{document}\n");
00267     WRITEOUT_BUFFER(working_line);
00268     g_string_printf(working_line, "\\fi\n");
00269     WRITEOUT_BUFFER(working_line);
00270
00271     /* Write layer definitions */
00272     write_layer_definitions(tex_file, layer_infos, working_line);
00273
00274     /* Open tikz Pictute */
00275     g_string_printf(working_line, "\\begin{tikzpicture}\n");
00276     WRITEOUT_BUFFER(working_line);
00277
00278     /* Generate graphics output */
00279     render_cell(cell, layer_infos, tex_file, working_line, scale);
00280
00281     g_string_printf(working_line, "\\end{tikzpicture}\n");
00282     WRITEOUT_BUFFER(working_line);
00283
00284     g_string_printf(working_line, "\\iftestmode\n");
00285     WRITEOUT_BUFFER(working_line);
00286     g_string_printf(working_line, "\\end{document}\n");
00287     WRITEOUT_BUFFER(working_line);
00288     g_string_printf(working_line, "\\fi\n");
00289     WRITEOUT_BUFFER(working_line);
00290
00291     fflush(tex_file);
00292     g_string_free(working_line, TRUE);
00293 }
00294
00295
00296
00297
00298
00299
00300
00301
00302

```


13.49 latex-output.h File Reference

LaTeX output renderer.

```
#include <glib.h>
#include <stdio.h>
#include "gds-render/layer/layer-info.h"
#include <gds-render/gds-utils/gds-types.h>
Include dependency graph for latex-output.h:
```



This graph shows which files directly or indirectly include this file:



Macros

- `#define LATEX_LINE_BUFFER_KB (10)`
Buffer for LaTeX Code line in KiB.

Functions

- `void latex_render_cell_to_code (struct gds_cell *cell, GList *layer_infos, FILE *tex_file, double scale, gboolean create_pdf_layers, gboolean standalone_document)`
Render cell to LaTeX/TikZ code.

13.49.1 Detailed Description

LaTeX output renderer.

Author

Mario Hüttel mario.huettel@gmx.net

Definition in file [latex-output.h](#).

13.50 latex-output.h

```

00001 /*
00002  * GDSII-Converter
00003  * Copyright (C) 2018 Mario Hüttel <mario.huettel@gmx.net>
00004  *
00005  * This file is part of GDSII-Converter.
00006  *
00007  * GDSII-Converter is free software: you can redistribute it and/or modify
00008  * it under the terms of the GNU General Public License version 2 as
00009  * published by the Free Software Foundation.
00010  *
00011  * GDSII-Converter is distributed in the hope that it will be useful,
00012  * but WITHOUT ANY WARRANTY; without even the implied warranty of
00013  * MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE. See the
00014  * GNU General Public License for more details.
00015  *
00016  * You should have received a copy of the GNU General Public License
00017  * along with GDSII-Converter. If not, see <http://www.gnu.org/licenses/>.
00018  */
00019
00026 #ifndef __LATEX_OUTPUT_H__
00027 #define __LATEX_OUTPUT_H__
00028
00034 #include <glib.h>
00035 #include <stdio.h>
00036
00037 #include "gds-render/layer/layer-info.h"
00038 #include <gds-render/gds-utils/gds-types.h>
00039
00040 #define LATEX_LINE_BUFFER_KB (10)
00051 void latex_render_cell_to_code(struct gds_cell *cell, GList *layer_infos, FILE *tex_file, double scale,
00052                             gboolean create_pdf_layers, gboolean standalone_document);
00053
00056 #endif /* __LATEX_OUTPUT_H__ */


```

13.51 latex-renderer.dox File Reference

13.52 layer-element.c File Reference

Implementation of the layer element used for configuring layer colors etc.

```
#include <gds-render/widgets/layer-element.h>
Include dependency graph for layer-element.c:
```



Functions

- static void [layer_element_dispose](#) (GObject *obj)
- static void [layer_element_constructed](#) (GObject *obj)
- static void [layer_element_class_init](#) (LayerElementClass *klass)
- static void [layer_element_init](#) (LayerElement *self)
- GtkWidget * [layer_element_new](#) (void)
 - *Create new layer element object.*
- const char * [layer_element_get_name](#) (LayerElement *elem)
 - *get name of the layer*
- void [layer_element_set_name](#) (LayerElement *elem, const char *name)
 - *layer_element_set_name*
- void [layer_element_set_layer](#) (LayerElement *elem, int layer)
 - *Set layer number for this layer.*
- int [layer_element_get_layer](#) (LayerElement *elem)
 - *Get layer number.*
- void [layer_element_set_export](#) (LayerElement *elem, gboolean export)
 - *Set export flag for this layer.*
- gboolean [layer_element_get_export](#) (LayerElement *elem)
 - *Get export flag of layer.*
- void [layer_element_get_color](#) (LayerElement *elem, GdkRGBA *rgba)
 - *Get color of layer.*
- void [layer_element_set_color](#) (LayerElement *elem, GdkRGBA *rgba)
 - *Set color of layer.*
- void [layer_element_set_dnd_callbacks](#) (LayerElement *elem, struct [layer_element_dnd_data](#) *data)
 - *Setup drag and drop of elem for use in the LayerSelector.*

13.52.1 Detailed Description

Implementation of the layer element used for configuring layer colors etc.

Author

Mario Hüttel mario.huettel@gmx.net

Definition in file [layer-element.c](#).

13.53 layer-element.c

```

00001 /*
00002  * GDSII-Converter
00003  * Copyright (C) 2018 Mario Hüttel <mario.huettel@gmx.net>
00004  *
00005  * This file is part of GDSII-Converter.
00006  *
00007  * GDSII-Converter is free software: you can redistribute it and/or modify
00008  * it under the terms of the GNU General Public License version 2 as
00009  * published by the Free Software Foundation.
00010  *
00011  * GDSII-Converter is distributed in the hope that it will be useful,
00012  * but WITHOUT ANY WARRANTY; without even the implied warranty of
00013  * MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE. See the
00014  * GNU General Public License for more details.
00015  *
00016  * You should have received a copy of the GNU General Public License
00017  * along with GDSII-Converter. If not, see <http://www.gnu.org/licenses/>.
00018  */
00019
00020 /*
00021  * The drag and drop implementation is adapted from
00022  * https://gitlab.gnome.org/GNOME/gtk/blob/gtk-3-22/tests/testlist3.c
00023  *
00024  * Thanks to the GTK3 people for creating these examples.
00025  */
00026
00039 #include <gds-render/widgets/layer-element.h>
00040
00041 G_DEFINE_TYPE(LayerElement, layer_element, GTK_TYPE_LIST_BOX_ROW)
00042
00043 static void layer_element_dispose(GObject *obj)
00044 {
00045     /* destroy parent container. This destroys all widgets inside */
00046     G_OBJECT_CLASS(layer_element_parent_class)->dispose(obj);
00047 }
00048
00049 static void layer_element_constructed(GObject *obj)
00050 {
00051     G_OBJECT_CLASS(layer_element_parent_class)->constructed(obj);
00052 }
00053
00054 static void layer_element_class_init(LayerElementClass *klass)
00055 {
00056     GObjectClass *oclass = G_OBJECT_CLASS(klass);
00057     oclass->dispose = layer_element_dispose;
00058     oclass->constructed = layer_element_constructed;
00059 }
00060
00061 static void layer_element_init(LayerElement *self)
00062 {
00063     GtkBuilder *builder;
00064     GtkWidget *glade_box;
00065     builder = gtk_builder_new_from_resource("/layer-widget.glade");
00066     glade_box = GTK_WIDGET(gtk_builder_get_object(builder, "box"));
00067     gtk_container_add(GTK_CONTAINER(self), glade_box);
00068
00069     /* Get Elements */
00070     self->priv.color = GTK_COLOR_BUTTON(gtk_builder_get_object(builder, "color"));
00071     self->priv.export = GTK_CHECK_BUTTON(gtk_builder_get_object(builder, "export"));
00072     self->priv.layer = GTK_LABEL(gtk_builder_get_object(builder, "layer"));
00073     self->priv.name = GTK_ENTRY(gtk_builder_get_object(builder, "entry"));
00074     self->priv.event_handle = GTK_EVENT_BOX(gtk_builder_get_object(builder, "event-box"));
00075
00076     g_object_unref(builder);

```

```

00077 }
00078
00079 GtkWidget *layer_element_new(void)
00080 {
00081     return GTK_WIDGET(g_object_new(TYPE_LAYER_ELEMENT, NULL));
00082 }
00083
00084 const char *layer_element_get_name(LayerElement *elem)
00085 {
00086     return gtk_entry_get_text(elem->priv.name);
00087 }
00088
00089 void layer_element_set_name(LayerElement *elem, const char* name)
00090 {
00091     gtk_entry_set_text(elem->priv.name, name);
00092 }
00093
00094 void layer_element_set_layer(LayerElement *elem, int layer)
00095 {
00096     GString *string;
00097
00098     string = g_string_new_len(NULL, 100);
00099     g_string_printf(string, "Layer: %d", layer);
00100     gtk_label_set_text(elem->priv.layer, (const gchar *)string->str);
00101     elem->priv.layer_num = layer;
00102     g_string_free(string, TRUE);
00103 }
00104
00105 int layer_element_get_layer(LayerElement *elem)
00106 {
00107     return elem->priv.layer_num;
00108 }
00109
00110 void layer_element_set_export(LayerElement *elem, gboolean export)
00111 {
00112     gtk_toggle_button_set_active(GTK_TOGGLE_BUTTON(elem->priv.export), export);
00113 }
00114
00115 gboolean layer_element_get_export(LayerElement *elem)
00116 {
00117     return gtk_toggle_button_get_active(GTK_TOGGLE_BUTTON(elem->priv.export));
00118 }
00119
00120 void layer_element_get_color(LayerElement *elem, GdkRGBA *rgba)
00121 {
00122     if (!rgba)
00123         return;
00124
00125     gtk_color_chooser_get_rgba(GTK_COLOR_CHOOSER(elem->priv.color), rgba);
00126 }
00127
00128 void layer_element_set_color(LayerElement *elem, GdkRGBA *rgba)
00129 {
00130     if (!elem || !rgba)
00131         return;
00132
00133     gtk_color_chooser_set_rgba(GTK_COLOR_CHOOSER(elem->priv.color), rgba);
00134 }
00135
00136 void layer_element_set_dnd_callbacks(LayerElement *elem, struct
layer_element_dnd_data *data)
00137 {
00138     if (!elem || !data)
00139         return;
00140
00141     /* Setup drag and drop */
00142     gtk_style_context_add_class (gtk_widget_get_style_context (GTK_WIDGET (elem)), "row");
00143     gtk_drag_source_set (GTK_WIDGET (elem->priv.event_handle), GDK_BUTTON1_MASK, data->
entries, data->entry_count, GDK_ACTION_MOVE);
00144     g_signal_connect (elem->priv.event_handle, "drag-begin", G_CALLBACK (data->
drag_begin), NULL);
00145     g_signal_connect (elem->priv.event_handle, "drag-data-get", G_CALLBACK (data->
drag_data_get), NULL);
00146     g_signal_connect (elem->priv.event_handle, "drag-end", G_CALLBACK (data->
drag_end), NULL);
00147
00148 }
00149


```

13.54 layer-element.h File Reference


Implementation of the layer element used for configuring layer colors etc.

```
#include <gtk/gtk.h>
```

Include dependency graph for layer-element.h:



This graph shows which files directly or indirectly include this file:



Data Structures

- struct [_LayerElementPriv](#)
- struct [_LayerElement](#)
- struct [layer_element_dnd_data](#)

This structure holds the necessary data to set up a LayerElement for Drag'n'Drop.

Macros

- `#define` [TYPE_LAYER_ELEMENT](#) (layer_element_get_type())

Typedefs

- typedef struct [_LayerElementPriv](#) [LayerElementPriv](#)

Functions

- GtkWidget * [layer_element_new](#) (void)
Create new layer element object.
- const char * [layer_element_get_name](#) (LayerElement *elem)
get name of the layer
- void [layer_element_set_name](#) (LayerElement *elem, const char *name)
layer_element_set_name
- void [layer_element_set_layer](#) (LayerElement *elem, int layer)
Set layer number for this layer.
- int [layer_element_get_layer](#) (LayerElement *elem)
Get layer number.
- void [layer_element_set_export](#) (LayerElement *elem, gboolean export)
Set export flag for this layer.
- gboolean [layer_element_get_export](#) (LayerElement *elem)
Get export flag of layer.
- void [layer_element_get_color](#) (LayerElement *elem, GdkRGBA *rgba)
Get color of layer.
- void [layer_element_set_color](#) (LayerElement *elem, GdkRGBA *rgba)
Set color of layer.
- void [layer_element_set_dnd_callbacks](#) (LayerElement *elem, struct [layer_element_dnd_data](#) *data)
Setup drag and drop of elem for use in the LayerSelector.

13.54.1 Detailed Description

Implementation of the layer element used for configuring layer colors etc.

Author

Mario Hüttel mario.huettel@gmx.net

Definition in file [layer-element.h](#).

13.55 layer-element.h

```

00001 /*
00002  * GDSII-Converter
00003  * Copyright (C) 2018 Mario Hüttel <mario.huettel@gmx.net>
00004  *
00005  * This file is part of GDSII-Converter.
00006  *
00007  * GDSII-Converter is free software: you can redistribute it and/or modify
00008  * it under the terms of the GNU General Public License version 2 as
00009  * published by the Free Software Foundation.
00010  *
00011  * GDSII-Converter is distributed in the hope that it will be useful,
00012  * but WITHOUT ANY WARRANTY; without even the implied warranty of
00013  * MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE. See the
00014  * GNU General Public License for more details.
00015  *
00016  * You should have received a copy of the GNU General Public License
00017  * along with GDSII-Converter. If not, see <http://www.gnu.org/licenses/>.
00018  */
00019
00032 #ifndef __LAYER_ELEMENT_H__
00033 #define __LAYER_ELEMENT_H__
00034
00035 #include <gtk/gtk.h>

```

```


00036
00037 G_BEGIN_DECLS
00038
00039 /* Creates Class structure etc */
00040 G_DECLARE_FINAL_TYPE(LayerElement, layer_element, LAYER, ELEMENT, GtkWidget)
00041
00042 #define TYPE_LAYER_ELEMENT (layer_element_get_type())
00043
00044 typedef struct _LayerElementPriv {
00045     GtkWidget *name;
00046     GtkWidget *layer;
00047     int layer_num;
00048     GtkWidget *event_handle;
00049     GtkWidget *color;
00050     GtkWidget *export;
00051 } LayerElementPriv;
00052
00053 struct _LayerElement {
00054     /* Inheritance */
00055     GtkWidget parent;
00056     /* Custom Elements */
00057     LayerElementPriv priv;
00058 };
00059
00060 struct layer_element_dnd_data {
00061     GtkWidget *entries;
00062     int entry_count;
00063     void (*drag_begin)(GtkWidget *, GdkDragContext *, gpointer);
00064     void (*drag_data_get)(GtkWidget *, GdkDragContext *, GtkSelectionData *, guint, guint,
00065     gpointer);
00066     void (*drag_end)(GtkWidget *, GdkDragContext *, gpointer);
00067 };
00068
00069 GtkWidget *layer_element_new(void);
00070
00071 const char *layer_element_get_name(LayerElement *elem);
00072
00073 void layer_element_set_name(LayerElement *elem, const char *name);
00074
00075 void layer_element_set_layer(LayerElement *elem, int layer);
00076
00077 int layer_element_get_layer(LayerElement *elem);
00078
00079 void layer_element_set_export(LayerElement *elem, gboolean export);
00080
00081 gboolean layer_element_get_export(LayerElement *elem);
00082
00083 void layer_element_get_color(LayerElement *elem, GdkRGBA *rgba);
00084
00085 void layer_element_set_color(LayerElement *elem, GdkRGBA *rgba);
00086
00087 void layer_element_set_dnd_callbacks(LayerElement *elem, struct
00088     layer_element_dnd_data *data);
00089
00090
00091 G_END_DECLS
00092
00093 #endif /* __LAYER_ELEMENT_H__ */
00094

```

13.56 layer-info.c File Reference

Helper functions for layer info struct.

```
#include <gds-render/layer/layer-info.h>  
Include dependency graph for layer-info.c:
```



Functions

- void [layer_info_delete_struct](#) (struct [layer_info](#) *info)
Delete a [layer_info](#) struct.

13.56.1 Detailed Description

Helper functions for layer info struct.

Author

Mario Hüttel mario.huettel@gmx.net

Definition in file [layer-info.c](#).

13.56.2 Function Documentation

13.56.2.1 [layer_info_delete_struct\(\)](#)

```
void layer_info_delete_struct (  
    struct layer\_info * info )
```

Delete a [layer_info](#) struct.

Parameters


<i>info</i>	Struct to be deleted.
-------------	-----------------------

Note

The `layer_info::name` Element has to be freed manually

Definition at line 28 of file `layer-info.c`.

Here is the caller graph for this function:



13.57 layer-info.c

```

00001 /*
00002  * GDSII-Converter
00003  * Copyright (C) 2019 Mario Hüttel <mario.huettel@gmx.net>
00004  *
00005  * This file is part of GDSII-Converter.
00006  *
00007  * GDSII-Converter is free software: you can redistribute it and/or modify
00008  * it under the terms of the GNU General Public License version 2 as
00009  * published by the Free Software Foundation.
00010  *
00011  * GDSII-Converter is distributed in the hope that it will be useful,
00012  * but WITHOUT ANY WARRANTY; without even the implied warranty of
00013  * MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE. See the
00014  * GNU General Public License for more details.
00015  *
00016  * You should have received a copy of the GNU General Public License
00017  * along with GDSII-Converter. If not, see <http://www.gnu.org/licenses/>.
00018  */
00019
00026 #include <gds-render/layer/layer-info.h>
00027
00028 void layer_info_delete_struct(struct layer_info *info)
00029 {
00030     if (info)
00031         free(info);
00032 }
00033


```

13.58 layer-info.h File Reference


Helper functions and definition of layer info struct.

```
#include <gtk/gtk.h>
```

Include dependency graph for layer-info.h:



This graph shows which files directly or indirectly include this file:



Data Structures

- struct [layer_info](#)
Layer information.

Functions

- void [layer_info_delete_struct](#) (struct [layer_info](#) *info)
Delete a [layer_info](#) struct.

13.58.1 Detailed Description

Helper functions and definition of layer info struct.

Author

Mario Hüttel mario.huettel@gmx.net

Definition in file [layer-info.h](#).

13.58.2 Function Documentation

13.58.2.1 layer_info_delete_struct()

```
void layer_info_delete_struct (
    struct layer_info * info )
```

Delete a `layer_info` struct.

Parameters


<code>info</code>	Struct to be deleted.
-------------------	-----------------------

Note

The `layer_info::name` Element has to be freed manually

Definition at line 28 of file `layer-info.c`.

Here is the caller graph for this function:



13.59 layer-info.h

```
00001 /*
00002  * GDSII-Converter
00003  * Copyright (C) 2019 Mario Hüttel <mario.huettel@gmx.net>
00004  *
00005  * This file is part of GDSII-Converter.
00006  *
00007  * GDSII-Converter is free software: you can redistribute it and/or modify
00008  * it under the terms of the GNU General Public License version 2 as
00009  * published by the Free Software Foundation.
00010  *
00011  * GDSII-Converter is distributed in the hope that it will be useful,
00012  * but WITHOUT ANY WARRANTY; without even the implied warranty of
00013  * MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE. See the
00014  * GNU General Public License for more details.
00015  *
00016  * You should have received a copy of the GNU General Public License
00017  * along with GDSII-Converter. If not, see <http://www.gnu.org/licenses/>.
00018  */
00019
00026 #ifndef _LAYER_INFO_H_
00027 #define _LAYER_INFO_H_
00028
00029 #include <gtk/gtk.h>
00030
00036 struct layer_info
00037 {
00038     int layer;
00039     char *name;
```

```

00040     int stacked_position;
00041     GdkRGBA color;
00042 };
00043
00049 void layer_info_delete_struct(struct layer_info *info);
00050
00051 #endif // _LAYER_INFO_H_

```

13.60 layer-selector.c File Reference


Implementation of the layer selector.

```

#include <glib.h>
#include <string.h>
#include <stdio.h>
#include <stdlib.h>
#include <gds-render/layer/layer-selector.h>
#include <gds-render/layer/layer-info.h>
#include <gds-render/gds-utils/gds-parser.h>
#include <gds-render/widgets/layer-element.h>
#include <gds-render/layer/mapping-parser.h>

```

Include dependency graph for layer-selector.c:



Data Structures

- struct [_LayerSelector](#)

Functions

- static void [sel_layer_element_drag_begin](#) (GtkWidget *widget, GdkDragContext *context, gpointer data)
- static void [sel_layer_element_drag_end](#) (GtkWidget *widget, GdkDragContext *context, gpointer data)
- static void [sel_layer_element_drag_data_get](#) (GtkWidget *widget, GdkDragContext *context, GtkSelectionData *selection_data, guint info, guint time, gpointer data)
- static GtkWidget * [layer_selector_get_last_row](#) (GtkListBox *list)
- static GtkWidget * [layer_selector_get_row_before](#) (GtkListBox *list, GtkWidget *row)
- static GtkWidget * [layer_selector_get_row_after](#) (GtkListBox *list, GtkWidget *row)
- static void [layer_selector_drag_data_received](#) (GtkWidget *widget, GdkDragContext *context, gint x, gint y, GtkSelectionData *selection_data, guint info, guint32 time, gpointer data)
- static gboolean [layer_selector_drag_motion](#) (GtkWidget *widget, GdkDragContext *context, int x, int y, guint time)
- static void [layer_selector_drag_leave](#) (GtkWidget *widget, GdkDragContext *context, guint time)

- static void [layer_selector_dispose](#) (GObject *self)
- static void [layer_selector_class_init](#) (LayerSelectorClass *klass)
- static void [layer_selector_setup_dnd](#) (LayerSelector *self)
- static void [layer_selector_init](#) (LayerSelector *self)
- LayerSelector * [layer_selector_new](#) (GtkListBox *list_box)
 - layer_selector_new*
- GList * [layer_selector_export_rendered_layer_info](#) (LayerSelector *selector)
 - Get a list of all layers that shall be exported when rendering the cells.*
- static void [layer_selector_clear_widgets](#) (LayerSelector *self)
- static gboolean [layer_selector_check_if_layer_widget_exists](#) (LayerSelector *self, int layer)
 - Check if a specific layer element with the given layer number is present in the layer selector.*
- static void [sel_layer_element_setup_dnd_callbacks](#) (LayerSelector *self, LayerElement *element)
 - Setup the necessary drag and drop callbacks of layer elements.*
- static void [layer_selector_analyze_cell_layers](#) (LayerSelector *self, struct [gds_cell](#) *cell)
 - Analyze cell layers and append detected layers to layer selector self.*
- static gint [layer_selector_sort_func](#) (GtkListBoxRow *row1, GtkListBoxRow *row2, gpointer unused)
 - sort_func Sort callback for list box*
- void [layer_selector_generate_layer_widgets](#) (LayerSelector *selector, GList *libs)
 - Generate layer widgets in in the LayerSelector instance.*
- static LayerElement * [layer_selector_find_layer_element_in_list](#) (GList *el_list, int layer)
 - Find LayerElement in list with specified layer number.*
- static void [layer_selector_load_layer_mapping_from_file](#) (LayerSelector *self, gchar *file_name)
 - Load the layer mapping from a CSV formatted file.*
- static void [layer_selector_load_mapping_clicked](#) (GtkWidget *button, gpointer user_data)
 - Callback for Load Mapping Button.*
- static void [layer_selector_save_layer_mapping_data](#) (LayerSelector *self, const gchar *file_name)
 - Save layer mapping of selector self to a file.*
- static void [layer_selector_save_mapping_clicked](#) (GtkWidget *button, gpointer user_data)
 - Callback for Save Layer Mapping Button.*
- void [layer_selector_set_load_mapping_button](#) (LayerSelector *selector, GtkWidget *button, GtkWindow *main_window)
 - Supply button for loading the layer mapping.*
- void [layer_selector_set_save_mapping_button](#) (LayerSelector *selector, GtkWidget *button, GtkWindow *main_window)
 - Supply button for saving the layer mapping.*
- void [layer_selector_force_sort](#) (LayerSelector *selector, enum [layer_selector_sort_algo](#) sort_function)
 - Force the layer selector list to be sorted according to sort_function.*

Variables

- static const char * [dnd_additional_css](#)

13.60.1 Detailed Description

Implementation of the layer selector.

Author

Mario Hüttel mario.huettel@gmx.net

Definition in file [layer-selector.c](#).

13.61 layer-selector.c

```

00001 /*
00002  * GDSII-Converter
00003  * Copyright (C) 2018 Mario Hüttel <mario.huettel@gmx.net>
00004  *
00005  * This file is part of GDSII-Converter.
00006  *
00007  * GDSII-Converter is free software: you can redistribute it and/or modify
00008  * it under the terms of the GNU General Public License version 2 as
00009  * published by the Free Software Foundation.
00010  *
00011  * GDSII-Converter is distributed in the hope that it will be useful,
00012  * but WITHOUT ANY WARRANTY; without even the implied warranty of
00013  * MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE. See the
00014  * GNU General Public License for more details.
00015  *
00016  * You should have received a copy of the GNU General Public License
00017  * along with GDSII-Converter. If not, see <http://www.gnu.org/licenses/>.
00018  */
00019
00031 #include <glib.h>
00032 #include <string.h>
00033 #include <stdio.h>
00034 #include <stdlib.h>
00035
00036 #include <gds-render/layer/layer-selector.h>
00037 #include <gds-render/layer/layer-info.h>
00038 #include <gds-render/gds-utils/gds-parser.h>
00039 #include <gds-render/widgets/layer-element.h>
00040 #include <gds-render/layer/mapping-parser.h>
00041
00042 struct _LayerSelector {
00043     /* Parent */
00044     GObject parent;
00045     /* Own fields */
00046     GtkWidget *associated_load_button;
00047     GtkWidget *associated_save_button;
00048     GtkWindow *load_parent_window;
00049     GtkWindow *save_parent_window;
00050     GtkListBox *list_box;
00051
00052     GtkTargetEntry dnd_target;
00053
00054     gpointer dummy[4];
00055 };
00056
00057 G_DEFINE_TYPE(LayerSelector, layer_selector, G_TYPE_OBJECT)
00058
00059 /* Drag and drop code
00060  * Original code from https://blog.gtk.org/2017/06/01/drag-and-drop-in-lists-revisited/
00061  */
00062
00063 static void sel_layer_element_drag_begin(GtkWidget *widget, GdkDragContext *
context, gpointer data)
00064 {
00065     GtkWidget *row;
00066     GtkAllocation alloc;
00067     cairo_surface_t *surface;
00068     cairo_t *cr;
00069     int x, y;
00070     (void)data;
00071
00072     row = gtk_widget_get_ancestor(widget, GTK_TYPE_LIST_BOX_ROW);
00073     gtk_widget_get_allocation(row, &alloc);
00074     surface = cairo_image_surface_create(CAIRO_FORMAT_ARGB32, alloc.width, alloc.height);
00075     cr = cairo_create(surface);
00076
00077     gtk_style_context_add_class(gtk_widget_get_style_context(row), "drag-icon");
00078     gtk_widget_draw(row, cr);
00079     gtk_style_context_remove_class(gtk_widget_get_style_context(row), "drag-icon");
00080
00081     gtk_widget_translate_coordinates(widget, row, 0, 0, &x, &y);
00082     cairo_surface_set_device_offset(surface, -x, -y);
00083     gtk_drag_set_icon_surface(context, surface);
00084
00085     cairo_destroy(cr);
00086     cairo_surface_destroy(surface);
00087
00088     g_object_set_data(G_OBJECT(gtk_widget_get_parent(row)), "drag-row", row);
00089     gtk_style_context_add_class(gtk_widget_get_style_context(row), "drag-row");
00090 }
00091
00092 static void sel_layer_element_drag_end(GtkWidget *widget, GdkDragContext *context
, gpointer data)
00093 {

```

```

00094     GtkWidget *row;
00095     (void)context;
00096     (void)data;
00097
00098     row = gtk_widget_get_ancestor(widget, GTK_TYPE_LIST_BOX_ROW);
00099     g_object_set_data(G_OBJECT(gtk_widget_get_parent(row)), "drag-row", NULL);
00100     gtk_style_context_remove_class(gtk_widget_get_style_context(row), "drag-row");
00101     gtk_style_context_remove_class(gtk_widget_get_style_context(row), "drag-hover");
00102 }
00103
00104 static void sel_layer_element_drag_data_get(GtkWidget *widget,
GdkDragContext *context,
00105     GtkSelectionData *selection_data,
00106     guint info, guint time, gpointer data)
00107 {
00108     (void)context;
00109     (void)info;
00110     (void)time;
00111     (void)data;
00112     GdkAtom atom;
00113
00114     atom = gdk_atom_intern_static_string("GTK_LIST_BOX_ROW");
00115
00116     gtk_selection_data_set(selection_data, atom,
00117         32, (const guchar *)&widget, sizeof(gpointer));
00118 }
00119
00120 static GtkWidget *layer_selector_get_last_row (GtkListBox *list)
00121 {
00122     int i;
00123     GtkWidget *row;
00124
00125     row = NULL;
00126     for (i = 0; ; i++) {
00127         GtkWidget *tmp;
00128         tmp = gtk_list_box_get_row_at_index(list, i);
00129         if (tmp == NULL)
00130             break;
00131         row = tmp;
00132     }
00133
00134     return row;
00135 }
00136
00137 static GtkWidget *layer_selector_get_row_before (GtkListBox *list,
GtkWidget *row)
00138 {
00139     int pos;
00140
00141     pos = gtk_list_box_row_get_index (row);
00142     return gtk_list_box_get_row_at_index (list, pos - 1);
00143 }
00144
00145 static GtkWidget *layer_selector_get_row_after (GtkListBox *list,
GtkWidget *row)
00146 {
00147     int pos;
00148
00149     pos = gtk_list_box_row_get_index(row);
00150     return gtk_list_box_get_row_at_index(list, pos + 1);
00151 }
00152
00153 static void layer_selector_drag_data_received(GtkWidget *widget,
GdkDragContext *context, gint x, gint y,
00154     GtkSelectionData *selection_data, guint info, guint32 time,
00155     gpointer data)
00156 {
00157     GtkWidget *row_before, *row_after;
00158     GtkWidget *row;
00159     GtkWidget *source;
00160     int pos;
00161
00162     row_before = GTK_WIDGET(g_object_get_data(G_OBJECT(widget), "row-before"));
00163     row_after = GTK_WIDGET(g_object_get_data(G_OBJECT(widget), "row-after"));
00164
00165     g_object_set_data(G_OBJECT(widget), "row-before", NULL);
00166     g_object_set_data(G_OBJECT(widget), "row-after", NULL);
00167
00168     if (row_before)
00169         gtk_style_context_remove_class(gtk_widget_get_style_context(row_before), "drag-hover-bottom");
00170     if (row_after)
00171         gtk_style_context_remove_class(gtk_widget_get_style_context(row_after), "drag-hover-top");
00172
00173     row = (gpointer) *((gpointer *)gtk_selection_data_get_data(selection_data));
00174     source = gtk_widget_get_ancestor(row, GTK_TYPE_LIST_BOX_ROW);
00175
00176     if (source == row_after)

```

```

00177         return;
00178
00179     g_object_ref(source);
00180     gtk_container_remove(GTK_CONTAINER(gtk_widget_get_parent(source)), source);
00181
00182     if (row_after)
00183         pos = gtk_list_box_row_get_index(GTK_LIST_BOX_ROW(row_after));
00184     else
00185         pos = gtk_list_box_row_get_index(GTK_LIST_BOX_ROW(row_before)) + 1;
00186
00187     gtk_list_box_insert(GTK_LIST_BOX(widget), source, pos);
00188     g_object_unref(source);
00189 }
00190
00191 static gboolean layer_selector_drag_motion(GtkWidget *widget, GdkDragContext *
context, int x, int y, guint time)
00192 {
00193     GtkAllocation alloc;
00194     GtkWidget *row;
00195     int hover_row_y;
00196     int hover_row_height;
00197     GtkWidget *drag_row;
00198     GtkWidget *row_before;
00199     GtkWidget *row_after;
00200
00201     row = GTK_WIDGET(gtk_list_box_get_row_at_y(GTK_LIST_BOX(widget), y));
00202
00203     drag_row = GTK_WIDGET(g_object_get_data(G_OBJECT(widget), "drag-row"));
00204     row_after = GTK_WIDGET(g_object_get_data(G_OBJECT(widget), "row-after"));
00205     row_before = GTK_WIDGET(g_object_get_data(G_OBJECT(widget), "row-before"));
00206
00207     gtk_style_context_remove_class(gtk_widget_get_style_context(drag_row), "drag-hover");
00208     if (row_before)
00209         gtk_style_context_remove_class(gtk_widget_get_style_context(row_before), "drag-hover-bottom");
00210     if (row_after)
00211         gtk_style_context_remove_class(gtk_widget_get_style_context(row_after), "drag-hover-top");
00212
00213     if (row) {
00214         gtk_widget_get_allocation(row, &alloc);
00215         hover_row_y = alloc.y;
00216         hover_row_height = alloc.height;
00217
00218         if (y < hover_row_y + hover_row_height/2) {
00219             row_after = row;
00220             row_before = GTK_WIDGET(layer_selector_get_row_before(GTK_LIST_BOX
(widget),
                                GTK_LIST_BOX_ROW(row)));
00221         } else {
00222             row_before = row;
00223             row_after = GTK_WIDGET(layer_selector_get_row_after(GTK_LIST_BOX(
widget),
                                GTK_LIST_BOX_ROW(row)));
00224         }
00225     } else {
00226     } else {
00227         row_before = GTK_WIDGET(layer_selector_get_last_row(GTK_LIST_BOX(widget)
));
00228     });
00229     row_after = NULL;
00230 }
00231
00232 g_object_set_data(G_OBJECT(widget), "row-before", row_before);
00233 g_object_set_data(G_OBJECT(widget), "row-after", row_after);
00234
00235 if (drag_row == row_before || drag_row == row_after) {
00236     gtk_style_context_add_class(gtk_widget_get_style_context(drag_row), "drag-hover");
00237     return FALSE;
00238 }
00239
00240 if (row_before)
00241     gtk_style_context_add_class(gtk_widget_get_style_context(row_before), "drag-hover-bottom");
00242 if (row_after)
00243     gtk_style_context_add_class(gtk_widget_get_style_context(row_after), "drag-hover-top");
00244
00245 return TRUE;
00246 }
00247
00248 static void layer_selector_drag_leave(GtkWidget *widget, GdkDragContext *context,
guint time)
00249 {
00250     GtkWidget *drag_row;
00251     GtkWidget *row_before;
00252     GtkWidget *row_after;
00253
00254     drag_row = GTK_WIDGET(g_object_get_data(G_OBJECT(widget), "drag-row"));
00255     row_before = GTK_WIDGET(g_object_get_data(G_OBJECT(widget), "row-before"));
00256     row_after = GTK_WIDGET(g_object_get_data(G_OBJECT(widget), "row-after"));
00257
00258     gtk_style_context_remove_class(gtk_widget_get_style_context(drag_row), "drag-hover");

```



```

00259     if (row_before)
00260         gtk_style_context_remove_class(gtk_widget_get_style_context(row_before), "drag-hover-bottom");
00261     if (row_after)
00262         gtk_style_context_remove_class(gtk_widget_get_style_context(row_after), "drag-hover-top");
00263
00264 }
00265
00266 static const char *dnd_additional_css =
00267     ".row:not(:first-child) { "
00268     " border-top: 1px solid alpha(gray,0.5); "
00269     " border-bottom: 1px solid transparent; "
00270     "}"
00271     ".row:first-child { "
00272     " border-top: 1px solid transparent; "
00273     " border-bottom: 1px solid transparent; "
00274     "}"
00275     ".row:last-child { "
00276     " border-top: 1px solid alpha(gray,0.5); "
00277     " border-bottom: 1px solid alpha(gray,0.5); "
00278     "}"
00279     ".row.drag-icon { "
00280     " background: #282828; "
00281     " border: 1px solid blue; "
00282     "}"
00283     ".row.drag-row { "
00284     " color: gray; "
00285     " background: alpha(gray,0.2); "
00286     "}"
00287     ".row.drag-row.drag-hover { "
00288     " border-top: 1px solid #4e9a06; "
00289     " border-bottom: 1px solid #4e9a06; "
00290     "}"
00291     ".row.drag-hover image, "
00292     ".row.drag-hover label { "
00293     " color: #4e9a06; "
00294     "}"
00295     ".row.drag-hover-top {"
00296     " border-top: 1px solid #4e9a06; "
00297     "}"
00298     ".row.drag-hover-bottom {"
00299     " border-bottom: 1px solid #4e9a06; "
00300     "}"
00301
00302 static void layer_selector_dispose(GObject *self)
00303 {
00304     LayerSelector *sel = LAYER_SELECTOR(self);
00305
00306     g_clear_object(&sel->list_box);
00307     g_clear_object(&sel->load_parent_window);
00308     g_clear_object(&sel->save_parent_window);
00309     g_clear_object(&sel->associated_load_button);
00310     g_clear_object(&sel->associated_save_button);
00311
00312     if (sel->dnd_target.target) {
00313         g_free(sel->dnd_target.target);
00314         sel->dnd_target.target = NULL;
00315     }
00316
00317     /* Chain up to parent's dispose function */
00318     G_OBJECT_CLASS(layer_selector_parent_class)->dispose(self);
00319 }
00320
00321 static void layer_selector_class_init(LayerSelectorClass *klass)
00322 {
00323     GObjectClass *object_class = G_OBJECT_CLASS(klass);
00324     GtkCssProvider *provider;
00325
00326     /* Implement handles to virtual functions */
00327     object_class->dispose = layer_selector_dispose;
00328
00329     /* Setup the CSS provider for the drag and drop animations once */
00330     provider = gtk_css_provider_new();
00331     gtk_css_provider_load_from_data(provider, dnd_additional_css, -1, NULL);
00332     gtk_style_context_add_provider_for_screen(gdk_screen_get_default(), GTK_STYLE_PROVIDER(provider), 800);
00333
00334     g_object_unref(provider);
00335 }
00336
00337 static void layer_selector_setup_dnd(LayerSelector *self)
00338 {
00339     gtk_drag_dest_set(GTK_WIDGET(self->list_box), GTK_DEST_DEFAULT_MOTION | GTK_DEST_DEFAULT_DROP, &self->
dnd_target, 1, GDK_ACTION_MOVE);
00340     g_signal_connect(self->list_box, "drag-data-received", G_CALLBACK(
layer_selector_drag_data_received), NULL);
00341     g_signal_connect(self->list_box, "drag-motion", G_CALLBACK(
layer_selector_drag_motion), NULL);
00342     g_signal_connect(self->list_box, "drag-leave", G_CALLBACK(

```

```

        layer_selector_drag_leave), NULL);
00343 }
00344
00345 /* Drag and drop end */
00346
00347 static void layer_selector_init(LayerSelector *self)
00348 {
00349     self->load_parent_window = NULL;
00350     self->save_parent_window = NULL;
00351     self->associated_load_button = NULL;
00352     self->associated_save_button = NULL;
00353
00354     self->dnd_target.target = g_strdup_printf("LAYER_SELECTOR_DND_%p", self);
00355     self->dnd_target.info = 0;
00356     self->dnd_target.flags = GTK_TARGET_SAME_APP;
00357 }
00358
00359 LayerSelector *layer_selector_new(GtkListBox *list_box)
00360 {
00361     LayerSelector *selector;
00362
00363     if (GTK_IS_LIST_BOX(list_box) == FALSE)
00364         return NULL;
00365
00366     selector = LAYER_SELECTOR(g_object_new(TYPE_LAYER_SELECTOR, NULL));
00367     selector->list_box = list_box;
00368     layer_selector_setup_dnd(selector);
00369     g_object_ref(G_OBJECT(list_box));
00370
00371     return selector;
00372 }
00373
00374 GList *layer_selector_export_rendered_layer_info(LayerSelector *
selector)
00375 {
00376     GList *info_list = NULL;
00377     LayerElement *le;
00378     struct layer_info *linfo;
00379     GList *row_list;
00380     GList *temp;
00381     int i;
00382
00383     if (!selector)
00384         return NULL;
00385
00386     row_list = gtk_container_get_children(GTK_CONTAINER(selector->list_box));
00387
00388     /* Iterate through widgets and add layers that shall be exported */
00389     for (i = 0, temp = row_list; temp != NULL; temp = temp->next, i++) {
00390
00391         le = LAYER_ELEMENT(temp->data);
00392
00393         if (layer_element_get_export(le) == TRUE) {
00394             /* Allocate new info and fill with info */
00395             linfo = (struct layer_info *)malloc(sizeof(struct
layer_info));
00396             layer_element_get_color(le, &linfo->color);
00397             linfo->layer = layer_element_get_layer(le);
00398             linfo->stacked_position = i;
00399             linfo->name = (char *)layer_element_get_name(le);
00400
00401             /* Append to list */
00402             info_list = g_list_append(info_list, (gpointer)linfo);
00403         }
00404     }
00405
00406     return info_list;
00407 }
00408
00409 static void layer_selector_clear_widgets(LayerSelector *self)
00410 {
00411     GList *list;
00412     GList *temp;
00413
00414     list = gtk_container_get_children(GTK_CONTAINER(self->list_box));
00415     for (temp = list; temp != NULL; temp = temp->next) {
00416         gtk_container_remove(GTK_CONTAINER(self->list_box), GTK_WIDGET(temp->data));
00417     }
00418     /* Widgets are already destroyed when removed from box because they are only referenced inside the
container */
00419
00420     g_list_free(list);
00421
00422     /* Deactivate buttons */
00423     if (self->associated_load_button)
00424         gtk_widget_set_sensitive(self->associated_load_button, FALSE);
00425     if (self->associated_save_button)

```

```

00426         gtk_widget_set_sensitive(self->associated_save_button, FALSE);
00427     }
00428
00435 static gboolean layer_selector_check_if_layer_widget_exists(
LayerSelector *self, int layer) {
00436     GList *list;
00437     GList *temp;
00438     LayerElement *widget;
00439     gboolean ret = FALSE;
00440
00441     list = gtk_container_get_children(GTK_CONTAINER(self->list_box));
00442
00443     for (temp = list; temp != NULL; temp = temp->next) {
00444         widget = LAYER_ELEMENT(temp->data);
00445         if (layer_element_get_layer(widget) == layer) {
00446             ret = TRUE;
00447             break;
00448         }
00449     }
00450
00451     g_list_free(list);
00452
00453     return ret;
00454 }
00455
00461 static void sel_layer_element_setup_dnd_callbacks(LayerSelector *self,
LayerElement *element)
00462 {
00463     struct layer_element_dnd_data dnd_data;
00464
00465     if (!self || !element)
00466         return;
00467
00468     dnd_data.entries = &self->dnd_target;
00469     dnd_data.entry_count = 1;
00470     dnd_data.drag_end = sel_layer_element_drag_end;
00471     dnd_data.drag_begin = sel_layer_element_drag_begin;
00472     dnd_data.drag_data_get = sel_layer_element_drag_data_get;
00473
00474     layer_element_set_dnd_callbacks(element, &dnd_data);
00475 }
00476
00482 static void layer_selector_analyze_cell_layers(LayerSelector *self,
struct gds_cell *cell)
00483 {
00484     GList *graphics;
00485     struct gds_graphics *gfx;
00486     int layer;
00487     GtkWidget *le;
00488
00489     for (graphics = cell->graphic_objs; graphics != NULL; graphics = graphics->next) {
00490         gfx = (struct gds_graphics *)graphics->data;
00491         layer = (int)gfx->layer;
00492         if (layer_selector_check_if_layer_widget_exists(self,
layer) == FALSE) {
00493             le = layer_element_new();
00494             sel_layer_element_setup_dnd_callbacks(self, LAYER_ELEMENT(
le));
00495             layer_element_set_layer(LAYER_ELEMENT(le),
layer);
00496             gtk_list_box_insert(self->list_box, le, -1);
00497             gtk_widget_show(le);
00498         }
00499     }
00500 }
00501
00510 static gint layer_selector_sort_func(GtkListBoxRow *row1, GtkListBoxRow *row2,
gpointer unused)
00511 {
00512     LayerElement *le1, *le2;
00513     gint ret;
00514     static const enum layer_selector_sort_algo default_sort =
LAYER_SELECTOR_SORT_DOWN;
00515     const enum layer_selector_sort_algo *algo = (const enum
layer_selector_sort_algo *)unused;
00516
00517     /* Assume downward sorting */
00518     /* TODO: This is nasty. Find a better way */
00519     if (!algo)
00520         algo = &default_sort;
00521
00522     le1 = LAYER_ELEMENT(row1);
00523     le2 = LAYER_ELEMENT(row2);
00524
00525     /* Determine sort fow downward sort */
00526     ret = layer_element_get_layer(le1) -
layer_element_get_layer(le2);

```

```

00527
00528 /* Change order if upward sort is requested */
00529 ret *= (*algo == LAYER_SELECTOR_SORT_DOWN ? 1 : -1);
00530
00531 return ret;
00532 }
00533
00534 void layer_selector_generate_layer_widgets(LayerSelector *selector,
GList *libs)
00535 {
00536     GList *cell_list = NULL;
00537     struct gds_library *lib;
00538
00539     layer_selector_clear_widgets(selector);
00540
00541     for (; libs != NULL; libs = libs->next) {
00542         lib = (struct gds_library *)libs->data;
00543         for (cell_list = lib->cells; cell_list != NULL; cell_list = cell_list->next) {
00544             layer_selector_analyze_cell_layers(selector, (struct
gds_cell *)cell_list->data);
00545         } /* For Cell List */
00546     } /* For libs */
00547
00548     /* Sort the layers */
00549     layer_selector_force_sort(selector,
LAYER_SELECTOR_SORT_DOWN);
00550
00551     /* Activate Buttons */
00552     if (selector->associated_load_button)
00553         gtk_widget_set_sensitive(selector->associated_load_button, TRUE);
00554     if (selector->associated_save_button)
00555         gtk_widget_set_sensitive(selector->associated_save_button, TRUE);
00556 }
00557
00564 static LayerElement *layer_selector_find_layer_element_in_list(
GList *el_list, int layer)
00565 {
00566     LayerElement *ret = NULL;
00567     for (; el_list != NULL; el_list = el_list->next) {
00568         if (layer_element_get_layer(LAYER_ELEMENT(el_list->data)) == layer) {
00569             ret = LAYER_ELEMENT(el_list->data);
00570             break;
00571         }
00572     }
00573     return ret;
00574 }
00575
00587 static void layer_selector_load_layer_mapping_from_file(
LayerSelector *self, gchar *file_name)
00588 {
00589     GFile *file;
00590     GFileInputStream *stream;
00591     GDataInputStream *dstream;
00592     LayerElement *le;
00593     char *name;
00594     gboolean export;
00595     int layer;
00596     GdkRGBA color;
00597     int result;
00598     GList *rows;
00599     GList *temp;
00600
00601     file = g_file_new_for_path(file_name);
00602     stream = g_file_read(file, NULL, NULL);
00603
00604     if (!stream)
00605         goto destroy_file;
00606
00607     dstream = g_data_input_stream_new(G_INPUT_STREAM(stream));
00608
00609     rows = gtk_container_get_children(GTK_CONTAINER(self->list_box));
00610
00611     /* Reference and remove all rows from box */
00612     for (temp = rows; temp != NULL; temp = temp->next) {
00613         le = LAYER_ELEMENT(temp->data);
00614         /* Referencing protects the widget from being deleted when removed */
00615         g_object_ref(G_OBJECT(le));
00616         gtk_container_remove(GTK_CONTAINER(self->list_box), GTK_WIDGET(le));
00617     }
00618
00619     while((result = mapping_parser_load_line(dstream, &export, &
name, &layer, &color)) >= 0) {
00620         /* skip broken line */
00621         if (result == 1)
00622             continue;
00623
00624         /* Add rows in the same order as in file */

```

```

00625     if ((le = layer_selector_find_layer_element_in_list(rows,
layer))) {
00626         gtk_list_box_insert(self->list_box, GTK_WIDGET(le), -1);
00627
00628         layer_element_set_color(le, &color);
00629         layer_element_set_export(le, export);
00630         layer_element_set_name(le, name);
00631         g_free(name);
00632
00633         /* Dereference and remove from list */
00634         g_object_unref(G_OBJECT(le));
00635         rows = g_list_remove(rows, le);
00636     }
00637 }
00638
00639 /* Add remaining elements */
00640 for (temp = rows; temp != NULL; temp = temp->next) {
00641     le = LAYER_ELEMENT(temp->data);
00642     /* Referencing protects the widget from being deleted when removed */
00643     gtk_list_box_insert(self->list_box, GTK_WIDGET(le), -1);
00644     g_object_unref(G_OBJECT(le));
00645 }
00646
00647 /* Delete list */
00648 g_list_free(rows);
00649
00650 /* read line */
00651 g_object_unref(dstream);
00652 g_object_unref(stream);
00653 destroy_file:
00654     g_object_unref(file);
00655 }
00656
00662 static void layer_selector_load_mapping_clicked(GtkWidget *button,
gpointer user_data)
00663 {
00664     LayerSelector *sel;
00665     GtkWidget *dialog;
00666     gint res;
00667     gchar *file_name;
00668
00669     sel = LAYER_SELECTOR(user_data);
00670
00671     dialog = gtk_file_chooser_dialog_new("Load Mapping File", GTK_WINDOW(sel->load_parent_window),
GTK_FILE_CHOOSER_ACTION_OPEN,
00672         "Cancel", GTK_RESPONSE_CANCEL, "Load Mapping", GTK_RESPONSE_ACCEPT, NULL);
00673     res = gtk_dialog_run(GTK_DIALOG(dialog));
00674     if (res == GTK_RESPONSE_ACCEPT) {
00675         file_name = gtk_file_chooser_get_filename(GTK_FILE_CHOOSER(dialog));
00676         layer_selector_load_layer_mapping_from_file(sel,
file_name);
00677         g_free(file_name);
00678     }
00679     gtk_widget_destroy(dialog);
00680 }
00681
00682
00683
00689 static void layer_selector_save_layer_mapping_data(LayerSelector *
self, const gchar *file_name)
00690 {
00691     FILE *file;
00692     char workbuff[512];
00693     GList *le_list;
00694     GList *temp;
00695
00696     /* Overwrite existing file */
00697     file = fopen((const char *)file_name, "w");
00698
00699     le_list = gtk_container_get_children(GTK_CONTAINER(self->list_box));
00700
00701     /* File format is CSV: <Layer>,<target_pos>,<R>,<G>,<B>,<Alpha>,<Export?>,<Name> */
00702     for (temp = le_list; temp != NULL; temp = temp->next) {
00703         /* To be sure it is a valid string */
00704         workbuff[0] = 0;
00705         mapping_parser_gen_csv_line(LAYER_ELEMENT(temp->data), workbuff, sizeof(
workbuff));
00706         fwrite(workbuff, sizeof(char), strlen(workbuff), file);
00707     }
00708
00709     g_list_free(le_list);
00710
00711     /* Save File */
00712     fflush(file);
00713     fclose(file);
00714 }
00715

```

```

00721 static void layer_selector_save_mapping_clicked(GtkWidget *button,
00722 gpointer user_data)
00723 {
00724     GtkWidget *dialog;
00725     gint res;
00726     gchar *file_name;
00727     LayerSelector *sel;
00728     sel = LAYER_SELECTOR(user_data);
00729
00730     dialog = gtk_file_chooser_dialog_new("Save Mapping File", GTK_WINDOW(sel->save_parent_window),
00731 GTK_FILE_CHOOSER_ACTION_SAVE,
00732 "Cancel", GTK_RESPONSE_CANCEL, "Save Mapping", GTK_RESPONSE_ACCEPT, NULL);
00733     gtk_file_chooser_set_do_overwrite_confirmation(GTK_FILE_CHOOSER(dialog), TRUE);
00734
00735     res = gtk_dialog_run(GTK_DIALOG(dialog));
00736     if (res == GTK_RESPONSE_ACCEPT) {
00737         file_name = gtk_file_chooser_get_filename(GTK_FILE_CHOOSER(dialog));
00738         layer_selector_save_layer_mapping_data(sel, file_name);
00739         g_free(file_name);
00740     }
00741     gtk_widget_destroy(dialog);
00742 }
00743 void layer_selector_set_load_mapping_button(LayerSelector *selector,
00744 GtkWidget *button, GtkWindow *main_window)
00745 {
00746     g_clear_object(&selector->load_parent_window);
00747     g_clear_object(&selector->associated_load_button);
00748
00749     g_object_ref(G_OBJECT(button));
00750     g_object_ref(G_OBJECT(main_window));
00751     selector->associated_load_button = button;
00752     selector->load_parent_window = main_window;
00753     g_signal_connect(button, "clicked", G_CALLBACK(
00754 layer_selector_load_mapping_clicked), selector);
00755 }
00756 void layer_selector_set_save_mapping_button(LayerSelector *selector,
00757 GtkWidget *button, GtkWindow *main_window)
00758 {
00759     g_clear_object(&selector->save_parent_window);
00760     g_clear_object(&selector->associated_save_button);
00761
00762     g_object_ref(G_OBJECT(button));
00763     g_object_ref(G_OBJECT(main_window));
00764     selector->associated_save_button = button;
00765     selector->save_parent_window = main_window;
00766     g_signal_connect(button, "clicked", G_CALLBACK(
00767 layer_selector_save_mapping_clicked), selector);
00768 }
00769 void layer_selector_force_sort(LayerSelector *selector, enum
00770 layer_selector_sort_algo sort_function)
00771 {
00772     GtkWidget *box;
00773
00774     if (!selector)
00775         return;
00776
00777     box = selector->list_box;
00778     if (!box)
00779         return;
00780
00781     /* Set sorting function, sort, and disable sorting function */
00782     gtk_list_box_set_sort_func(box, layer_selector_sort_func, (gpointer)&
00783 sort_function, NULL);
00784     gtk_list_box_invalidate_sort(box);
00785     gtk_list_box_set_sort_func(box, NULL, NULL, NULL);
00786 }
00787 }
00788 }
00789 }

```


13.62 layer-selector.dox File Reference

13.63 layer-selector.h File Reference


Implementation of the Layer selection list.

```
#include <gtk/gtk.h>
#include <glib.h>
```

Include dependency graph for layer-selector.h:



This graph shows which files directly or indirectly include this file:



Macros

- `#define` [TYPE_LAYER_SELECTOR](#) ([layer_selector_get_type\(\)](#))

Enumerations

- enum [layer_selector_sort_algo](#) { [LAYER_SELECTOR_SORT_DOWN](#) = 0, [LAYER_SELECTOR_SORT_UP](#) }

Defines how to sort the layer selector list box.

Functions

- `G_BEGIN_DECLS` [G_DECLARE_FINAL_TYPE](#) ([LayerSelector](#), [layer_selector](#), [LAYER_SELECTOR](#), [G_TYPE_LAYER_SELECTOR](#), [G_TYPE_OBJECT](#))
- [LayerSelector *](#) [layer_selector_new](#) ([GtkListBox *](#)*list_box*)
layer_selector_new
- void [layer_selector_generate_layer_widgets](#) ([LayerSelector *](#)*selector*, [GList *](#)*libs*)

Generate layer widgets in in the LayerSelector instance.

- void `layer_selector_set_load_mapping_button` (LayerSelector *selector, GtkWidget *button, GtkWidget *main_window)

Supply button for loading the layer mapping.

- void `layer_selector_set_save_mapping_button` (LayerSelector *selector, GtkWidget *button, GtkWidget *main_window)

Supply button for saving the layer mapping.

- GList * `layer_selector_export_rendered_layer_info` (LayerSelector *selector)

Get a list of all layers that shall be exported when rendering the cells.

- void `layer_selector_force_sort` (LayerSelector *selector, enum `layer_selector_sort_algo` sort_function)

Force the layer selector list to be sorted according to `sort_function`.

13.63.1 Detailed Description

Implementation of the Layer selection list.

Author

Mario Hüttel mario.huettel@gmx.net

Definition in file [layer-selector.h](#).

13.64 layer-selector.h

```

00001 /*
00002  * GDSII-Converter
00003  * Copyright (C) 2018 Mario Hüttel <mario.huettel@gmx.net>
00004  *
00005  * This file is part of GDSII-Converter.
00006  *
00007  * GDSII-Converter is free software: you can redistribute it and/or modify
00008  * it under the terms of the GNU General Public License version 2 as
00009  * published by the Free Software Foundation.
00010  *
00011  * GDSII-Converter is distributed in the hope that it will be useful,
00012  * but WITHOUT ANY WARRANTY; without even the implied warranty of
00013  * MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE. See the
00014  * GNU General Public License for more details.
00015  *
00016  * You should have received a copy of the GNU General Public License
00017  * along with GDSII-Converter. If not, see <http://www.gnu.org/licenses/>.
00018  */
00019
00031 #ifndef __LAYER_SELECTOR_H__
00032 #define __LAYER_SELECTOR_H__
00033
00034 #include <gtk/gtk.h>
00035 #include <glib.h>
00036
00037 G_BEGIN_DECLS
00038
00039 G_DECLARE_FINAL_TYPE(LayerSelector, layer_selector, LAYER, SELECTOR, GObject);
00040
00041 #define TYPE_LAYER_SELECTOR (layer_selector_get_type())
00042
00046 enum layer_selector_sort_algo {LAYER_SELECTOR_SORT_DOWN = 0
, LAYER_SELECTOR_SORT_UP};
00047
00053 LayerSelector *layer_selector_new(GtkListBox *list_box);
00054
00061 void layer_selector_generate_layer_widgets(LayerSelector *selector,
GList *libs);
00062
00069 void layer_selector_set_load_mapping_button(LayerSelector *selector,
GtkWidget *button, GtkWidget *main_window);
00070

```



```

00077 void layer_selector_set_save_mapping_button(LayerSelector *selector,
GtkWidget *button, GtkWidget *main_window);
00078
00084 GList *layer_selector_export_rendered_layer_info(LayerSelector *
selector);
00085
00091 void layer_selector_force_sort(LayerSelector *selector, enum
layer_selector_sort_algo sort_function);
00092
00093 G_END_DECLS
00094
00095 #endif /* __LAYER_SELECTOR_H__ */
00096

```


13.65 lib-cell-renderer.c File Reference

LibCellRenderer GObject Class.

```

#include <gds-render/tree-renderer/lib-cell-renderer.h>
#include <gds-render/gds-utils/gds-types.h>
Include dependency graph for lib-cell-renderer.c:

```



Enumerations

- enum { PROP_LIB = 1, PROP_CELL, PROP_ERROR_LEVEL, PROP_COUNT }

Functions

- void [lib_cell_renderer_init](#) (LibCellRenderer *self)
- static void [lib_cell_renderer_constructed](#) (GObject *obj)
- static void [convert_error_level_to_color](#) (GdkRGBA *color, unsigned int error_level)
- static void [lib_cell_renderer_set_property](#) (GObject *object, guint param_id, const GValue *value, GParamSpec *pspec)
- static void [lib_cell_renderer_get_property](#) (GObject *object, guint param_id, GValue *value, GParamSpec *pspec)
- void [lib_cell_renderer_class_init](#) (LibCellRendererClass *klass)
- GtkCellRenderer * [lib_cell_renderer_new](#) (void)

Create a new renderer for rendering [gds_cell](#) and [gds_library](#) elements.

Variables

- static GParamSpec * [properties](#) [[PROP_COUNT](#)]

13.65.1 Detailed Description

LibCellRenderer GObject Class.

Author

Mario Hüttel mario.huettel@gmx.net

Definition in file [lib-cell-renderer.c](#).

13.66 lib-cell-renderer.c

```

00001 /*
00002  * GDSII-Converter
00003  * Copyright (C) 2018 Mario Hüttel <mario.huettel@gmx.net>
00004  *
00005  * This file is part of GDSII-Converter.
00006  *
00007  * GDSII-Converter is free software: you can redistribute it and/or modify
00008  * it under the terms of the GNU General Public License version 2 as
00009  * published by the Free Software Foundation.
00010  *
00011  * GDSII-Converter is distributed in the hope that it will be useful,
00012  * but WITHOUT ANY WARRANTY; without even the implied warranty of
00013  * MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE. See the
00014  * GNU General Public License for more details.
00015  *
00016  * You should have received a copy of the GNU General Public License
00017  * along with GDSII-Converter. If not, see <http://www.gnu.org/licenses/>.
00018  */
00019
00031 #include <gds-render/tree-renderer/lib-cell-renderer.h>
00032 #include <gds-render/gds-utils/gds-types.h>
00033
00034 G_DEFINE_TYPE(LibCellRenderer, lib_cell_renderer, GTK_TYPE_CELL_RENDERER_TEXT)
00035
00036 enum {
00037     PROP_LIB = 1,
00038     PROP_CELL,
00039     PROP_ERROR_LEVEL,
00040     PROP_COUNT
00041 };
00042
00043 void lib_cell_renderer_init(LibCellRenderer *self)
00044 {
00045     /* Nothing to do */
00046 }
00047
00048 static void lib_cell_renderer_constructed(GObject *obj)
00049 {
00050     G_OBJECT_CLASS(lib_cell_renderer_parent_class)->constructed(obj);
00051 }
00052
00053 static void convert_error_level_to_color(GdkRGBA *color, unsigned int
error_level)
00054 {
00055
00056     /* Always use no transparency */
00057     color->alpha = 1.0;
00058
00059     if (error_level & LIB_CELL_RENDERER_ERROR_ERR) {
00060         /* Error set. Color cell red */
00061         color->red = 1.0;
00062         color->blue = 0.0;
00063         color->green = 0.0;
00064     } else if (error_level & LIB_CELL_RENDERER_ERROR_WARN) {
00065         /* Only warning set; orange color */
00066         color->red = 1.0;

```

```

00067     color->blue = 0.0;
00068     color->green = 0.6;
00069 } else {
00070     /* Everything okay; green color */
00071     color->red = (double)61.0/(double)255.0;
00072     color->green = (double)152.0/(double)255.0;
00073     color->blue = 0.0;
00074 }
00075 }
00076
00077 static void lib_cell_renderer_set_property(GObject      *object,
00078     guint      param_id,
00079     const GValue *value,
00080     GParamSpec *pspec)
00081 {
00082     GValue val = G_VALUE_INIT;
00083     GdkRGBA color;
00084
00085     switch (param_id) {
00086     case PROP_LIB:
00087         g_value_init(&val, G_TYPE_STRING);
00088         g_value_set_string(&val, ((struct gds_library *)g_value_get_pointer(value))->
00089     name);
00089         g_object_set_property(object, "text", &val);
00090         break;
00091     case PROP_CELL:
00092         g_value_init(&val, G_TYPE_STRING);
00093         g_value_set_string(&val, ((struct gds_cell *)g_value_get_pointer(value))->
00094     name);
00094         g_object_set_property(object, "text", &val);
00095         break;
00096     case PROP_ERROR_LEVEL:
00097         /* Set cell color according to error level */
00098         g_value_init(&val, GDK_TYPE_RGBA);
00099         convert_error_level_to_color(&color, g_value_get_uint(value));
00100         g_value_set_boxed(&val, &color);
00101         g_object_set_property(object, "foreground-rgba", &val);
00102         break;
00103     default:
00104         G_OBJECT_WARN_INVALID_PROPERTY_ID(object, param_id, pspec);
00105         break;
00106     }
00107 }
00108
00109 static void lib_cell_renderer_get_property(GObject      *object,
00110     guint      param_id,
00111     GValue      *value,
00112     GParamSpec *pspec)
00113 {
00114     switch (param_id) {
00115     default:
00116         G_OBJECT_WARN_INVALID_PROPERTY_ID(object, param_id, pspec);
00117         break;
00118     }
00119 }
00120
00121 static GParamSpec *properties[PROP_COUNT];
00122
00123 void lib_cell_renderer_class_init(LibCellRendererClass *klass)
00124 {
00125     GObjectClass *oclass = G_OBJECT_CLASS(klass);
00126
00127     oclass->constructed = lib_cell_renderer_constructed;
00128     oclass->set_property = lib_cell_renderer_set_property;
00129     oclass->get_property = lib_cell_renderer_get_property;
00130
00131     properties[PROP_LIB] = g_param_spec_pointer("gds-lib", "gds-lib",
00132         "Library reference to be displayed",
00133         G_PARAM_WRITABLE);
00134     properties[PROP_CELL] = g_param_spec_pointer("gds-cell", "gds-cell",
00135         "Cell reference to be displayed",
00136         G_PARAM_WRITABLE);
00137     properties[PROP_ERROR_LEVEL] = g_param_spec_uint("error-level", "error-level",
00138         "Error level of this cell", 0, 255, 0, G_PARAM_WRITABLE);
00139
00140     g_object_class_install_properties(oclass, PROP_COUNT, properties);
00141 }
00142
00143 GtkCellRenderer *lib_cell_renderer_new()
00144 {
00145     return GTK_CELL_RENDERER(g_object_new(TYPE_LIB_CELL_RENDERER, NULL));
00146 }
00147

```


13.67 lib-cell-renderer.dox File Reference

13.68 lib-cell-renderer.h File Reference


Header file for the LibCellRenderer GObject Class.

```
#include <gtk/gtk.h>
```

Include dependency graph for lib-cell-renderer.h:



This graph shows which files directly or indirectly include this file:



Data Structures

- [struct `_LibCellRenderer`](#)

Macros

- [#define `TYPE_LIB_CELL_RENDERER` \(`lib_cell_renderer_get_type\(\)`\)](#)
- [#define `LIB_CELL_RENDERER_ERROR_WARN` \(`1U<<0`\)](#)
- [#define `LIB_CELL_RENDERER_ERROR_ERR` \(`1U<<1`\)](#)

Typedefs

- typedef struct `_LibCellRenderer` `LibCellRenderer`

Functions

- GType `lib_cell_renderer_get_type` (void)
lib_cell_renderer_get_type
- GtkCellRenderer * `lib_cell_renderer_new` (void)
Create a new renderer for rendering `gds_cell` and `gds_library` elements.

13.68.1 Detailed Description

Header file for the LibCellRenderer GObject Class.

Author

Mario Hüttel mario.huettel@gmx.net

Definition in file [lib-cell-renderer.h](#).

13.69 lib-cell-renderer.h

```

00001 /*
00002  * GDSII-Converter
00003  * Copyright (C) 2018 Mario Hüttel <mario.huettel@gmx.net>
00004  *
00005  * This file is part of GDSII-Converter.
00006  *
00007  * GDSII-Converter is free software: you can redistribute it and/or modify
00008  * it under the terms of the GNU General Public License version 2 as
00009  * published by the Free Software Foundation.
00010  *
00011  * GDSII-Converter is distributed in the hope that it will be useful,
00012  * but WITHOUT ANY WARRANTY; without even the implied warranty of
00013  * MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE. See the
00014  * GNU General Public License for more details.
00015  *
00016  * You should have received a copy of the GNU General Public License
00017  * along with GDSII-Converter. If not, see <http://www.gnu.org/licenses/>.
00018  */
00019
00031 #ifndef __LIB_CELL_RENDERER_H__
00032 #define __LIB_CELL_RENDERER_H__
00033
00034 #include <gtk/gtk.h>
00035
00036 G_BEGIN_DECLS
00037
00038 G_DECLARE_FINAL_TYPE(LibCellRenderer, lib_cell_renderer, LIB_CELL,
00039 RENDERER, GtkCellRendererText)
00039 #define TYPE_LIB_CELL_RENDERER (lib_cell_renderer_get_type())
00040
00044 #define LIB_CELL_RENDERER_ERROR_WARN (1U<<0)
00045 #define LIB_CELL_RENDERER_ERROR_ERR (1U<<1)
00046
00048 typedef struct _LibCellRenderer {
00049     /* Inheritance */
00050     GtkCellRendererText super;
00051     /* Custom Elements */
00052 } LibCellRenderer;
00053
00058 GType lib_cell_renderer_get_type(void);
00059
00064 GtkCellRenderer *lib_cell_renderer_new(void);
00065
00066 G_END_DECLS
00067
00068 #endif /* __LIB_CELL_RENDERER_H__ */
00069

```

13.70 Imf-spec.dox File Reference


13.71 main-page.dox File Reference

13.72 main.c File Reference

main.c

```
#include <stdio.h>
#include <gtk/gtk.h>
#include <glib.h>
#include <gds-render/gds-render-gui.h>
#include <gds-render/command-line.h>
#include <gds-render/external-renderer.h>
#include <gds-render/version.h>
```

Include dependency graph for main.c:



Data Structures

- struct [application_data](#)
Structure containing The GtkApplication and a list containing the GdsRenderGui objects.

Functions

- static void [app_quit](#) (GSimpleAction *action, GVariant *parameter, gpointer user_data)
Callback for the menu entry 'Quit'.
- static void [app_about](#) (GSimpleAction *action, GVariant *parameter, gpointer user_data)
Callback for the 'About' menu entry.
- static void [gui_window_closed_callback](#) (GdsRenderGui *gui, gpointer user_data)
Called when a GUI main window is closed.
- static void [gapp_activate](#) (GApplication *app, gpointer user_data)
Activation of the GUI.
- static int [start_gui](#) (int argc, char **argv)
Start the graphical interface.
- static void [print_version](#) (void)
Print the application version string to stdout.
- int [main](#) (int argc, char **argv)
The "entry point" of the application.

Variables

- static const GActionEntry [app_actions](#) []
Contains the application menu entries.

13.72.1 Detailed Description

[main.c](#)

Author

Mario Hüttel mario.huettel@gmx.net

Definition in file [main.c](#).

13.72.2 Function Documentation

13.72.2.1 [app_about\(\)](#)

```
static void app_about (  
    GSimpleAction * action,  
    GVariant * parameter,  
    gpointer user_data ) [static]
```

Callback for the 'About' menu entry.

This function shows the about dialog.

Parameters

<i>action</i>	GSimpleAction, unused
<i>parameter</i>	Unused.
<i>user_data</i>	Unused

Definition at line [83](#) of file [main.c](#).

13.72.2.2 [app_quit\(\)](#)

```
static void app_quit (  
    GSimpleAction * action,  
    GVariant * parameter,  
    gpointer user_data ) [static]
```

Callback for the menu entry 'Quit'.

Destroys all GUIs contained in the [application_data](#) structure provided by `user_data`.

The complete suspension of all main windows leads to the termination of the GApplication.

Parameters

<i>action</i>	unused
<i>parameter</i>	unused
<i>user_data</i>	application_data structure

Definition at line 56 of file [main.c](#).

13.72.2.3 `gapp_activate()`

```
static void gapp_activate (  
    GApplication * app,  
    gpointer user_data ) [static]
```


Activation of the GUI.

Parameters


<i>app</i>	The GApplication reference
<i>user_data</i>	Used to store the individual GUI instances.

Definition at line 148 of file [main.c](#).

Here is the call graph for this function:



Here is the caller graph for this function:



13.72.2.4 `gui_window_closed_callback()`

```

static void gui_window_closed_callback (
    GdsRenderGui * gui,
    gpointer user_data ) [static]
  
```

Called when a GUI main window is closed.


The `GdsRenderGui` object associated with the closed main window is removed from the list of open GUIs (`user_data`) and unreferenced.

Parameters

<i>gui</i>	The GUI instance the closed main window belongs to
<i>user_data</i>	List of GUIs

Definition at line [134](#) of file [main.c](#).

Here is the caller graph for this function:



13.72.2.5 `main()`

```

int main (
    int argc,
    char ** argv )
  
```

The "entry point" of the application.

Parameters


<i>argc</i>	Number of command line parameters
<i>argv</i>	Command line parameters

Returns

Execution status of the application

Definition at line 237 of file [main.c](#).

Here is the call graph for this function:



13.72.2.6 print_version()

```
static void print_version (
    void ) [static]
```

Print the application version string to stdout.

Definition at line 225 of file [main.c](#).

Here is the caller graph for this function:



13.72.2.7 start_gui()

```

static int start_gui (
    int argc,
    char ** argv ) [static]
  
```

Start the graphical interface.

This function starts the GUI. If there's already a running instance of this program, a second window will be created in that instance and the second one is terminated.


Parameters

<i>argc</i>	
<i>argv</i>	


Returns

Definition at line 177 of file [main.c](#).

Here is the call graph for this function:



Here is the caller graph for this function:



13.72.3 Variable Documentation

13.72.3.1 app_actions

```
const GActionEntry app_actions[] [static]
```

Initial value:

```
= {
  {"quit", app_quit, NULL, NULL, NULL, {0}},
  {"about", app_about, NULL, NULL, NULL, {0}}
}
```

Contains the application menu entries.

Definition at line 120 of file [main.c](#).

13.73 main.c

```

00001 /*
00002  * GDSII-Converter
00003  * Copyright (C) 2018 Mario Hüttel <mario.huettel@gmx.net>
00004  *
00005  * This file is part of GDSII-Converter.
00006  *
00007  * GDSII-Converter is free software: you can redistribute it and/or modify
00008  * it under the terms of the GNU General Public License version 2 as
00009  * published by the Free Software Foundation.
00010  *
00011  * GDSII-Converter is distributed in the hope that it will be useful,
00012  * but WITHOUT ANY WARRANTY; without even the implied warranty of
00013  * MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE. See the
00014  * GNU General Public License for more details.
00015  *
00016  * You should have received a copy of the GNU General Public License
00017  * along with GDSII-Converter. If not, see <http://www.gnu.org/licenses/>.
00018  */
00019
00026 #include <stdio.h>
00027 #include <gtk/gtk.h>
00028 #include <glib.h>
00029
00030 #include <gds-render/gds-render-gui.h>
00031 #include <gds-render/command-line.h>
00032 #include <gds-render/external-renderer.h>
00033 #include <gds-render/version.h>
00034

```

```

00038 struct application_data {
00039     GtkApplication *app;
00040     GList *gui_list;
00041 };
00042
00056 static void app_quit(GSimpleAction *action, GVariant *parameter, gpointer user_data)
00057 {
00058     struct application_data * const appdata = (struct
application_data *)user_data;
00059     (void)action;
00060     (void)parameter;
00061     GList *list_iter;
00062     GdsRenderGui *gui;
00063
00064     /* Dispose all GUIs */
00065     for (list_iter = appdata->gui_list; list_iter != NULL; list_iter = g_list_next(list_iter)) {
00066         gui = RENDERER_GUI(list_iter->data);
00067         g_object_unref(gui);
00068     }
00069
00070     g_list_free(appdata->gui_list);
00071     appdata->gui_list = NULL;
00072 }
00073
00083 static void app_about(GSimpleAction *action, GVariant *parameter, gpointer user_data)
00084 {
00085     GtkBuilder *builder;
00086     GtkDialog *dialog;
00087     GdkPixbuf *logo_buf;
00088     GError *error = NULL;
00089     (void)user_data;
00090     (void)action;
00091     (void)parameter;
00092
00093     builder = gtk_builder_new_from_resource("/about.glade");
00094     dialog = GTK_DIALOG(gtk_builder_get_object(builder, "about-dialog"));
00095     gtk_window_set_transient_for(GTK_WINDOW(dialog), NULL);
00096     gtk_about_dialog_set_version(GTK_ABOUT_DIALOG(dialog), _app_version_string);
00097
00098     /* Load icon from resource */
00099     logo_buf = gdk_pixbuf_new_from_resource_at_scale("/logo.svg", 100, 100, TRUE, &error);
00100     if (logo_buf) {
00101         /* Set logo */
00102         gtk_about_dialog_set_logo(GTK_ABOUT_DIALOG(dialog), logo_buf);
00103
00104         /* Pixbuf is now owned by about dialog. Unref */
00105         g_object_unref(logo_buf);
00106     } else if (error) {
00107         fprintf(stderr, "Logo could not be displayed: %s\n", error->message);
00108         g_error_free(error);
00109     }
00110
00111     gtk_dialog_run(dialog);
00112
00113     gtk_widget_destroy(GTK_WIDGET(dialog));
00114     g_object_unref(builder);
00115 }
00116
00120 const static GActionEntry app_actions[] = {
00121     {"quit", app_quit, NULL, NULL, NULL, {0}},
00122     {"about", app_about, NULL, NULL, NULL, {0}}
00123 };
00124
00134 static void gui_window_closed_callback(GdsRenderGui *gui, gpointer user_data)
00135 {
00136     GList **gui_list = (GList **)user_data;
00137
00138     /* Dispose of Gui element */
00139     *gui_list = g_list_remove(*gui_list, gui);
00140     g_object_unref(gui);
00141 }
00142
00148 static void gapp_activate(GApplication *app, gpointer user_data)
00149 {
00150     GtkWindow *main_window;
00151     GdsRenderGui *gui;
00152
00153     struct application_data * const appdata = (struct
application_data *)user_data;
00154
00155     gui = gds_render_gui_new();
00156     appdata->gui_list = g_list_append(appdata->gui_list, gui);
00157
00158     g_signal_connect(gui, "window-closed", G_CALLBACK(gui_window_closed_callback)
, &appdata->gui_list);
00159
00160     main_window = gds_render_gui_get_main_window(gui);

```

```

00161
00162     gtk_application_add_window(GTK_APPLICATION(app), main_window);
00163     gtk_widget_show(GTK_WIDGET(main_window));
00164 }
00165
00177 static int start_gui(int argc, char **argv)
00178 {
00179
00180     GtkApplication *gapp;
00181     int app_status;
00182     static struct application_data appdata = {
00183         .gui_list = NULL
00184     };
00185     GMenu *menu;
00186     GMenu *m_quit;
00187     GMenu *m_about;
00188
00189     gapp = gtk_application_new("de.shimatta.gds-render", G_APPLICATION_FLAGS_NONE);
00190     g_application_register(G_APPLICATION(gapp), NULL, NULL);
00191     g_signal_connect(gapp, "activate", G_CALLBACK(gapp_activate), &appdata);
00192
00193     if (g_application_get_is_remote(G_APPLICATION(gapp)) == TRUE) {
00194         g_application_activate(G_APPLICATION(gapp));
00195         printf("There is already an open instance. Will open second window in said instance.\n");
00196         return 0;
00197     }
00198
00199     menu = g_menu_new();
00200     m_quit = g_menu_new();
00201     m_about = g_menu_new();
00202     g_menu_append(m_quit, "Quit", "app.quit");
00203     g_menu_append(m_about, "About", "app.about");
00204     g_menu_append_section(menu, NULL, G_MENU_MODEL(m_about));
00205     g_menu_append_section(menu, NULL, G_MENU_MODEL(m_quit));
00206     g_action_map_add_action_entries(G_ACTION_MAP(gapp), app_actions,
00207         G_N_ELEMENTS(app_actions), &appdata);
00208     gtk_application_set_app_menu(GTK_APPLICATION(gapp), G_MENU_MODEL(menu));
00209
00210     g_object_unref(m_quit);
00211     g_object_unref(m_about);
00212     g_object_unref(menu);
00213
00214     app_status = g_application_run(G_APPLICATION(gapp), argc, argv);
00215     g_object_unref(gapp);
00216
00217     g_list_free(appdata.gui_list);
00218
00219     return app_status;
00220 }
00221
00225 static void print_version(void)
00226 {
00227     printf("This is gds-render, version: %s\n\nFor a list of supported commands execute with --help option.
00228     \n",
00229         _app_version_string);
00230 }
00231
00237 int main(int argc, char **argv)
00238 {
00239     int i;
00240     GError *error = NULL;
00241     GOptionContext *context;
00242     gchar *gds_name;
00243     gchar *basename;
00244     gchar *pdfname = NULL, *texname = NULL, *mappingname = NULL, *cellname = NULL, *svgname = NULL;
00245     gboolean tikz = FALSE, pdf = FALSE, pdf_layers = FALSE, pdf_standalone = FALSE, svg = FALSE;
00246     gboolean version = FALSE;
00247     gchar *custom_library_path = NULL;
00248     gchar *custom_library_file_name = NULL;
00249     int scale = 1000;
00250     int app_status = 0;
00251
00252     GOptionEntry entries[] = {
00253         {"version", 'v', 0, G_OPTION_ARG_NONE, &version, "Print version", NULL},
00254         {"tikz", 't', 0, G_OPTION_ARG_NONE, &tikz, "Output TikZ code", NULL},
00255         {"pdf", 'p', 0, G_OPTION_ARG_NONE, &pdf, "Output PDF document", NULL},
00256         /*{"svg", 'S', 0, G_OPTION_ARG_NONE, &svg, "Output SVG image", NULL},
00257         {"scale", 's', 0, G_OPTION_ARG_INT, &scale, "Divide output coordinates by <SCALE>", "<SCALE>"},
00258         {"tex-output", 'o', 0, G_OPTION_ARG_FILENAME, &texname, "Optional path for TeX file", "PATH"},
00259         {"pdf-output", 'O', 0, G_OPTION_ARG_FILENAME, &pdfname, "Optional path for PDF file", "PATH"},
00260         /*{"svg-output", 0, 0, G_OPTION_ARG_FILENAME, &svgname, "Optional path for PDF file", "PATH"},
00261         {"mapping", 'm', 0, G_OPTION_ARG_FILENAME, &mappingname, "Path for Layer Mapping File", "PATH"},
00262         {"cell", 'c', 0, G_OPTION_ARG_STRING, &cellname, "Cell to render", "NAME"},
00263         {"tex-standalone", 'a', 0, G_OPTION_ARG_NONE, &pdf_standalone, "Create standalone PDF", NULL},
00264         {"tex-layers", 'l', 0, G_OPTION_ARG_NONE, &pdf_layers, "Create PDF Layers (OCG)", NULL},
00265         {"custom-render-lib", 'P', 0, G_OPTION_ARG_FILENAME, &custom_library_path, "Path to a custom shared
object, that implements the " EXTERNAL_LIBRARY_FUNCTION " function", "PATH"},

```

```


00266     {"external-lib-output", 'e', 0, G_OPTION_ARG_FILENAME, &custom_library_file_name, "Output path for
external render library", "PATH"},
00267     {NULL}
00268 };
00269
00270 context = g_option_context_new(" FILE - Convert GDS file <FILE> to graphic");
00271 g_option_context_add_main_entries(context, entries, NULL);
00272 g_option_context_add_group(context, gtk_get_option_group(TRUE));
00273
00274 if (!g_option_context_parse(context, &argc, &argv, &error)) {
00275     g_print("Option parsing failed: %s\n", error->message);
00276     exit(1);
00277 }
00278
00279 if (version) {
00280     print_version();
00281     goto ret_status;
00282 }
00283
00284 if (argc >= 2) {
00285     if (scale < 1) {
00286         printf("Scale < 1 not allowed. Setting to 1\n");
00287         scale = 1;
00288     }
00289
00290     /* No format selected */
00291     if (!(tikz || pdf || svg))
00292         tikz = TRUE;
00293
00294     /* Get gds name */
00295     gds_name = argv[1];
00296
00297     /* Print out additional arguments as ignored */
00298     for (i = 2; i < argc; i++) {
00299         printf("Ignored argument: %s", argv[i]);
00300     }
00301
00302     /* Check if PDF/TeX names are supplied. if not generate */
00303     basename = g_path_get_basename(gds_name);
00304
00305     if (!texname)
00306         texname = g_strdup_printf("./%s.tex", basename);
00307
00308     if (!pdfname)
00309         pdfname = g_strdup_printf("./%s.pdf", basename);
00310
00311     if (!svgname)
00312         svgname = g_strdup_printf("./%s.svg", basename);
00313
00314     command_line_convert_gds(gds_name, pdfname, texname, pdf, tikz,
00315                             mappingname, cellname, (double)scale,
00316                             pdf_layers, pdf_standalone, svg, svgname,
00317                             custom_library_path, custom_library_file_name);
00318
00319     /* Clean up */
00319     g_free(pdfname);
00320     g_free(texname);
00321     g_free(svgname);
00322     g_free(basename);
00323     if (mappingname)
00324         g_free(mappingname);
00325     if (cellname)
00326         g_free(cellname);
00327     app_status = 0;
00328 } else {
00329     app_status = start_gui(argc, argv);
00330 }
00331
00332 ret_status:
00333     return app_status;
00334 }

```

13.74 mapping-parser.c File Reference

Function to read a mapping file line and parse it.


```
#include <gds-render/layer/mapping-parser.h>  
Include dependency graph for mapping-parser.c:
```



Functions

- int [mapping_parser_load_line](#) (GDataInputStream *stream, gboolean *export, char **name, int *layer, GdkRGBA *color)
Load a line from `stream` and parse try to parse it as layer information.
- void [mapping_parser_gen_csv_line](#) (LayerElement *layer_element, char *line_buffer, size_t max_len)
Create Line for LayerMapping file with supplied information.

13.74.1 Detailed Description

Function to read a mapping file line and parse it.

Author

Mario Hüttel mario.huettel@gmx.net

Definition in file [mapping-parser.c](#).

13.75 mapping-parser.c

```

00001 /*
00002  *
00003  * GDSII-Converter
00004  * Copyright (C) 2018 Mario Hüttel <mario.huettel@gmx.net>
00005  *
00006  * This file is part of GDSII-Converter.
00007  *
00008  * GDSII-Converter is free software: you can redistribute it and/or modify
00009  * it under the terms of the GNU General Public License version 2 as
00010  * published by the Free Software Foundation.
00011  *
00012  * GDSII-Converter is distributed in the hope that it will be useful,
00013  * but WITHOUT ANY WARRANTY; without even the implied warranty of
00014  * MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE. See the
00015  * GNU General Public License for more details.
00016  *
00017  * You should have received a copy of the GNU General Public License
00018  * along with GDSII-Converter. If not, see <http://www.gnu.org/licenses/>.
00019  */
00020
00021 #include <gds-render/layer/mapping-parser.h>
00022
00023
00024 int mapping_parser_load_line(GDataInputStream *stream, gboolean *export, char **
name, int *layer, GdkRGBA *color)
00025 {
00026     int ret;
00027     gsize len;
00028     gchar *line;
00029     GRegex *regex;
00030     GMatchInfo *mi;
00031     char *match;
00032
00033     if ((!export) || (!name) || (!layer) || (!color)) {
00034         ret = 1;
00035         goto ret_direct;
00036     }
00037
00038     regex = g_regex_new("(?<layer>[0-9]+), (?<r>[0-9\\.]+), (?<g>[0-9\\.]+), (?<b>[0-9\\.]+), (?<a>[0-9\\.]+), (?<export>[01]), (?<name>.*)$", 0, 0, NULL);
00039
00040     line = g_data_input_stream_read_line(stream, &len, NULL, NULL);
00041     if (!line) {
00042         ret = -1;
00043         goto destroy_regex;
00044     }
00045
00046     /* Match line in CSV */
00047     g_regex_match(regex, line, 0, &mi);
00048     if (g_match_info_matches(mi)) {
00049         /* Line is valid */
00050         match = g_match_info_fetch_named(mi, "layer");
00051         *layer = (int)g_ascii_strtoll(match, NULL, 10);
00052         g_free(match);
00053         match = g_match_info_fetch_named(mi, "r");
00054         color->red = g_ascii_strtod(match, NULL);
00055         g_free(match);
00056         match = g_match_info_fetch_named(mi, "g");
00057         color->green = g_ascii_strtod(match, NULL);
00058         g_free(match);
00059         match = g_match_info_fetch_named(mi, "b");
00060         color->blue = g_ascii_strtod(match, NULL);
00061         g_free(match);
00062         match = g_match_info_fetch_named(mi, "a");
00063         color->alpha = g_ascii_strtod(match, NULL);
00064         g_free(match);
00065         match = g_match_info_fetch_named(mi, "export");
00066         *export = (!strcmp(match, "1")) ? TRUE : FALSE;
00067         g_free(match);
00068         match = g_match_info_fetch_named(mi, "name");
00069         *name = match;
00070
00071         ret = 0;
00072     } else {
00073         /* Line is malformed */
00074         printf("Could not recognize line in CSV as valid entry: %s\n", line);
00075         ret = 1;
00076     }
00077
00078     g_match_info_free(mi);
00079     g_free(line);
00080     destroy_regex:
00081     g_regex_unref(regex);
00082     ret_direct:
00083     return ret;

```

```

00094
00095 }
00096
00097 void mapping_parser_gen_csv_line(LayerElement *layer_element, char *line_buffer,
    size_t max_len)
00098 {
00099     int i;
00100     GString *string;
00101     gboolean export;
00102     const gchar *name;
00103     int layer;
00104     GdkRGBA color;
00105
00106     string = g_string_new_len(NULL, max_len-1);
00107
00108     /* Extract values */
00109     export = layer_element_get_export(layer_element);
00110     name = (const gchar*)layer_element_get_name(layer_element);
00111     layer = layer_element_get_layer(layer_element);
00112     layer_element_get_color(layer_element, &color);
00113
00114     /* print values to line */
00115     g_string_printf(string, "%d:%lf:%lf:%lf:%lf:%d:%s\n",
00116         layer, color.red, color.green,
00117         color.blue, color.alpha, (export == TRUE ? 1 : 0), name);
00118     /* Fix broken locale settings */
00119     for (i = 0; string->str[i]; i++) {
00120         if (string->str[i] == '/')
00121             string->str[i] = '.';
00122     }
00123
00124     for (i = 0; string->str[i]; i++) {
00125         if (string->str[i] == ':')
00126             string->str[i] = ',';
00127     }
00128
00129     if (string->len > (max_len-1)) {
00130         printf("Layer Definition too long. Please shorten Layer Name!!\n");
00131         line_buffer[0] = 0x0;
00132         return;
00133     }
00134
00135     /* copy max_len bytes of string */
00136     strncpy(line_buffer, (char *)string->str, max_len-1);
00137     line_buffer[max_len-1] = 0;
00138
00139     /* Completely remove string */
00140     g_string_free(string, TRUE);
00141 }
00142

```

13.76 mapping-parser.h File Reference


Function to read a mapping file line and parse it.

```


#include <glib.h>
#include <gds-render/widgets/layer-element.h>

```

Include dependency graph for mapping-parser.h:



This graph shows which files directly or indirectly include this file:



Functions

- int [mapping_parser_load_line](#) (GDataInputStream *stream, gboolean *export, char **name, int *layer, GdkRGBA *color)
Load a line from stream and parse try to parse it as layer information.
- void [mapping_parser_gen_csv_line](#) (LayerElement *layer_element, char *line_buffer, size_t max_len)
Create Line for LayerMapping file with supplied information.

13.76.1 Detailed Description

Function to read a mapping file line and parse it.

Author

Mario Hüttel mario.huettel@gmx.net

Definition in file [mapping-parser.h](#).

13.77 mapping-parser.h

```

00001 /*
00002  * GDSII-Converter
00003  * Copyright (C) 2018 Mario Hüttel <mario.huettel@gmx.net>
00004  *
00005  * This file is part of GDSII-Converter.
00006  *
00007  * GDSII-Converter is free software: you can redistribute it and/or modify
00008  * it under the terms of the GNU General Public License version 2 as
00009  * published by the Free Software Foundation.
00010  *
00011  * GDSII-Converter is distributed in the hope that it will be useful,
00012  * but WITHOUT ANY WARRANTY; without even the implied warranty of
00013  * MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE. See the
00014  * GNU General Public License for more details.
00015  *
00016  * You should have received a copy of the GNU General Public License
00017  * along with GDSII-Converter. If not, see <http://www.gnu.org/licenses/>.
00018  */
00019
00026 #ifndef __MAPPING_PARSER_H__
00027 #define __MAPPING_PARSER_H__
00028
00034 #include <glib.h>
00035
00036 #include <gds-render/widgets/layer-element.h>
00037
00047 int mapping_parser_load_line(GDataInputStream *stream, gboolean *export, char **
name, int *layer, GdkRGBA *color);
00048
00055 void mapping_parser_gen_csv_line(LayerElement *layer_element, char *line_buffer,
size_t max_len);
00056
00059 #endif /* __MAPPING_PARSER_H__ */

```

13.78 README.MD File Reference

13.79 README.MD

```

00001 # GDS-Render Readme
00002
00003 This software is a rendering programm for GDS2 layout files.
00004 The GDS2 format is mainly used in integrated circuit development.
00005 This program allows the conversion of a GDS file to a vector graphics file.
00006
00007 ## Output Formats
00008 * Export GDS Layout to LaTeX (using TikZ).
00009 * Export to PDF (Cairographics).
00010
00011 # Features
00012 Note: Due to various size limitations of both TikZ and the PDF export, the layout might not render
correctly. In this case adjust the scale value. A higher scale value scales down your design.
00013
00014 * Configurable layer stack-up.
00015 * Layer colors configurable as ARGB color values.
00016 * Command line interface.
00017 * ~~Awesome~~ Somehow usable GUI.
00018
00019 # License and Other Stuff
00020 * Free software (GPLv2 _only_)
00021 * Coded in plain C using GTK+3.0, Glib2, and Cairographics

```

13.80 renderers.dox File Reference


13.81 tree-store.c File Reference

```

#include <gds-render/tree-renderer/tree-store.h>
#include <gds-render/tree-renderer/lib-cell-renderer.h>

```

```
#include <gds-render/gds-utils/gds-types.h>
Include dependency graph for tree-store.c:
```



Functions

- static gboolean [tree_sel_func](#) (GtkTreeSelection *selection, GtkTreeModel *model, GtkTreePath *path, gboolean path_currently_selected, gpointer data)
this function only allows cells to be selected
- static gboolean [cell_store_filter_visible_func](#) (GtkTreeModel *model, GtkTreeIter *iter, gpointer data)
cell_store_filter_visible_func Decides whether an element of the tree model model is visible.
- static void [change_filter](#) (GtkWidget *entry, gpointer data)
- struct [tree_stores](#) * [setup_cell_selector](#) (GtkTreeView *view, GtkEntry *search_entry)
Setup a GtkTreeView with the necessary columns.

13.82 tree-store.c

```

00001 /*
00002  * GDSII-Converter
00003  * Copyright (C) 2018 Mario Hüttel <mario.huettel@gmx.net>
00004  *
00005  * This file is part of GDSII-Converter.
00006  *
00007  * GDSII-Converter is free software: you can redistribute it and/or modify
00008  * it under the terms of the GNU General Public License version 2 as
00009  * published by the Free Software Foundation.
00010  *
00011  * GDSII-Converter is distributed in the hope that it will be useful,
00012  * but WITHOUT ANY WARRANTY; without even the implied warranty of
00013  * MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE. See the
00014  * GNU General Public License for more details.
00015  *
00016  * You should have received a copy of the GNU General Public License
00017  * along with GDSII-Converter. If not, see <http://www.gnu.org/licenses/>.
00018  */
00019
00020 #include <gds-render/tree-renderer/tree-store.h>
00021 #include <gds-render/tree-renderer/lib-cell-renderer.h>
00022 #include <gds-render/gds-utils/gds-types.h>
00023
00024 static gboolean tree_sel_func(GtkTreeSelection *selection,
00025                             GtkTreeModel *model,
00026                             GtkTreePath *path,
00027                             gboolean path_currently_selected,
00028                             gpointer data)
00029 {
00030     GtkTreeIter iter;
00031     struct gds_cell *cell;
00032     unsigned int error_level;

```

```

00053     gboolean ret = FALSE;
00054     (void)selection;
00055     (void)path_currently_selected;
00056     (void)data;
00057
00058     gtk_tree_model_get_iter(model, &iter, path);
00059     gtk_tree_model_get(model, &iter, CELL_SEL_CELL, &cell,
CELL_SEL_CELL_ERROR_STATE, &error_level, -1);
00060
00061     /* Allow only rows with _valid_ cell to be selected */
00062     if (cell) {
00063         /* Cell available. Check if it passed the critical checks */
00064         if (!(error_level & LIB_CELL_RENDERER_ERROR_ERR))
00065             ret = TRUE;
00066     }
00067
00068     return ret;
00069 }
00070
00079 static gboolean cell_store_filter_visible_func(GtkTreeModel *model,
GtkTreeIter *iter, gpointer data)
00080 {
00081     struct tree_stores *stores = (struct tree_stores *)data;
00082     struct gds_cell *cell;
00083     struct gds_library *lib;
00084     gboolean result = FALSE;
00085     const char *search_string;
00086
00087     if (!model || !iter || !stores)
00088         goto exit_filter;
00089
00090     gtk_tree_model_get(model, iter, CELL_SEL_CELL, &cell,
CELL_SEL_LIBRARY, &lib, -1);
00091
00092     if (lib) {
00093         result = TRUE;
00094         goto exit_filter;
00095     }
00096
00097     if (!cell)
00098         goto exit_filter;
00099
00100     search_string = gtk_entry_get_text(stores->search_entry);
00101
00102     /* Show all, if field is empty */
00103     if (!strlen(search_string))
00104         result = TRUE;
00105
00106     if (strstr(cell->name, search_string))
00107         result = TRUE;
00108
00109     gtk_tree_view_expand_all(stores->base_tree_view);
00110
00111 exit_filter:
00112     return result;
00113 }
00114
00115 static void change_filter(GtkWidget *entry, gpointer data)
00116 {
00117     struct tree_stores *stores = (struct tree_stores *)data;
00118     (void)entry;
00119
00120     gtk_tree_model_filter_refilter(stores->filter);
00121 }
00122
00129 struct tree_stores *setup_cell_selector(GtkTreeView* view, GtkEntry *
search_entry)
00130 {
00131     static struct tree_stores stores;
00132     GtkWidget *render_dates;
00133     GtkWidget *render_cell;
00134     GtkWidget *render_lib;
00135     GtkWidget *column;
00136
00137     stores.base_tree_view = view;
00138     stores.search_entry = search_entry;
00139
00140     stores.base_store = gtk_tree_store_new(CELL_SEL_COLUMN_COUNT,
G_TYPE_POINTER, G_TYPE_POINTER, G_TYPE_UINT, G_TYPE_STRING, G_TYPE_STRING);
00141
00142     /* Searching */
00143     if (search_entry) {
00144         stores.filter = GTK_TREE_MODEL_FILTER(gtk_tree_model_filter_new(GTK_TREE_MODEL(stores.
base_store), NULL));
00145         gtk_tree_model_filter_set_visible_func (stores.filter,
(GtkTreeModelFilterVisibleFunc)
00146         cell_store_filter_visible_func,

```

```

00147         &stores, NULL);
00148     g_signal_connect(GTK_SEARCH_ENTRY(search_entry), "search-changed", G_CALLBACK(
change_filter), &stores);
00149 }
00150
00151     gtk_tree_view_set_model(view, GTK_TREE_MODEL(stores.filter));
00152
00153     render_dates = gtk_cell_renderer_text_new();
00154     render_cell = lib_cell_renderer_new();
00155     render_lib = lib_cell_renderer_new();
00156
00157     column = gtk_tree_view_column_new_with_attributes("Library", render_lib, "gds-lib",
CELL_SEL_LIBRARY, NULL);
00158     gtk_tree_view_append_column(view, column);
00159
00160     column = gtk_tree_view_column_new_with_attributes("Cell", render_cell, "gds-cell",
CELL_SEL_CELL,
00161         "error-level", CELL_SEL_CELL_ERROR_STATE, NULL);
00162     gtk_tree_view_append_column(view, column);
00163
00164     column = gtk_tree_view_column_new_with_attributes("Mod. Date", render_dates, "text",
CELL_SEL_MODDATE, NULL);
00165     gtk_tree_view_append_column(view, column);
00166
00167     column = gtk_tree_view_column_new_with_attributes("Acc. Date", render_dates, "text",
CELL_SEL_ACCESSDATE, NULL);
00168     gtk_tree_view_append_column(view, column);
00169
00170     /* Callback for selection
00171      * This prevents selecting a library */
00172     gtk_tree_selection_set_select_function(gtk_tree_view_get_selection(view),
tree_sel_func, NULL, NULL);
00173
00174     return &stores;
00175 }


```

13.83 tree-store.h File Reference


Header file for Tree store implementation.

```
#include <gtk/gtk.h>
```

Include dependency graph for tree-store.h:



This graph shows which files directly or indirectly include this file:



Data Structures

- struct [tree_stores](#)

Enumerations

- enum [cell_store_columns](#) {
[CELL_SEL_LIBRARY](#) = 0, [CELL_SEL_CELL](#), [CELL_SEL_CELL_ERROR_STATE](#), [CELL_SEL_MODDATE](#),
[CELL_SEL_ACCESSDATE](#), [CELL_SEL_COLUMN_COUNT](#) }

Columns of selection tree view.

Functions

- struct [tree_stores](#) * [setup_cell_selector](#) (GtkTreeView *view, GtkEntry *search_entry)

Setup a GtkTreeView with the necessary columns.

13.83.1 Detailed Description

Header file for Tree store implementation.

Tree store implementation.

Author

Mario Hüttel mario.huettel@gmx.net

Definition in file [tree-store.h](#).

13.84 tree-store.h

```
00001 /*
00002  * GDSII-Converter
00003  * Copyright (C) 2018 Mario Hüttel <mario.huettel@gmx.net>
00004  *
00005  * This file is part of GDSII-Converter.
00006  *
00007  * GDSII-Converter is free software: you can redistribute it and/or modify
00008  * it under the terms of the GNU General Public License version 2 as
00009  * published by the Free Software Foundation.
00010  *
00011  * GDSII-Converter is distributed in the hope that it will be useful,
00012  * but WITHOUT ANY WARRANTY; without even the implied warranty of
00013  * MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE. See the
00014  * GNU General Public License for more details.
00015  *
00016  * You should have received a copy of the GNU General Public License
00017  * along with GDSII-Converter. If not, see <http://www.gnu.org/licenses/>.
00018  */
00019
00031 #ifndef __TREE_STORE_H__
00032 #define __TREE_STORE_H__
00033
00034 #include <gtk/gtk.h>
00035
00037 enum cell_store_columns {
00038     CELL_SEL_LIBRARY = 0,
00039     CELL_SEL_CELL,
00040     CELL_SEL_CELL_ERROR_STATE,
00041     CELL_SEL_MODDATE,
00042     CELL_SEL_ACCESSDATE,
00043     CELL_SEL_COLUMN_COUNT
00044 };
00045
00046 struct tree_stores {
00047     GtkTreeView *base_tree_view;
00048     GtkTreeStore *base_store;
00049     GtkTreeModelFilter *filter;
00050     GtkEntry *search_entry;
00051 };
00052
00053 struct tree_stores *setup_cell_selector(GtkTreeView* view, GtkEntry *
search_entry);
00054
00055 #endif /* __TREE_STORE_H__ */
00056
```


13.85 usage.dox File Reference

13.86 vector-operations.c File Reference

2D Vector operations

```
#include <math.h>
#include <stdlib.h>
#include <gds-render/geometric/vector-operations.h>
```

Include dependency graph for vector-operations.c:



Macros

- `#define ABS_DBL(a) ((a) < 0 ? -(a) : (a))`

Functions

- double `vector_2d_scalar_multiply` (struct `vector_2d` *a, struct `vector_2d` *b)
- void `vector_2d_normalize` (struct `vector_2d` *vec)
- void `vector_2d_rotate` (struct `vector_2d` *vec, double angle)
- struct `vector_2d` * `vector_2d_copy` (struct `vector_2d` *opt_res, struct `vector_2d` *vec)
- struct `vector_2d` * `vector_2d_alloc` (void)
- void `vector_2d_free` (struct `vector_2d` *vec)
- void `vector_2d_scale` (struct `vector_2d` *vec, double scale)
- double `vector_2d_abs` (struct `vector_2d` *vec)
- double `vector_2d_calculate_angle_between` (struct `vector_2d` *a, struct `vector_2d` *b)
- void `vector_2d_subtract` (struct `vector_2d` *res, struct `vector_2d` *a, struct `vector_2d` *b)
- void `vector_2d_add` (struct `vector_2d` *res, struct `vector_2d` *a, struct `vector_2d` *b)

13.86.1 Detailed Description

2D Vector operations

Author

Mario Hüttel mario.huettel@gmx.net

Definition in file [vector-operations.c](#).

13.87 vector-operations.c

```

00001 /*
00002  * GDSII-Converter
00003  * Copyright (C) 2018 Mario Hüttel <mario.huettel@gmx.net>
00004  *
00005  * This file is part of GDSII-Converter.
00006  *
00007  * GDSII-Converter is free software: you can redistribute it and/or modify
00008  * it under the terms of the GNU General Public License version 2 as
00009  * published by the Free Software Foundation.
00010  *
00011  * GDSII-Converter is distributed in the hope that it will be useful,
00012  * but WITHOUT ANY WARRANTY; without even the implied warranty of
00013  * MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE. See the
00014  * GNU General Public License for more details.
00015  *
00016  * You should have received a copy of the GNU General Public License
00017  * along with GDSII-Converter. If not, see <http://www.gnu.org/licenses/>.
00018  */
00019
00031 #include <math.h>
00032 #include <stdlib.h>
00033
00034 #include <gds-render/geometric/vector-operations.h>
00035
00036 #define ABS_DBL(a) ((a) < 0 ? -(a) : (a))
00037
00038 double vector_2d_scalar_multiply(struct vector_2d *a, struct
vector_2d *b)
00039 {
00040     if (a && b)
00041         return (a->x * b->x) + (a->y * b->y);
00042     else
00043         return 0.0;
00044 }
00045
00046 void vector_2d_normalize(struct vector_2d *vec)
00047 {
00048     double len;
00049     if (!vec)
00050         return;
00051     len = sqrt(pow(vec->x,2)+pow(vec->y,2));
00052     vec->x = vec->x/len;
00053     vec->y = vec->y/len;
00054 }
00055
00056 void vector_2d_rotate(struct vector_2d *vec, double angle)
00057 {
00058     double sin_val, cos_val;
00059     struct vector_2d temp;
00060
00061     if (!vec)
00062         return;
00063
00064     sin_val = sin(angle);
00065     cos_val = cos(angle);
00066
00067     vector_2d_copy(&temp, vec);
00068
00069     /* Apply rotation matrix */
00070     vec->x = (cos_val * temp.x) - (sin_val * temp.y);
00071     vec->y = (sin_val * temp.x) + (cos_val * temp.y);
00072 }
00073
00074 struct vector_2d *vector_2d_copy(struct vector_2d *opt_res, struct
vector_2d *vec)
00075 {
00076     struct vector_2d *res;
00077
00078     if (!vec)
00079         return NULL;
00080
00081     if (opt_res)
00082         res = opt_res;
00083     else
00084         res = vector_2d_alloc();
00085
00086     if (res) {
00087         res->x = vec->x;
00088         res->y = vec->y;
00089     }
00090     return res;
00091 }
00092
00093 struct vector_2d *vector_2d_alloc(void)

```


```
00094 {
00095     return (struct vector_2d *)malloc(sizeof(struct vector_2d));
00096 }
00097
00098 void vector_2d_free(struct vector_2d *vec)
00099 {
00100     if (vec) {
00101         free(vec);
00102     }
00103 }
00104
00105 void vector_2d_scale(struct vector_2d *vec, double scale)
00106 {
00107     if (!vec)
00108         return;
00109     vec->x *= scale;
00110     vec->y *= scale;
00111 }
00112
00113
00114 double vector_2d_abs(struct vector_2d *vec)
00115 {
00116     double len = 0.0;
00117     if (vec) {
00118         len = sqrt(pow(vec->x,2)+pow(vec->y,2));
00119     }
00120     return len;
00121 }
00122
00123 double vector_2d_calculate_angle_between(struct
vector_2d *a, struct vector_2d *b)
00124 {
00125     double cos_angle;
00126
00127     if (!a || !b)
00128         return 0.0;
00129
00130     cos_angle = ABS_DBL(vector_2d_scalar_multiply(a, b)) / (
vector_2d_abs(a) * vector_2d_abs(b));
00131     return acos(cos_angle);
00132 }
00133
00134 void vector_2d_subtract(struct vector_2d *res, struct
vector_2d *a, struct vector_2d *b)
00135 {
00136     if (res && a && b) {
00137         res->x = a->x - b->x;
00138         res->y = a->y - b->y;
00139     }
00140 }
00141
00142 void vector_2d_add(struct vector_2d *res, struct vector_2d *a, struct
vector_2d *b)
00143 {
00144     if (res && a && b) {
00145         res->x = a->x + b->x;
00146         res->y = a->y + b->y;
00147     }
00148 }
00149
```

13.88 vector-operations.h File Reference


Header for 2D Vector operations.

```
#include <math.h>
```

Include dependency graph for vector-operations.h:



This graph shows which files directly or indirectly include this file:



Data Structures

- struct [vector_2d](#)

Macros

- #define [DEG2RAD\(a\)](#) ((a)*M_PI/180.0)

Functions

- double `vector_2d_scalar_multiply` (struct `vector_2d` *a, struct `vector_2d` *b)
- void `vector_2d_normalize` (struct `vector_2d` *vec)
- void `vector_2d_rotate` (struct `vector_2d` *vec, double angle)
- struct `vector_2d` * `vector_2d_copy` (struct `vector_2d` *opt_res, struct `vector_2d` *vec)
- struct `vector_2d` * `vector_2d_alloc` (void)
- void `vector_2d_free` (struct `vector_2d` *vec)
- void `vector_2d_scale` (struct `vector_2d` *vec, double scale)
- double `vector_2d_abs` (struct `vector_2d` *vec)
- double `vector_2d_calculate_angle_between` (struct `vector_2d` *a, struct `vector_2d` *b)
- void `vector_2d_subtract` (struct `vector_2d` *res, struct `vector_2d` *a, struct `vector_2d` *b)
- void `vector_2d_add` (struct `vector_2d` *res, struct `vector_2d` *a, struct `vector_2d` *b)

13.88.1 Detailed Description

Header for 2D Vector operations.

Author

Mario Hüttel mario.huettel@gmx.net

Definition in file `vector-operations.h`.

13.89 vector-operations.h

```

00001 /*
00002  * GDSII-Converter
00003  * Copyright (C) 2018 Mario Hüttel <mario.huettel@gmx.net>
00004  *
00005  * This file is part of GDSII-Converter.
00006  *
00007  * GDSII-Converter is free software: you can redistribute it and/or modify
00008  * it under the terms of the GNU General Public License version 2 as
00009  * published by the Free Software Foundation.
00010  *
00011  * GDSII-Converter is distributed in the hope that it will be useful,
00012  * but WITHOUT ANY WARRANTY; without even the implied warranty of
00013  * MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE. See the
00014  * GNU General Public License for more details.
00015  *
00016  * You should have received a copy of the GNU General Public License
00017  * along with GDSII-Converter. If not, see <http://www.gnu.org/licenses/>.
00018  */
00019
00032 #ifndef _VECTOR_OPERATIONS_H_
00033 #define _VECTOR_OPERATIONS_H_
00034
00035 #include <math.h>
00036
00037 struct vector_2d {
00038     double x;
00039     double y;
00040 };
00041
00042 #define DEG2RAD(a) ((a)*M_PI/180.0)
00043
00044 double vector_2d_scalar_multiply(struct vector_2d *a, struct
vector_2d *b);
00045 void vector_2d_normalize(struct vector_2d *vec);
00046 void vector_2d_rotate(struct vector_2d *vec, double angle);
00047 struct vector_2d *vector_2d_copy(struct vector_2d *opt_res, struct
vector_2d *vec);
00048 struct vector_2d *vector_2d_alloc(void);
00049 void vector_2d_free(struct vector_2d *vec);
00050 void vector_2d_scale(struct vector_2d *vec, double scale);

```

```

00051 double vector_2d_abs(struct vector_2d *vec);
00052 double vector_2d_calculate_angle_between(struct
vector_2d *a, struct vector_2d *b);
00053 void vector_2d_subtract(struct vector_2d *res, struct
vector_2d *a, struct vector_2d *b);
00054 void vector_2d_add(struct vector_2d *res, struct vector_2d *a, struct
vector_2d *b);
00055
00056 #endif /* _VECTOR_OPERATIONS_H_ */
00057

```

13.90 version.c File Reference

Variables

- const char * `_app_version_string` = "!" version not set !"

This string holds the [Git Based Version Number](#) of the app.

13.91 version.c


```

00001 /*
00002  * GDSII-Converter
00003  * Copyright (C) 2018 Mario Hüttel <mario.huettel@gmx.net>
00004  *
00005  * This file is part of GDSII-Converter.
00006  *
00007  * GDSII-Converter is free software: you can redistribute it and/or modify
00008  * it under the terms of the GNU General Public License version 2 as
00009  * published by the Free Software Foundation.
00010  *
00011  * GDSII-Converter is distributed in the hope that it will be useful,
00012  * but WITHOUT ANY WARRANTY; without even the implied warranty of
00013  * MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE. See the
00014  * GNU General Public License for more details.
00015  *
00016  * You should have received a copy of the GNU General Public License
00017  * along with GDSII-Converter. If not, see <http://www.gnu.org/licenses/>.
00018  */
00019
00020
00028 #ifdef PROJECT_GIT_VERSION
00029 #define xstr(a) str(a)
00030 #define str(a) #a
00031 const char *_app_version_string = xstr(PROJECT_GIT_VERSION);
00032 #else
00033 const char *_app_version_string = "!" version not set !";
00034 #endif
00035

```

13.92 version.h File Reference

This graph shows which files directly or indirectly include this file:



Variables

- `const char * _app_version_string`

This string holds the [Git Based Version Number](#) of the app.

13.93 version.h

```
00001 /*
00002  * GDSII-Converter
00003  * Copyright (C) 2018 Mario Hüttel <mario.huettel@gmx.net>
00004  *
00005  * This file is part of GDSII-Converter.
00006  *
00007  * GDSII-Converter is free software: you can redistribute it and/or modify
00008  * it under the terms of the GNU General Public License version 2 as
00009  * published by the Free Software Foundation.
00010  *
00011  * GDSII-Converter is distributed in the hope that it will be useful,
00012  * but WITHOUT ANY WARRANTY; without even the implied warranty of
00013  * MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE. See the
00014  * GNU General Public License for more details.
00015  *
00016  * You should have received a copy of the GNU General Public License
00017  * along with GDSII-Converter. If not, see <http://www.gnu.org/licenses/>.
00018  */
00019
00026 extern const char *_app_version_string;
00027
```

13.94 versioning.dox File Reference

13.95 widgets.dox File Reference

